



Owner's Manual Manual Pemilik

Read before you ride!

Baca sebelum menunggang!

Use Only Honda Genuine Parts

Use Honda Lubricant
for Greater Performance



This manual should be considered a permanent part of the vehicle and should remain with the vehicle when it is resold.

This publication includes the latest production information available before printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation.

No part of this publication may be reproduced without written permission.

The vehicle pictured in this owner's manual may not match your actual vehicle.

Welcome

Congratulations on your purchase of a new Honda vehicle. Your selection of a Honda makes you part of a worldwide family of satisfied customers who appreciate Honda's reputation for building quality into every product.

To ensure your safety and riding pleasure:

- Read this owner's manual carefully.
- Follow all recommendations and procedures contained in this manual.
- Pay close attention to safety messages contained in this manual and on the vehicle.

- The following codes in this manual indicate the country.
- The illustrations here in are based on the AFS110MD MA type.

Country Codes

Code	Country
------	---------

AFS110MD

MA	Malaysia
----	----------

AFS110MCS

MA	Malaysia
----	----------

A Few Words About Safety

Your safety, and the safety of others, is very important. Operating this vehicle safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on safety labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all hazards associated with operating or maintaining a vehicle. You must use your own good judgement.

You will find important safety information in a variety of forms, including:

- Safety labels on the vehicle
 - Safety Messages preceded by a safety alert symbol  and one of three signal words: DANGER, WARNING, or CAUTION.
- These signal words mean:

DANGER

You **WILL** be KILLED or SERIOUSLY HURT if you don't follow instructions.

WARNING

You **CAN** be KILLED or SERIOUSLY HURT if you don't follow instructions.

CAUTION

You **CAN** be HURT if you don't follow instructions.

Other important information is provided under the following titles:

- NOTICE** Information to help you avoid damage to your vehicle, other property, or the environment.

Contents

Vehicle Safety

P. 2

Operation Guide

P. 12

Maintenance

P. 32

Troubleshooting

P. 76

Information

P. 94

Specifications

P. 105

Index

P. 108

Vehicle Safety

This section contains important information for safe riding of your vehicle.
Please read this section carefully.

Safety Guidelines	P. 3
Safety Precautions	P. 6
Riding Precautions.....	P. 7
Accessories & Modifications.....	P. 10
Loading	P. 11

Safety Guidelines

Follow these guidelines to enhance your safety:

- Perform all routine and regular inspections specified in this manual.
- Stop the engine and keep sparks and flame away before filling the fuel tank.
- Do not run the engine in enclosed or partly enclosed areas. Carbon monoxide in exhaust gases is toxic and can kill you.

Always Wear a Helmet

It's a proven fact: helmets and protective apparel significantly reduce the number and severity of head and other injuries. So always wear an approved helmet and protective apparel. 📖 P. 6

Before Riding

Make sure that you are physically fit, mentally focused and free of alcohol and drugs. Check that you and your passenger are both wearing

an approved helmet and protective apparel. Instruct your passenger on holding onto the grab rail or your waist, leaning with you in turns, and keeping their feet on the footpegs, even when the vehicle is stopped.

Take Time to Learn & Practice

Even if you have ridden other vehicles, practice riding in a safe area to become familiar with how this vehicle works and handles, and to become accustomed to the vehicle's size and weight.

Ride Defensively

Always pay attention to other vehicles around you, and do not assume that other drivers see you. Be prepared to stop quickly or perform an evasive maneuver.

Safety Guidelines

Make Yourself Easy to See

Make yourself more visible, especially at night, by wearing bright reflective clothing, positioning yourself so other drivers can see you, signaling before turning or changing lanes, and using your horn when necessary.

Ride within Your Limits

Never ride beyond your personal abilities or faster than conditions warrant. Fatigue and inattention can impair your ability to use good judgement and ride safely.

Don't Drink and Ride

Alcohol and riding don't mix. Even one alcoholic drink can reduce your ability to respond to changing conditions, and your reaction time gets worse with every additional drink. Don't drink and ride, and don't let your friends drink and ride either.

Keep Your Honda in Safe Condition

It's important to keep your vehicle properly maintained and in safe riding condition. Inspect your vehicle before every ride and perform all recommended maintenance. Never exceed load limits (➡ P. 11), and do not modify your vehicle or install accessories that would make your vehicle unsafe (➡ P. 10).

If You are Involved in a Crash

Personal safety is your first priority. If you or anyone else has been injured, take time to assess the severity of the injuries and whether it is safe to continue riding. Call for emergency assistance if needed. Also follow applicable laws and regulations if another person or vehicle is involved in the crash.

If you decide to continue riding, first turn the ignition switch to the **○** (Off) position, and evaluate the condition of your vehicle. Inspect for

fluid leaks, check the tightness of critical nuts and bolts, and check the handlebar, control levers, brakes, and wheels. Ride slowly and cautiously. Your vehicle may have suffered damage that is not immediately apparent. Have your vehicle thoroughly checked at a qualified service facility as soon as possible.

Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colourless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in confined or even partly enclosed area, the air you breathe could contain a dangerous amount of carbon monoxide. Never run your vehicle inside a garage or other enclosure.

WARNING

Running the engine of your vehicle while in an enclosed or even partially enclosed area can cause a rapid build-up of toxic carbon monoxide gas.

Breathing this colourless, odorless gas can quickly cause unconsciousness and lead to death

Only run your vehicle's engine when it is located in a well ventilated area outdoors.

Safety Precautions

Safety Precautions

- Ride cautiously and keep your hands on the handlebar and feet on the footpegs.
- Keep passenger's hands onto the grab rail or your waist, passenger's feet on the footpegs while riding.
- Always consider the safety of your passenger, as well as other drivers and riders.

Protective Apparel

Make sure that you and any passenger are wearing an approved helmet, eye protection, and high-visibility protective clothing. Ride defensively in response to weather and road conditions.

■ Helmet

Safety-standard certified, high-visibility, correct size for your head

- Must fit comfortably but securely, with the chin strap fastened.

- Face shield with unobstructed field of vision or other approved eye protection

⚠ WARNING

Not wearing a helmet increases the chance of serious injury or death in a crash.

Make sure that you and any passenger always wear an approved helmet and protective apparel.

■ Gloves

Full-finger leather gloves with high abrasion resistance

■ Boots or Riding Shoes

Sturdy boots with non-slip soles and ankle protection

■ Jacket and Trousers

Protective, highly visible, long-sleeved jacket and durable trousers for riding (or a protective suit)

Riding Precautions

Running-in Period

During the first 500 km (300 miles) of running, follow these guidelines to ensure your vehicle's future reliability and performance.

- Avoid full-throttle starts and rapid acceleration.
- Avoid hard braking and rapid down-shifts.
- Ride conservatively.

Brakes

Observe the following guidelines:

- Avoid excessively hard braking and downshifting.
 - ▶ Sudden braking can reduce the vehicle's stability.
 - ▶ Where possible, reduce speed before turning; otherwise you risk sliding out.
- Exercise caution on low traction surfaces.
 - ▶ The tyres slip more easily on such surfaces

and braking distances are longer.

- Avoid continuous braking.
 - ▶ Repeated braking, such as when descending long, steep slopes can seriously overheat the brakes, reducing their effectiveness. Use engine braking with intermittent use of the brakes to reduce speed.
- For full braking effectiveness, operate both the front and rear brakes together.

Riding Precautions

■ Engine Braking

Engine braking helps slow your vehicle down when you release the throttle. For further slowing action, downshift to a lower gear. Use engine braking with intermittent use of the brakes to reduce speed when descending long, steep slopes.

■ Wet or Rainy Conditions

Road surfaces are slippery when wet, and wet brakes further reduce braking efficiency. Exercise extra caution when braking in wet conditions.

If the brakes get wet, apply the brakes while riding at low speed to help them dry.

Parking

- Park on a firm, level surface.
- If you must park on a slight incline or loose surface, park so that the vehicle cannot move or fall over.
- Make sure that high-temperature parts cannot come into contact with flammable materials.
- Do not touch the engine, muffler, brakes and other high-temperature parts until they cool down.
- To reduce the likelihood of theft, always lock the handlebar and remove the key when leaving the vehicle unattended. Use of an anti-theft device is also recommended.

■ Parking with the Side Stand or Centre Stand

1 Stop the engine.


2 Using the side stand

Push the side stand down.

Slowly lean the vehicle to the left until its weight rests on the side stand.

Using the centre stand

To lower the centre stand, stand on the left side of the vehicle. Hold the left handle grip and the grab rail. Press down on the tip of the centre stand with your right foot and, simultaneously, pull up and back.



3. Turn the handlebar fully to the left.
► Turning the handlebar to the right reduces stability and may cause the vehicle to fall.
4. Turn the ignition switch to the  (Lock) position and remove the key.  P. 21

Refuelling and Fuel Guidelines

Follow these guidelines to protect the engine, fuel system and catalytic converter:

- Use only unleaded petrol.
- Use recommended octane number. Using lower octane petrol will result in decreased engine performance.
- Do not use fuels containing a high concentration of alcohol.  P. 103
- Do not use stale or contaminated petrol or an oil/petrol mixture.
- Avoid getting dirt or water in the fuel tank.

Accessories & Modifications

We strongly advise that you do not add any accessories that were not specifically designed for your vehicle by Honda or make modifications to your vehicle from its original design. Doing so can make it unsafe.

Modifying your vehicle may also void your warranty and make your vehicle illegal to operate on public roads and highways. Before deciding to install accessories on your vehicle be certain the modification is safe and legal.

WARNING

Improper accessories or modifications can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding accessories and modifications.

Do not pull a trailer with, or attach a sidecar to, your vehicle. Your vehicle was not designed for these attachments, and their use can seriously impair your vehicle's handling.

Loading

- Carrying extra weight affects your vehicle's handling, braking and stability.
Always ride at a safe speed for the load you are carrying.
- Avoid carrying an excessive load and keep within specified load limits.
Maximum weight capacity / Maximum luggage weight 📖 P. 105
- Tie all luggage securely, evenly balanced and close to the centre of the vehicle.
- Do not place objects near the lights or the muffler.

WARNING


Overloading or improper loading can cause a crash and you can be seriously hurt or killed.

Follow all load limits and other loading guidelines in this manual.

Basic Operation Flow

Pre-ride Inspection ➡ P. 37

Carefully inspect your vehicle to make sure that it is safe to ride.



How to use basic features.

- Instruments ➡ P. 18
- Indicators ➡ P. 19
- Switches ➡ P. 20
- Steering Lock ➡ P. 21

Acceleration

Apply throttle gradually.
Obey the speed limit.

Shift Change ➡ P. 26



Starting the Engine ➡ P. 23

Start and warm the engine.
Avoid revving the engine.



Starting the Vehicle

Before pulling away, indicate your direction with the turn signal switch, and check for oncoming traffic.



Braking**STOP!**

Close the throttle and apply the front and rear brakes together.


► The brakelight will indicate that you have applied the brakes.

Stopping

If pulling off the road, signal early enough to show traffic that you are pulling over, and pull over smoothly.

**Turning Corners**

Do your braking before entering corners.



Gradually reapply throttle when exiting turn.


Parking ➡ P. 8


Park on a firm level surface. Use the stand, and lock the steering.

**Refuelling** ➡ P. 28

Parts Location


AFS110MD







Parts Location (Continued)

AFS110MCS






Instruments




Indicators

If one of these indicators does not come on when it should, have your dealer check for problems.



Switches



 **Start button**

 **Horn button**

 **Turn signal switch**

▶ Pressing the switch turns the turn signal off.

Headlight dimmer switch

-  : High beam
-  : Low beam

Ignition Switch


Switches the electrical system on/off, locks the steering.

- Key can be removed when in the ○ (Off) or  (Lock) position.

Steering Lock

Lock the steering when parking to help prevent theft.

A U-shaped wheel lock or similar device is also recommended.



I (On)


Turns electrical system on for starting/riding.

○ (Off)

Turns engine off.

 (Lock)

Locks steering.



Locking

- 1** Turn the handlebar all the way to the left or right.
- 2** Push the key down, and turn the ignition switch to the  (Lock) position.
 - Jiggle the handlebar if the lock is difficult to engage.
- 3** Remove the key.

Unlocking

Insert the key, and turn the ignition switch to the ○ (Off) position.


Fuel Valve

The two-way fuel valve is used to control the flow of fuel from the fuel tank to the carburetor.

ON



OFF






ON: normal position for riding.

OFF: for parking, storing, or transportation.

Starting the Engine

Start your engine using the following procedure.



To restart a warm engine, follow the procedure for "High Air Temperature."

Starting the Engine *(Continued)*

NOTICE

- If the engine does not start within 5 seconds, turn the ignition switch to the **O** (Off) position and wait 10 seconds before trying to start the engine again to recover battery voltage.
- Extended fast idling and revving the engine can damage the engine, and the exhaust system.
- Do not operate the kickstarter while the engine is running as engine damage could result. Do not apply excessive force on the kickstarter.
- Fold up the kickstarter after the kickstarter is returned to the pedal stop.

Normal Air Temperature 10 - 35°C (50 - 95°F):

- 1 Make sure the fuel valve is in the On position.
- 2 Turn the ignition switch to the **I** (On) position.
- 3 Shift the transmission to Neutral (**N** indicator comes on).
- 4 Pull the choke lever up all the way to fully ON.

5 Using the start button

With the throttle slightly open, press the start button.

Using the kickstarter

Lightly depress the kickstarter until resistance is felt.

Then let the kickstarter return to the top of its stroke.

With the throttle slightly open, operate the kickstarter. Kick from the top of the stroke through to the bottom with a rapid, continuous motion.

- 6 Immediately after the engine starts, push the choke lever down to the halfway position.
- 7 Warm up the engine by opening and closing the throttle slightly.
- 8 About a quarter minute after the engine starts, push the choke lever down all the way to fully OFF.
- 9 If idling is unstable, open the throttle slightly.

High Air Temperature 35°C (95°F) or above :

- ① Do not use the choke.
- ② **Using the start button**

With the throttle slightly open, press the start button.

Using the kickstarter

Lightly depress the kickstarter until resistance is felt.

Then let the kickstarter return to the top of its stroke.

With the throttle slightly open, operate the kickstarter. Kick from the top of the stroke through to the bottom with a rapid, continuous motion.

Low Air Temperature 10°C (50°F) or below :

- ① Follow steps 1- 6 under "Normal Air Temperature."
- ② Warm up the engine by opening and closing the throttle slightly.
- ③ Continue warming up the engine until it runs smoothly and responds to the throttle, when the choke lever is at fully OFF.

If the engine does not start:

- ① Turn the ignition switch to the **○** (Off) position.
- ② Push the choke lever down all the way to fully OFF.
- ③ Open the throttle fully.
- ④ Crank the engine several times with the kickstarter.
- ⑤ Follow steps 1-2 under "High Air Temperature."

If Engine Will Not Start ➡ P.77

Shifting Gears

Your vehicle transmission has four forward gears.


The gearshift operation differs when stopping and when moving.

When stopping, change can be made from 4th to neutral directly with the 4-step rotary system.

When moving, the forward 4-step return system is used.

Change cannot be made from 4th to neutral directly.

- ▶ Always return the throttle grip first before changing gear.
- ▶ Operate lightly with the tips of your toes until the shift lever is pushed down.
- ▶ Avoid changing gear needlessly and riding with your foot on the shift lever since this may damage the gear change mechanism and clutch mechanism.



Proper shifting can prevent damaging the engine and transmission.

Upshifting

The upper limit speed of each gear is shown in gear range. ➡ P.18

Upshift to a higher gear before exceeding the upper limit speed.

Upshifting at speeds higher than the upper limit speed can cause damage to the engine.

Downshifting

Downshifting at speeds higher than those in the table below may overrev the engine and can cause damage to the engine and transmission.

Follow the table below when downshifting the gears.

Downshifting Acceptable Speed	
From 4th to 3rd	75 km/h or less
From 3rd to 2nd	50 km/h or less
From 2nd to 1st	30 km/h or less

Refuelling

Fuel type: Unleaded petrol only


Fuel octane number: Your vehicle is designed to use Research Octane Number (RON) 91 or higher.

Tank capacity: 3.7 litres (0.98 US gal, 0.81 Imp gal)

Refuelling and Fuel Guidelines ➡ P. 9

Opening the Fuel Fill Cap

- 1 Open the seat. ➡ P. 30
- 2 Turn the fuel fill cap counterclockwise until it stops and remove the fuel fill cap.



Do not fill with fuel above the lower edge of the filler neck.

Closing the Fuel Fill Cap


- ① Install and tighten the fuel fill cap firmly by turning it clockwise.
 - Make sure that the arrow marks on the fuel fill cap and fuel tank is aligned.
- ② Close the seat.

WARNING

Petrol is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine, and keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

Storage Equipment



Helmet Holders

The helmet holders are located under the seat.

► Use the helmet holders only when parked.

Seat Open

Insert the ignition key into the seat lock and turn it clockwise to unlock.

Seat Close

Close and push down on the rear of the seat until it locks. Make sure that the seat is locked securely to pull it up lightly. Take care not to lock your key in the compartment under the seat.

⚠ WARNING

Riding with a helmet attached to the holder can interfere with your ability to safely operate the vehicle and could lead to a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.

Luggage Box

Never exceed the maximum weight limit.

Maximum Weight: 5 kg (11 lb)


- ▶ Do not store any items that are flammable or susceptible to heat damage.
- ▶ Do not store valuables or fragile articles.

Document Bag

The document bag is in the document compartment in the reverse side of the seat.


Document compartment

Document bag



Tool

The tools are in the luggage box.



Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

Importance of Maintenance	P. 33
Maintenance Schedule	P. 34
Maintenance Fundamentals.....	P. 37
Tool.....	P. 48
Removing & Installing Body Components...	P. 49
Battery	P. 49
Headlight Case.....	P. 51
Main Pipe Cover	P. 53
Spark Plug.....	P. 54
Engine Oil.....	P. 56
Brakes.....	P. 59
Side Stand	P. 67

Drive Chain.....	P. 68
Throttle.....	P. 73
Crankcase Breather	P. 74
Other Adjustments.....	P. 75
Adjusting the Headlight Aim	P. 75

Importance of Maintenance

Importance of Maintenance

Keeping your vehicle well-maintained is absolutely essential to your safety and to protect your investment, obtain maximum performance, avoid breakdowns, and reduce air pollution. Maintenance is the owner's responsibility. Be sure to inspect your vehicle before each ride, and perform the periodic checks specified in the Maintenance Schedule. ➡ P. 34

WARNING

Improperly maintaining your vehicle or failing to correct a problem before you ride can cause a crash in which you can be seriously hurt or killed.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

Maintenance Safety

Always read the maintenance instructions before you begin each task, and make sure that you have the tools, parts, and skills required. We cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

Follow these guidelines when performing maintenance.

- Stop the engine and remove the key.
- Place your vehicle on a firm, level surface using the side stand, centre stand or a maintenance stand to provide support.
- Allow the engine, muffler, brakes, and other high-temperature parts to cool before servicing as you can get burned.
- Run the engine only when instructed, and do so in a well-ventilated area.

Maintenance Schedule

The maintenance schedule specifies the maintenance requirements necessary to ensure safe, dependable performance, and proper emission control.

Maintenance work should be performed in accordance with Honda's standards and specifications by properly trained and equipped technicians. Your dealer meets all of these requirements. Keep an accurate record of maintenance to help ensure that your vehicle is properly maintained. Make sure that whomever performs the maintenance completes this record.

All scheduled maintenance is considered a normal owner operating cost and will be charged to you by your dealer. Retain all receipts. If you sell the vehicle, these receipts should be transferred with the vehicle to the new owner.

Honda recommends that your dealer should road test your vehicle after each periodic maintenance is carried out.

Items		Pre-ride Check P. 37	Frequency *1								Annual Check	Regular Replace	Refer to page
			× 1,000 km	1	6	12	18	24	30	36			
			× 1,000 mi	0.6	4	8	12	16	20	24			
Fuel Line					I	I	I	I	I	I	I		–
Fuel Level		I											28
Fuel Strainer Screen					C	C	C	C	C	C			–
Throttle Operation		I			I	I	I	I	I	I	I		73
Air Cleaner *2							R			R			47
Crankcase Breather *3					C	C	C	C	C	C			74
Spark Plug					I	R	I	R	I	R			54
Valve Clearance					I	I	I	I	I	I			–
Engine Oil		I		R	R	R	R	R	R	R	R		56
Engine Oil Strainer Screen						C		C		C			–
Engine Oil Centrifugal filter						C		C		C			–
Engine Idle Speed				I	I	I	I	I	I	I	I		–
Secondary Air Supply System							I			I			–

Maintenance Level

-  : Intermediate. We recommend service by your dealer, unless you have the necessary tools and are mechanically skilled. Procedures are provided in an official Honda Shop Manual.
-  : Technical. In the interest of safety, have your vehicle serviced by your dealer.

Maintenance Legend

- I** : Inspect (clean, adjust, lubricate, or replace, if necessary)
- R** : Replace
- C** : Clean
- L** : Lubricate

Maintenance Schedule

Items		Pre-ride Check P. 37	Frequency *1								Annual Check	Regular Replace	Refer to page
			× 1,000 km	1	6	12	18	24	30	36			
			× 1,000 mi	0.6	4	8	12	16	20	24			
Secondary Air Supply Pair Filter *4												3 years	–
Drive Chain			Every 500 km (300 mi)										68
Brake Fluid *4 (AFS110MCS)												2 years	59
Brake Shoes Wear (AFS110MD)													65
Brake Shoes/Pads Wear (AFS110MCS)													60, 65
Brake System													59
Brakelight Switch													66
Headlight Aim													75
Lights/Horn													–
Clutch System													–
Side Stand													67
Suspension													–
Nuts, Bolts, Fasteners													–
Wheels/Tyres													44
Steering Head Bearings													–

Notes:

*1 : At higher odometer reading, repeat at the frequency interval established here.

*2 : Service more frequently when riding in unusually wet or dusty areas.

*3 : Service more frequently when riding in rain or at full throttle.

*4 : Replacement requires mechanical skill.

Pre-ride Inspection

To ensure safety, it is your responsibility to perform a pre-ride inspection and make sure that any problem you find is corrected. A pre-ride inspection is a must, not only for safety, but because having a breakdown, or even a flat tyre, can be a major inconvenience.

Check the following items before you get on your vehicle:

- Fuel level - Fill fuel tank when necessary. ➤ P. 28
- Throttle - Check for smooth opening and full closing in all steering positions. ➤ P. 73
- Engine oil level - Add engine oil if necessary. Check for leaks. ➤ P. 56
- Drive chain - Check condition and slack, adjust and lubricate if necessary. ➤ P. 68

- Brakes - Check operation;

AFS110MD

Front and Rear: check shoes wear (➤ P. 65) and freeplay, adjust if necessary. ➤ P. 62, 64

AFS110MCS

Front: check brake fluid level and pad wear. ➤ P. 59, 60

Rear: check shoes wear and freeplay, adjust if necessary. ➤ P. 65

- Lights and horn - Check that lights, indicators and horn function properly.
- Wheels and tyres - Check condition, air pressure and adjust if necessary. ➤ P. 44

Replacing Parts

Always use Honda Genuine Parts or their equivalents to ensure reliability and safety.

WARNING

Installing non-Honda parts may make your vehicle unsafe and cause a crash in which you can be seriously hurt or killed.

Always use Honda Genuine Parts or equivalents that have been designed and approved for your vehicle.

Battery

Your vehicle has a maintenance-free type battery. You do not have to check the battery electrolyte level or add distilled water. Clean the battery terminals if they become dirty or corroded.

Do not remove the battery cap seals. There is no need to remove the cap when charging.

NOTICE

Your battery is a maintenance-free type and can be permanently damaged if the cap strip is removed.

NOTICE

An improperly disposed of battery can be harmful to the environment and human health. Always confirm local regulations for proper battery disposal instruction.

What to do in an emergency

If any of the following occur, immediately see your doctor.

- Electrolyte splashes into your eyes:
 - ▶ Wash your eyes repeatedly with cool water for at least 15 minutes. Using water under pressure can damage your eyes.
- Electrolyte splashes onto your skin:
 - ▶ Remove affected clothing and wash your skin thoroughly using water.
- Electrolyte splashes into your mouth:
 - ▶ Rinse mouth thoroughly with water, and do not swallow.

WARNING

The battery gives off explosive hydrogen gas during normal operation.

A spark or flame can cause the battery to explode with enough force to kill or seriously hurt you.


Wear protective clothing and a face shield, or have a skilled mechanic do the battery servicing.

Cleaning the Battery Terminals

1. Remove the battery.  P. 49
2. If the terminals are starting to corrode and are coated with a white substance, wash with warm water and wipe clean.

Maintenance Fundamentals

3. If the terminals are heavily corroded, clean and polish the terminals with a wire brush or sandpaper. Wear safety glasses.



4. After cleaning, reinstall the battery.

The battery has a limited life span. Consult your dealer about when you should replace the battery. Always replace the battery with another maintenance-free battery of the same type.

NOTICE

Installing non-Honda electrical accessories can overload the electrical system, discharging the battery and possibly damaging the system.


Fuses

Fuses protect the electrical circuits on your vehicle. If something electrical on your vehicle stops working, check for and replace any blown fuses. ➡ P. 93

Inspecting and Replacing Fuses

Turn the ignition switch to the **O** (Off) position to remove and inspect fuses. If a fuse is blown, replace with a fuse of the same rating. For fuse ratings, see "Specifications." ➡ P. 107

Blown fuse



NOTICE

Replacing a fuse with one that has a higher rating greatly increases the chance of damage to the electrical system.

If a fuse fails repeatedly, you likely have an electrical fault. Have your vehicle inspected by your dealer.

Engine Oil

Engine oil consumption varies and oil quality deteriorates according to riding conditions and time elapsed.

Check the engine oil level regularly, and add the recommended engine oil if necessary. Dirty oil or old oil should be changed as soon as possible.


Selecting the Engine Oil

For recommended engine oil, see "Specifications." ▣ P. 106


If you use non-Honda engine oil, check the label to make sure that the oil satisfies all of the following standards:

- JASO T 903 standard*¹: MA
- SAE standard*²: 10W-30
- API classification*³: SG or higher

- *1. The JASO T 903 standard is an index for engine oils for 4-stroke motorcycle engines. There are two classes: MA and MB. For example, the following label shows the MA classification.



- *2. The SAE standard grades oils by their viscosity.
- *3. The API classification specifies the quality and performance rating of engine oils. Use SG or higher oils, excluding oils marked as "Energy Conserving" or "Resource Conserving" on the circular API service symbol.



Maintenance Fundamentals

Brake Fluid

AFS110MCS

Do not add or replace brake fluid, except in an emergency. Use only fresh brake fluid from a sealed container. If you do add fluid, have the brake system serviced by your dealer as soon as possible.

NOTICE

Brake fluid can damage plastic and painted surfaces. Wipe up spills immediately and wash thoroughly.

Recommended brake fluid:


Honda DOT3 or DOT4 Brake Fluid or equivalent

Drive Chain

The drive chain must be inspected and lubricated regularly. Inspect the chain more frequently if you often ride on bad roads, ride at high speed, or ride with repeated fast acceleration. ➡ P. 68

If the chain does not move smoothly, makes strange noises, has damaged rollers, has loose pins, or kinks, have the chain inspected by your dealer.

Also inspect the drive sprocket and driven sprocket. If either has worn or damaged teeth, have the sprocket replaced by your dealer.



NOTICE

Use of a new chain with worn sprockets will cause rapid chain wear.

Cleaning and Lubricating

After inspecting the slack, clean the chain and sprockets while rotating the rear wheel.

Use a dry cloth with high flash-point solvent.


Use a soft brush if the chain is dirty.

After cleaning, wipe dry and lubricate with the recommended lubricant.

Recommended lubricant:

Drive chain lubricant

If not available, use SAE 80 or 90 gear oil.



Never use petrol or low flash point solvents for cleaning the drive chain.

A fire or explosion could result.

Avoid getting lubricant on the brakes or tyres.

Avoid applying excess chain lubricant to prevent spray onto your clothes and the vehicle.

Maintenance Fundamentals

Crankcase Breather

Service more frequently when riding in rain, at full throttle, or after the vehicle is washed or overturned. Service if the deposit level can be seen in the transparent section of the drain tube.

If the drain tube overflows, the air filter may become contaminated with engine oil causing poor engine performance. ➤ P. 74


Tyres (Inspecting/Replacing)

Checking the Air Pressure

Visually inspect your tyres and use an air pressure gauge to measure the air pressure at least once a month or any time you think the tyres look low. Always check air pressure when your tyres are cold.


Inspecting for Damage

Inspect the tyres for cuts, slits, or cracks that exposes fabric or cords, or nails or other foreign objects embedded in the side of the tyre or the tread. Also inspect for any unusual bumps or bulges in the side walls of the tyres.




Inspecting for Abnormal Wear

Inspect the tyres for signs of abnormal wear on the contact surface.



Inspecting Tread Depth

Inspect the tread wear indicators. If they become visible, replace the tyres immediately.



⚠ WARNING

Riding on tyres that are excessively worn or improperly inflated can cause a crash in which you can be seriously hurt or killed.

Follow all instructions in this owner's manual regarding tyre inflation and maintenance.

Maintenance Fundamentals

Have your tyres replaced by your dealer.
For recommended tyres and air pressure, see
"Specifications." ➔ P. 106

Follow these guidelines whenever you replace
tyres.

- Use the recommended tyres or equivalents of
the same size, construction, speed rating, and
load range.

AFS110MD

- Remember to replace the inner tube
whenever you replace a tyre. The old tube will
probably be stretched, and it could fail if
installed in a new tyre.

AFS110MCS

- Do not install a tube inside a tubeless tyre on
this vehicle. Excessive heat build-up can cause
the tube to burst.
- Use only tubeless tyres on this vehicle. The
rims are designed for tubeless tyres, and
during hard acceleration or braking, a tube-
type tyre could slip on the rim and cause the
tyre to rapidly deflate.

WARNING

Installing improper tyres on your vehicle
can adversely affect handling and
stability, and can cause a crash in which
you can be seriously hurt or killed.

Always use the size and type of tyres
recommended in this owner's manual.


Air Cleaner

This vehicle is equipped with a viscous type air cleaner element.

Air blow cleaning or any other cleaning can degrade the viscous element performance and cause the intake of dust.

Do not perform the maintenance.

Should be serviced by your dealer.



The tools are stored in the luggage box.

➡ P. 31

You can perform some roadside repairs, minor adjustments and parts replacement with the tools contained in the kit.

- Spark plug wrench
- Standard/Phillips screwdriver
- Screwdriver handle


Removing & Installing Body Components

Battery


Removal

Make sure the ignition switch is in the **O** (Off) position.

1. Open the seat. **P. 30**
2. Remove the battery cover by removing the screws.



3. Disconnect the negative $\ominus$ terminal from the battery.
4. Disconnect the positive $\oplus$ terminal from the battery.
5. Remove the battery taking care not to drop the terminal nuts.




■ Installation

Install the parts in the reverse order of removal. Always connect the positive ⊕ terminal first. Make sure that bolts and nuts are tight.


For proper handling of the battery, see
"Maintenance Fundamentals." ➤ P. 38
"Battery Goes Dead." ➤ P. 86

Headlight Case



Removal

1. Pull up the rubber dust covers.
2. Loosen the lock nuts by turning clockwise.
3. Loosen the rearview mirrors and remove them by turning them clockwise.
4. Loosen the mirror adapters by turning counterclockwise and remove them.



5. Remove the screws A and screw B.
6. Release the bosses by pressing the rear handle cover.
7. Remove the headlight case and disconnect the socket.


Installation

Install the parts in the reverse order of removal.

► To install the rearview mirrors.

1. Install the mirror adapters.
2. Install the rearview mirrors by turning counterclockwise until they will no longer turn.
3. Loosen the rearview mirrors approximately 2 turns.
4. Adjust the rearview mirrors.
5. Tighten the lock nuts and install the rubber dust covers.

Main Pipe Cover



Removal

1. Remove the screws A, screws B and screw C.
2. Slightly release the tabs from the slots.
3. Remove the main pipe cover.

Installation

Install the parts in the reverse order of removal.

Checking Spark Plug


For the recommended spark plug, see "Specifications." ➤ P. 106

Use only the recommended type of spark plug in the recommended heat range.

NOTICE

Using a spark plug with an improper heat range can cause engine damage.

1. Disconnect the spark plug cap from the spark plug.
2. Clean any dirt from around the spark plug base.
3. Remove the spark plug using provided spark plug wrench. ➤ P. 48




4. Inspect the electrodes and centre porcelain for deposits, erosion or carbon fouling.
 - ▶ If the erosion or deposit is heavy, replace the plug.
 - ▶ Clean a carbon or wet-fouled plug with a plug cleaner, otherwise use a wire brush.

5. Check the spark plug gap using a wire-type feeler gauge.
- If adjustment is necessary, bend the side electrode carefully.

The gap should be:

0.8 to 0.9 mm (0.03 to 0.04 in)



6. Make sure the plug washer is in good condition.
7. Install the spark plug. With the plug washer attached, thread the spark plug in by hand to prevent cross-threading.

8. Tighten the spark plug:
- If the old plug is good:
 - NGK: 1/6 turn after it seats.
 - DENSO: 1/8 turn after it seats.
 - If installing a new plug, tighten it twice to prevent loosening:
 - a) First, tighten the plug:
 - NGK: 1/4 turn after it seats.
 - DENSO: 3/4 turn after it seats.
 - b) Then loosen the plug.
 - c) Next, tighten the plug again:
 - NGK: 1/6 turn after it seats.
 - DENSO: 1/8 turn after it seats.


NOTICE

An improperly tightened spark plug can damage the engine. If a plug is too loose, a piston may be damaged. If a plug is too tight, the threads may be damaged.

9. Install the parts in the reverse order of removal.
- When reinstalling the spark plug cap, take care to avoid pinching any cable or wires.

Checking the Engine Oil

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch to the **O** (Off) position and wait for 2 to 3 minutes.
3. Place your vehicle on its centre stand on a firm, level surface.
4. Remove the oil fill cap/dipstick and wipe it clean.
5. Insert the oil fill cap/dipstick until it seats, but don't screw it in.
6. Check that the oil level is between the upper level and lower level marks in the oil fill cap/dipstick.
7. Securely install the oil fill cap/dipstick.



Adding Engine Oil

If the engine oil is below or near the lower level mark, add the recommended engine oil.

► P. 41, 106

1. Remove the oil fill cap/dipstick. Add the recommended oil until it reaches the upper level mark.
 - Place your vehicle on its centre stand on a firm, level surface when checking the oil level.
 - Do not overfill above the upper level mark.
 - Make sure no foreign objects enter the oil filler opening.
 - Wipe up any spills immediately.
2. Securely reinstall the oil fill cap/dipstick.

NOTICE

Overfilling with oil or operating with insufficient oil can cause damage to your engine. Do not mix different brands and grades of oil. They may affect lubrication and clutch operation.

For the recommended oil and oil selection guidelines, see "Maintenance Fundamentals."

► P. 41


Changing Engine Oil

Changing the oil requires special tools. We recommend that you have your vehicle serviced by your dealer.

1. If the engine is cold, idle the engine for 3 to 5 minutes.
2. Turn the ignition switch to the **O** (Off) position and wait for 2 to 3 minutes.

Engine Oil ► Changing Engine Oil

3. Place your vehicle on its centre stand on a firm, level surface.
4. Place a drain pan under the drain bolt.
5. Remove the oil fill cap/dipstick, drain bolt and sealing washer to drain the oil.
► Discard the oil at an approved recycling centre.



6. Install a new sealing washer onto the drain bolt. Tighten the drain bolt.

Torque: 24 N·m (2.4 kgf·m, 18 lbf·ft)

7. Fill the crankcase with the recommended oil (► P. 41, 106) and install the oil fill cap/dipstick.

Required oil

When changing oil:

0.8 litres (0.8 US qt, 0.7 Imp qt)


8. Check the oil level. ► P. 56
9. Check that there are no oil leaks.

Checking the Front Brake Fluid

AFS110MCS

1. Place your vehicle in an upright position on a firm, level surface.
2. Check that the brake fluid reservoir is horizontal and that the fluid level is above the L (lower) level mark.

If the brake fluid level in the reservoir is below the L (lower) level mark or the brake lever freeplay becomes excessive, inspect the brake pads for wear. If the brake pads are not worn, you most likely have a leak. Have your vehicle inspected by your dealer.



Inspecting the Front Brake Pads

AFS110MCS


Check the condition of the brake pad wear indicators.

The pads need to be replaced if a brake pad is worn to the indicator.

Inspect the brake pads from below the brake caliper.

If necessary have the pads replaced by your dealer.

Always replace both left and right brake pads at the same time.




Inspecting the Front Brake Lever Freeplay

AFS110MD

1. Place your vehicle on its centre stand on a firm, level surface.
2. Measure the distance of the front brake lever before the starts to take hold.

Freeplay at the tip of the brake lever:

10 to 20 mm (0.4 to 0.8 in)



Check the brake cable for kinks or signs of wear. If necessary have it replaced by your dealer.


Lubricate the brake cable with a commercially available cable lubricant to prevent premature wear and corrosion.

Make sure the brake arm, spring and fastener are in good condition.


Adjusting the Front Brake Lever Freeplay

AFS110MD


Adjust the freeplay of the brake lever with the front wheel pointed straight ahead. Make sure the cut-out on the adjusting nut is seated on the brake arm pin when adjusting the freeplay.



If proper adjustment cannot be obtained by this method, see your dealer.



1. Adjust by turning the front brake adjusting nut a half-turn at a time.
2. Apply the brake several times and check for free wheel rotation after the brake lever is released.
3. Push the brake arm to confirm that there is a gap between the front brake adjusting nut and brake arm pin.



After adjustment, confirm the freeplay of the brake lever.

Make sure the brake arm, spring and fastener are in good condition.


NOTICE

Do not turn the adjuster beyond its natural limits.

Inspecting the Rear Brake Pedal Freeplay

1. Place your vehicle on its centre stand on a firm, level surface.
2. Measure the distance of the rear brake pedal before the starts to take hold.


Freeplay at the tip of the rear brake pedal: 20 to 30 mm (0.8 to 1.2 in)



Make sure the brake rod, brake arm, spring and fastener are in good condition.


Adjusting the Rear Brake Pedal Freeplay

Make sure the cut-out on the adjusting nut is seated on the brake arm pin when adjusting the freeplay.




If proper adjustment cannot be obtained by this method, see your dealer.

1. Adjust by turning the rear brake adjusting nut a half-turn at a time.



2. Apply the brake several times and check for free wheel rotation after the brake pedal is released.

- Push the brake arm to confirm that there is a gap between the rear brake adjusting nut and brake arm pin.



After adjustment, confirm the freeplay of the rear brake pedal.

Make sure the brake rod, brake arm, spring and fastener are in good condition.

NOTICE

Do not turn the adjuster beyond its natural limits.


Inspecting the Brake Shoe Wear


AFS110MCS

The rear brake is equipped with a brake wear indicator.

AFS110MD

The front and rear brake are equipped with a brake wear indicator.




Brakes ► Adjusting the Brakelight Switch

When the brake is applied, an arrow attached to the brake arm moves toward a reference mark on the brake panel. If the arrow aligns with the reference mark on full application of the brake, the brake shoes must be replaced. See your dealer for this service.


When the brake service is necessary, see your dealer. Use only Honda Genuine Parts or its equivalent.

Adjusting the Brakelight Switch

Check the operation of the brakelight switch. Hold the brakelight switch and turn the adjusting nut in the direction A if the switch operates too late, or turn the nut in the direction B if the switch operates too soon.



Checking the Side Stand



1. Check that the side stand operates smoothly. If the side stand is stiff or squeaky, clean the pivot area and lubricate the pivot bolt with clean grease.
2. Check the spring for damage or loss of tension.

Inspecting the Drive Chain Slack

Check the drive chain slack at several points along the chain. If the slack is not constant at all points, some links may be kinked and binding.

Have the chain inspected by your dealer.


1. Shift the transmission to Neutral. Stop the engine.
2. Place your vehicle on its centre stand on a firm, level surface.

3. Check the slack in the lower half of the drive chain midway between the sprockets.

Drive chain slack:

20 to 30 mm (0.8 to 1.2 in)

- Do not ride your vehicle if the slack exceeds 50 mm (2.0 in).





4. Rotate the rear wheel and check that the chain moves smoothly.
5. Inspect the sprockets. ➡ P. 42
6. Clean and lubricate the drive chain. ➡ P. 43

Drive Chain ► Adjusting the Drive Chain Slack

Adjusting the Drive Chain Slack

Adjusting the chain requires special tools. Have the drive chain slack adjusted by your dealer.

1. Shift the transmission to Neutral. Stop the engine.
2. Place your vehicle on its centre stand on a firm, level surface.
3. Loosen the rear axle nut.
4. Loosen the lock nuts on both sides of the drive chain adjusters.



5. Turn both adjusting nuts an equal number of turns until the correct drive chain slack is obtained. Turn the adjusting nuts clockwise to tighten the chain. Turn the adjusting nuts counterclockwise and push the rear wheel toward the front to provide more slack.

Drive Chain ► Adjusting the Drive Chain Slack

Adjust the slack at a point midway between the drive sprocket and the driven sprocket.

Check the drive chain slack. ➡ P. 68

6. Check rear axle alignment by making sure the end of the drive chain adjuster aligns with the scale graduations on both sides of the swingarm.

Both marks should correspond. If the axle is misaligned, turn the right or left adjusting nut until the marks are aligned and recheck chain slack.

7. Tighten the rear axle nut.

Torque: 59 N·m (6.0 kgf·m, 44 lbf·ft)
--

8. Hold the adjusting nuts and tighten the lock nuts.

9. Recheck drive chain slack.

10. Rear brake pedal freeplay is affected when repositioning the rear wheel to adjust drive chain slack. Check rear brake pedal freeplay and adjust as necessary.

➡ P. 63

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Checking the Drive Chain Wear

If the drive chain slack is excessive when the rear axle is moved to the furthest limit of adjustment, the drive chain is worn and must be replaced.

Chain:

DID420AD2

RK420EL

KMC420JB


If necessary have the drive chain replaced by your dealer.

Checking the Throttle

With the engine off, check that the throttle rotates smoothly from fully closed to fully open in all steering positions and throttle freeplay is correct. If the throttle does not move smoothly, close automatically, or if the cable is damaged, have the vehicle inspected by your dealer.


Freeplay at the throttle grip flange:

2 to 6 mm (0.1 to 0.2 in).



Cleaning the Crankcase Breather


1. Place a suitable container to receive deposits.
2. Remove the crankcase breather tube and drain deposits.
3. Reinstall the crankcase breather tube.



Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. To move the headlight, loosen the adjusting bolt.

Tighten the adjusting bolt after adjustment.
Obey local laws and regulations.



Troubleshooting

Engine Will Not Start.....	P. 77
Tyre Puncture	P. 78
Electrical Trouble	P. 86
Battery Goes Dead.....	P. 86
Burned-out Light Bulb	P. 86
Blown Fuse	P. 93

Starter Motor Operates But Engine Does Not Start

Check the following items:

- Check the correct engine starting sequence
➡ P. 23
- Check that there is petrol in the fuel tank

Starter Motor Does Not Operate

Check the following items:

- Check the correct engine starting sequence.
➡ P. 23
 - Check for a blown fuse ➡ P. 93
 - Check for a loose battery connection or battery terminal corrosion ➡ P. 39, 49
 - Check the condition of the battery ➡ P. 86
- If the problem continues, have your vehicle inspected by your dealer.

Tyre Puncture

Repairing a puncture or removing a wheel requires special tools and technical expertise. We recommend you have this type of service performed by your dealer.

After an emergency repair, always have the tyre inspected/replaced by your dealer.

Tube Repair and Replacement

AFS110MD

If a tube is punctured or damaged, you should replace it as soon as possible. A tube that is repaired may not have the same reliability as a new one, and it may fail while you are riding. If you need to make a temporary repair by patching a tube or using an aerosol sealant, ride cautiously at reduced speed and have the tube replaced before you ride again.

Anytime a tube is replaced, the tyre should be carefully inspected as described.

WARNING

Riding your vehicle with a temporary tyre or tube repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tyre or tube repair, ride slowly and carefully and do not exceed 50 km/h (30 mph) until the tyre or tube is replaced.

Emergency Repair Using a Tyre Repair Kit

AFS110MCS

If your tyre has a minor puncture, you can make an emergency repair using a tubeless tyre repair kit.

Follow the instructions provided with the emergency tyre repair kit.

Riding your vehicle with a temporary tyre repair is very risky. Do not exceed 50 km/h (30 km/h). Have the tyre replaced by your dealer as soon as possible.

WARNING

Riding your vehicle with a temporary tyre repair can be risky. If the temporary repair fails, you can crash and be seriously injured or killed.

If you must ride with a temporary tyre or tube repair, ride slowly and carefully and do not exceed 50 km/h (30 mph) until the tyre is replaced.

Removing Wheels



Follow these procedures if you need to remove a wheel in order to repair a puncture.

Front Wheel

AFS110MD

Removal

1. Place your vehicle on its centre stand on a firm, level surface.
2. Support your vehicle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
3. Remove the speedometer cable by pushing the tab.
4. Remove the front brake adjusting nut and disconnect the front brake cable from the brake arm.
5. Remove the front axle nut.
6. Remove the front axle shaft, front wheel, and side collar.




Installation

1. Install the side collar into the right side wheel hub.
2. Position the wheel between the fork legs and insert the front axle shaft from the right side, through the right fork leg and wheel hub.
3. Make sure that the lug on the left fork leg is located in the slot of the brake panel.
4. Tighten the front axle nut.

Torque: 59 N·m (6.0 kgf·m, 44 lbf·ft)

5. Install the speedometer cable securely.
6. Install the front brake cable and front brake adjusting nut.
7. Adjust the front brake lever freeplay. ► P. 62
8. After installing the wheel, apply the brake lever several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.





If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Front Wheel

AFS110MCS

Removal

1. Place your vehicle on its centre stand on a firm, level surface.
2. Support your vehicle securely and raise the front wheel off the ground using a maintenance stand or a hoist.
3. Remove the speedometer cable by pushing the tab.
4. Remove the front axle nut.
5. Remove the front axle shaft, front wheel, speedometer gearbox and side collar.
 - Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - Do not pull the brake lever while the front wheel is removed.



Installation

1. Attach the side collar and speedometer gearbox to the wheel.
2. Position the wheel between the fork legs and insert the front axle shaft from the right side, through the right fork leg and wheel hub.

NOTICE

When installing a wheel or caliper into original position, carefully fit the brake disc between the pads to avoid scratching them.


3. Make sure that the lug on the left fork leg is located in the slot of the speedometer gearbox.
4. Tighten the front axle nut.

Torque: 59 N·m (6.0 kgf·m, 44 lbf·ft)

5. After installing the wheel, apply the brake lever several times and then check if the wheel rotates freely. Recheck the wheel if

the brake drags or if the wheel does not rotate freely.

6. Install the speedometer cable securely.




If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

Rear Wheel


Removal

1. Support your vehicle securely and raise the rear wheel off the ground using the centre stand or a hoist.
2. Remove the rear brake adjusting nut.
3. Disconnect the brake rod from the brake arm.
4. Disconnect the brake stopper arm from the brake panel by removing the cotter pin, brake stopper arm nut, washer and rubber grommet.
5. Loosen the drive chain lock nuts and drive chain adjusting nuts on both sides of the drive chain adjusters.



6. Remove the rear axle nut while holding the rear axle shaft at the other end with a wrench.
7. Remove the drive chain from the driven sprocket by pushing the rear wheel forward.

- Remove the rear axle shaft, drive chain adjusters, side collars and rear wheel from the swingarm.



Installation

- To install the rear wheel, reverse the removal procedure.
- Tighten the rear axle nut.

Torque: 59 N·m (6.0 kgf·m, 44 lbf·ft)

- Tighten the brake stopper arm nut.

Torque: 22 N·m (2.2 kgf·m, 16 lbf·ft)

- Adjust the rear brake pedal freeplay. ► P. 64
- Adjust the drive chain slack. ► P. 70
- After installing the wheel, apply the brake pedal several times and then check if the wheel rotates freely. Recheck the wheel if the brake drags or if the wheel does not rotate freely.

If a torque wrench was not used for installation, see your dealer as soon as possible to verify proper assembly. Improper assembly may lead to loss of braking capacity.

A used cotter pin may not effectively secure a fastener. Always replace a used cotter pin with a new one.

Battery Goes Dead

Charge the battery using a motorcycle battery charger.

Remove the battery from the vehicle before charging.

Do not use an automobile-type battery charger, as these can overheat a motorcycle battery and cause permanent damage.

If the battery does not recover after recharging, contact your dealer.

NOTICE

Jump starting using an automobile battery is not recommended, as this can damage your vehicle's electrical system.

Burned-out Light Bulb

Follow the procedure below to replace a burned-out light bulb.

Turn the ignition switch to the  (Off) or  (Lock) position.


Allow the bulb to cool before replacing it.

Do not use bulbs other than those specified.

Check the replacement bulb for correct operation before riding.

For the light bulb wattage, see "Specifications." ➞ P. 107


Headlight Bulb



1. Remove the headlight case. ► P. 51
2. Remove the rubber cover.
3. Slightly press down on the pin and turn it clockwise until it releases from the headlight bulb housing.
4. Remove the bulb.
5. Install a new bulb and parts in the reverse order of removal.
 - Install the rubber cover with its "▲" mark facing up.


Do not touch the glass surface with your fingers. If you touch the bulb with your bare hands, clean it with a cloth moistened with alcohol.

Position Light Bulb




1. Remove the main pipe cover. ► P. 53
2. Pull the socket without turning it.
3. Pull out the bulb without turning it.
4. Install a new bulb and parts in the reverse order of removal.

Brakelight/Taillight Bulb




1. Remove the brakelight/taillight lens by removing the screws and washers.
2. Slightly press the bulb and turn it counterclockwise.
3. Install a new bulb and parts in the reverse order of removal.

Front Turn Signal Bulb



1. Remove the main pipe cover. ► P. 53
2. Turn the socket counterclockwise, then pull it out.
3. Slightly press the bulb in and turn it counterclockwise.
4. Install a new bulb and parts in the reverse order of removal.
► Use only the amber bulb.


Rear Turn Signal Bulb



1. Remove the turn signal lens by removing the screw.
2. Turn the socket counterclockwise and pull it out.
3. Pull out the bulb without turning it.
4. Install a new bulb and parts in the reverse order of removal.

- Install the socket by turning it clockwise. Make sure that the "△" marks on the socket and turn signal housing are aligned.
- Use only the amber bulb.

License Plate Light Bulb




1. Remove the license light cover and cover packing by removing the screws.
2. Pull the bulb out of the socket without turning it.
3. Install a new bulb and parts in the reverse order of removal.

Blown Fuse

Before handling fuses, see "Inspecting and Replacing Fuses." ► P. 40

Fuse Box Fuses

1. Open the seat. ► P. 30
2. Remove the battery cover. ► P. 49
3. Open the fuse box covers.
4. Pull out the fuses one by one to check for a blown fuse. Always replace a blown fuse with a spare fuse of the same rating.
► The spare fuses are located on reverse side of the battery cover.
5. Close the fuse box covers.
6. Install the battery cover.
7. Close the seat.



NOTICE

If a fuse fails repeatedly, you likely have an electrical problem. Have your vehicle inspected by your dealer.

Information

Keys	P. 95
Instruments, Controls, & Other Features...	P. 96
Caring for Your Vehicle	P. 97
Storing Your Vehicle	P. 99
Transporting Your Vehicle	P. 100
You & the Environment.....	P. 101
Serial Numbers.....	P. 102
Fuels Containing Alcohol	P. 103
Catalytic Converter	P. 104

Keys

Ignition Key

Be sure to record the key number provided with the key number plate and record it in this manual.

Store the spare key in a safe location.

To make a duplicate, take the spare key or the key number to your dealer.

If you lose all keys and the key number, the ignition switch assembly will probably have to be removed by your dealer to determine the key number.

A metal key holder may cause damage to the area surrounding the ignition switch.

Instruments, Controls, & Other Features

Ignition Switch

Leaving the ignition switch in the **I** (On) position with the engine stopped will drain the battery.

Do not turn the key while riding.

Odometer

The odometer returns to 0 when the read-out exceeds 99,999.9.

Document Bag

The owner's manual, registration, and insurance information can be stored in the plastic document bag located on reverse side of the seat.

Caring for Your Vehicle

Frequent cleaning and polishing is important to ensure the life of your Honda. A clean vehicle makes it easier to spot potential problems. In particular, seawater and salts used to prevent ice on roads promote the formation of corrosion. Always wash your vehicle thoroughly after riding on coastal or treated roads.

Washing

Allow the engine, muffler, brakes, and other high-temperature parts to cool before washing.

1. Rinse your vehicle thoroughly using a low pressure garden hose to remove loose dirt.
2. If necessary, use a sponge or a soft towel with mild cleaner to remove road grime.
 - Clean the headlight lens, panels, and other plastic components with extra care to avoid scratching them. Avoid directing water into the air cleaner, muffler, and electrical parts.

3. Thoroughly rinse your vehicle with plenty of clean water and dry with a soft, clean cloth.
4. After the vehicle dries, lubricate any moving parts.
 - Make sure that no lubricant spills onto the brakes or tyres. Brake discs, pads, drum or shoes contaminated with oil suffer greatly reduced braking effectiveness and can lead to a crash.
5. Lubricate the drive chain immediately after washing and drying the vehicle.
6. Apply a coat of wax to prevent corrosion.
 - Avoid products that contain harsh detergents or chemical solvents. These can damage the metal, paint, and plastic on your vehicle.
 - Keep the wax clear of the tyres and brakes.
 - If your vehicle has any mat painted parts, do not apply a coat of wax to the mat painted surface.

■ Washing Precautions

Follow these guidelines when washing:

- Do not use high-pressure washers:
 - ▶ High-pressure water cleaners can damage moving parts and electrical parts, rendering them inoperable.
 - ▶ Water in the air intake can be drawn into the carburetor and/or enter the air cleaner.
 - Do not direct water at the muffler:
 - ▶ Water in the muffler can prevent starting and causes rust in the muffler.
 - Dry the brakes:
 - ▶ Water adversely affects braking effectiveness. After washing, apply the brakes intermittently at low speed to help dry them.
 - Do not direct water under the seat:
 - ▶ Water in the under seat compartment can damage your documents and other belongings.
-
- Do not direct water at the air cleaner:
 - ▶ Water in the air cleaner can prevent the engine from starting.
 - Do not direct water near the headlight:
 - ▶ The headlight's inside lens may fog temporarily after washing or while riding in the rain. This does not impact the headlight function.
 - ▶ Any condensation inside the headlight should dissipate after a few minutes of running the engine with the headlight(s) on. However, if you see a large amount of water or ice accumulated inside the lens(es), have your vehicle inspected by your dealer.
 - Do not use wax or polishing compounds on mat painted surface:
 - ▶ Use a soft cloth or sponge, plenty of water, and a mild detergent to clean mat painted surfaces. Dry with a soft clean cloth.

Aluminium Components

Aluminium will corrode from contact with dirt, mud, or road salt. Clean aluminium parts regularly and follow these guidelines to avoid scratches:

- Do not use stiff brushes, steel wool, or cleaners containing abrasives.
- Avoid riding over or scraping against curbs.

Panels

Follow these guidelines to prevent scratches and blemishes:

- Wash gently using a soft sponge and plenty of water.
- To remove stubborn stains, use diluted detergent and rinse thoroughly with plenty of water.
- Avoid getting petrol, brake fluid or detergents on the instruments, panels, or headlight.

Exhaust Pipe and Muffler

When the exhaust pipe and muffler are painted, do not use a commercially available abrasive kitchen cleaning compound. Use a neutral detergent to clean the painted surface on the exhaust pipe and muffler. If you are not sure if your exhaust pipe and muffler are painted, contact your dealer.

Storing Your Vehicle

If you store your vehicle outdoors, you should consider using a full-body vehicle cover.

If you won't be riding for an extended period, follow these guidelines:

- Wash your vehicle and wax all painted surfaces (except mat painted surfaces). Coat chrome pieces with rust-inhibiting oil.
- Lubricate the drive chain. ➤ P. 43
- Place your vehicle on its centre stand and position a block so that both tyres are off the ground.

Transporting Your Vehicle

- After rain, remove the body cover and allow the vehicle to dry.
- Remove the battery (➡ P. 49) to prevent discharge.
Charge the battery in a shaded, well-ventilated area.
 - ▶ If you leave the battery in place, disconnect the negative $\ominus$ terminal to prevent discharge.

After removing your vehicle from storage, inspect all maintenance items required by the Maintenance Schedule.

Transporting Your Vehicle

If your vehicle needs to be transported, it should be carried on a vehicle trailer or a flatbed truck or trailer that has a loading ramp or lifting platform, and motorcycle tie-down straps. Never try to tow your vehicle with a wheel or wheels on the ground.

NOTICE

Towing your vehicle can cause serious damage to the transmission.

You & the Environment

Owning and riding a vehicle can be enjoyable, but you must do your part to protect the environment.

Choose Sensible Cleaners

Use a biodegradable detergent when you wash your vehicle. Avoid aerosol spray cleaners that contain chlorofluorocarbons (CFCs) which damage the atmosphere's protective ozone layer.

Recycle Wastes

Put oil and other toxic wastes in approved containers and take them to a recycling centre. Call your local or state office of public works or environmental services to find a recycling centre in your area, and to get instructions on how to dispose of non-recyclable wastes. Do not place used engine oil in the trash, or pour it down a drain or on the ground. Used oil, petrol, and

cleaning solvents contain poisons that can hurt refuse workers and contaminate drinking water, lakes, rivers, and oceans.



Serial Numbers

The frame and engine serial numbers uniquely identify your vehicle and are required in order to register your vehicle. They may also be required when ordering replacement parts.

To check the frame number, open the seat.

➤ P. 30

You should record these numbers and keep them in a safe place.



Fuels Containing Alcohol

Some conventional fuels blended with alcohol are available in some locales to help reduce emissions to meet clean air standards. If you plan to use blended fuel, check that it is unleaded and meets the minimum octane rating requirement.

The following fuel blends can be used in your vehicle:

- Ethanol (ethyl alcohol) up to 10% by volume.
 - ▶ Petrol containing ethanol may be marketed under the name Gasohol.

The use of petrol containing more than 10% ethanol may:

- Damage the painting of the fuel tank.
- Damage the rubber tubes of the fuel line.
- Cause corrosion of the fuel tank.
- Cause poor drivability.

NOTICE

Use of blended fuels containing higher than approved percentages can damage metal, rubber, plastic parts of your fuel system.

If you notice any undesirable operating symptoms or performance problems, try a different brand of petrol.

Catalytic Converter

This vehicle is equipped with a three-way catalytic converter. The catalytic converter contains precious metals that serve as catalysts in high temperature chemical reactions that convert hydrocarbons (HC), carbon monoxide (CO), and oxides of nitrogen (NOx) in the exhaust gasses into safe compounds.

A defective catalytic converter contributes to air pollution and can impair your engine's performance. A replacement unit must be an original Honda part or equivalent.

Follow these guidelines to protect your vehicle's catalytic converter.

- Always use unleaded petrol. Leaded petrol will damage the catalytic converter.
- Keep the engine in good running condition.
- Have your vehicle serviced if your engine is misfiring, backfiring, stalling, or otherwise not running properly, stop riding and turn off the engine.

Specifications

■ Main Components

Overall length	1,937 mm (76.3 in)	
Overall width	703 mm (27.7 in)	
Overall height	1,089 mm (42.9 in)	
Wheelbase	1,227 mm (48.3 in)	
Minimum ground clearance	132 mm (5.2 in)	
Caster angle	26° 30'	
Trail	68 mm (2.7 in)	
Curb weight	AFS110MD	97 kg (214 lb)
	AFS110MCS	99 kg (218 lb)
Maximum weight capacity*1	155 kg (342 lb)	
Maximum luggage weight*2	Luggage box	5 kg (11 lb)
Passenger capacity	Rider and 1 passenger	
Minimum turning radius	1.90 m (6.23 ft)	

*1 Including rider, passenger, all luggage, and accessories.

*2 Includes the weight of the luggage and added accessories.

Displacement	109.17 cm ³ (6.659 cu-in)
Bore × stroke	50.000 × 55.597 mm (1.9685 × 2.1889 in)
Compression ratio	9.0:1
Fuel	Unleaded petrol Recommended: 91 RON or higher
Fuel containing alcohol	ETHANOL up to 10 % by volume
Tank capacity	3.7 litres (0.98 US gal, 0.81 Imp gal)
Battery	FTZ4V or YTZ4V 12V-3 Ah (10HR)
	1st 2.615
Gear ratio	2nd 1.555
	3rd 1.136
	4th 0.916
Reduction ratio (primary / final)	4.059 / 2.642

Specifications

■ Service Data

Tyre size	Front	70/90-17M/C 38P
	Rear	80/90-17M/C 50P
Tyre type	AFS110MD	Bias-ply, tube
	AFS110MCS	Bias-ply, tubeless
Recommended Tyre	Front	AFS110MD YUANXING CORDIAL YX-P180-XX VEE RUBBER V357F CST C-6016 IRC T-SPEC NF63B Z
		AFS110MCS IRC T-SPEC NF63B Y DUNLOP TT100
	Rear	AFS110MD YUANXING CORDIAL YX-P180-XX VEE RUBBER V357R CST C-6016R IRC T-SPEC NR78Y
		AFS110MCS IRC T-SPEC NR78Y DUNLOP ROADMASTER TT100

Tyre air pressure	Front	(Driver only) 200 kPa (2.00 kgf/cm ² , 29 psi)
		(Driver and passenger) 200 kPa (2.00 kgf/cm ² , 29 psi)
	Rear	(Driver only) 225 kPa (2.25 kgf/cm ² , 33 psi)
		(Driver and passenger) 280 kPa (2.80 kgf/cm ² , 41 psi)
Spark plug	(standard)	CPR6EA-9S (NGK) U20EPR9S (DENSO)
Spark plug gap		0.8 to 0.9 mm (0.03 to 0.04 in)
Idle speed		1,400 ± 100 rpm
Recommended engine oil		Honda 4-stroke motorcycle oil API Service Classification SG or higher, excluding oils marked as "Energy Conserving" or "Resource Conserving," SAE 10W-30, JASO T 903 standard MA
Engine oil capacity	After draining	0.8 litres (0.8 US qt, 0.7 Imp qt)
	After disassembly	1.0 litres (1.1 US qt, 0.9 Imp qt)
Recommended brake fluid	AFS110MCS	Honda DOT 3 or DOT 4 Brake Fluid
Recommended drive chain lubricant		Drive chain lubricant If not available, use SAE 80 or 90 gear oil.

Drive chain slack	20 to 30 mm (0.8 to 1.2 in)	
Standard drive chain	KMC420JB	
	DID420AD2	
	RK420EL	
	No. of links	104
Standard sprocket size	Drive sprocket	14T
	Driven sprocket	37T

■ Bulbs

Headlight	12 V-35/35 W
Brakelight/Taillight	12 V-21/5 W
Front turn signal light	12 V-10 W x 2
Rear turn signal light	12 V-10 W x 2
Position light	12 V-5 W
License plate light	12 V-5 W

■ Fuses

Main fuse	10 A
Other fuse	7.5 A

■ Torque Specifications

Engine oil drain bolt	24 N·m (2.4 kgf·m, 18 lbf·ft)
Front wheel axle nut	59 N·m (6.0 kgf·m, 44 lbf·ft)
Rear wheel axle nut	59 N·m (6.0 kgf·m, 44 lbf·ft)
Rear brake stopper arm nut	22 N·m (2.2 kgf·m, 16 lbf·ft)

A

Accessories10

B

Basic Operation Flow12

Battery38, 49

Brakelight Switch66

Brakes

Fluid59

Pad Wear60

Shoe Wear65

Braking7

Bulb

Brakelight/Taillight89

Front/Rear Turn Signal90

Headlight87

License Plate Light92

Position Light88

C

Caring for Your Vehicle97

Choke Lever25

Compartment

Document Bag31, 96

Tool31, 48

Crankcase Breather44, 74

D

Drive Chain42, 68

E

Electrical Trouble86

Engine

Number102

Oil41, 56

Starting23

Environment101

F

Flooded Engine25

Frame Number102

Fuel		
Gauge	18	
Recommended	28	
Remaining	18	
Tank Capacity	28	
Valve	22	
Fuels Containing Alcohol	103	
Fuses	40, 93	
 G		
Gasohol	103	
Gear Position Indicator	19	
Gear Range	18	
 H		
Headlight Aim	75	
Headlight Case	51	
Headlight Dimmer Switch	20	
Helmet Holder	30	
High Beam Indicator	19	
Horn Button	20	
 I		
Ignition Key	95	
Ignition Switch	21, 23	
Indicators	19	
Instruments	18	
 K		
Kickstarter	24	
 L		
Load Limits.....	11	
Loading Guidelines.....	11	
Luggage Box	31	
 M		
Main Pipe Cover	53	
Maintenance		
Fundamentals.....	37	
Importance	33	
Safety	33	
Schedule	34	
Maximum Luggage Weight	11	
Maximum Weight Capacity.....	11	

Modifications10

N

Neutral Indicator19

O

Odometer18

Oil

Engine41, 56

P

Parking8

Parts Location14

Petrol28, 103

Protective Apparel6

R

Recommended

Fuel28

Oil41

Refuelling28

Removal

Battery49

Headlight Case51

Main Pipe Cover53

Riding Precautions7

S

Safety Precautions6

Seat30

Serial Numbers102

Shifting Gears26

Side Stand67

Spark Plug54

Specifications105

Speedometer18

Start Button20, 23

Starting the Engine23

Steering Lock21

Storage

Compartment31

Document Bag31, 96

Equipment30

Storing Your Vehicle	99
Switches	20

T

Throttle	73
Tool	31, 48
Transporting Your Vehicle	100
Troubleshooting	76
Turn Signal Indicator	19
Turn Signal Switch	20

Tyres

Air Pressure	44, 105
Puncture	78
Replacing	44, 78

W

Washing Your Vehicle	97
----------------------------	----

Wheels

Front removal	80, 82
Rear removal	84



38K71A20
00X38-K71-A200

Boon Siew Honda Sdn. Bhd.
(676896-A)