





















CONTENTS—ENGINE GROUP


E01 CYLINDER HEAD (气缸头)	E02 CYLINDER (气缸)	E03 CRANKCASE (箱体)
		
E04 CRANKCASE COVER (箱盖)	E05 CRANKSHAFT (曲柄连杆)	E06 STARTER CLUTCH (起动离合器)
		
E07 CAM SHAFT VALVE (配气总成)	E08 CAM CHAIN (配气链条)	E09 OIL PUMP (机油泵)
		
E10 CLUTCH (离合器)	E11 TRANSMISSION (变速器)	E12 GEAR SHIFTING (变档)
		

CONTENTS—ENGINE GROUP

E13 STARTING MOTOR (起动电机)	E14 ELECTRICAL (电器件)	E15 ENGINE ASS'Y\CARBURETOR ASS'Y (发动机\化油器)
		
E16 KICK STARTER (反冲起动)		
		

CONTENTS—FRAME GROUP


F01 BODY COMP.,FRAME\FLOOR STEP	F02 SWITCH\CABLE\HANDLE\HANDLE LEVER\BRAKE	F03 FUEL TANK\SEAT\REAR CARRIER
		
F04 CHAIN CASE\CHAIN DRIVE \REAR SHOCK ABSORBER	F05 HEADLIGHT ASSY\METER\TURNING LINHT\TAILLIGHT ASSEMBLY	F06 WIRE HARNESS
		
F07 SWING ARM ASS'Y,RR\ARM,RR\REAR FENDER	F08 MAIN STAND\SIDE STAND	F09 FRONT WHEEL
		
F10 REAR WHEEL	F11 AIR CLEANER\EXHAUST MUFFLER\BATTERY COMP BRACKET\AIR CONDITIONING	F12 FRONT SHOCK ABSORBER\STEERING STEM\BRIDGE,FORK TOP
		



序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E1-1	11101QK01000-009	Head, cylinder	气缸头组合	1	
E1-2	09108Q060805	Stud bolt	双头螺柱	2	
E1-3	09161Q110801	RubberWasher	橡胶垫	1	
E1-4	09206Q080806	Pin 8×11	定位销8×11	2	
E1-5	02104Q060355	Bolt M6×35	螺栓M6×35	8	
E1-6	02104Q060602	Bolt M6×60	螺栓M6×60	2	
E1-7	11141QK01000	Gasket cylinder head	气缸头密封垫	1	
E1-8	09206Q110803	Pin 11×16	定位销11×16	2	
E1-9	09168Q060807	Washer	密封垫	2	
E1-10	11151QK01000	Rubber pad	减震块	6	
E1-11	09159Q080802	Nut M8	气缸头螺母M8	1	
E1-12	09159Q080804	Nut M8	盖形螺母M8	3	
E1-13	05406Q011065	Nut M6	螺母M6	2	
E1-14	09168Q080807	Gasket	密封垫	4	
E1-15	09482Q000809	Spark plug(NGK CR8E)	火花塞(CR8E)	1	
E1-16	11175QK01000-009	Cap, inspection	检查孔帽	2	


E1-17	09280Q290802	O-Ring (3.0×29.5)	O型圈 (3.0×29.5)	2
E1-18	09241Q220801	Plug, head	塞子	1
E1-19	26431QK01000	Geartachometer driven	转速表从动齿轮	1
E1-20	26441QK01000	Sleeve	连接套管	1
E1-21	26451QK01000	Oil seal	油封	1
E1-22	09128Q050802	Screw M5×12	螺钉M5×12	1
E1-23	09289Q040802	Oil seal 5×12×18	油封5×12×18	1
E1-24A	13111QK01010	Pipe, intake	进气弯管	1
E1-25	09280Q310801	O-Ring (2.4×31.7)	O型圈 (2.4×31.7)	1
E1-26A	02104Q060165	Screw M6×16	螺钉M6×16	2
E1-27	09402Q462007	Clamp	卡夹	1

FIG.2




E02 CYLINDER (气缸)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E2-1	11210QK01000-009	Cylinder	气缸体	1	
E2-2	09108Q080826	Stud bolt L:148	双头螺柱 L:148	2	
E2-3	09108Q080827	Stud bolt L:153	双头螺柱L:153	2	
E2-4	09108Q060824	Stud bolt L:34	双头螺柱 L:34	4	
E2-5	05404Q011062	Nut M6	螺母M6	4	
E2-6	11241QK01020	Gasket, cylinder	气缸密封垫	1	
E2-7	09206Q110804	Pin 11×14	定位销11×14	2	



E03 CRANKCASE (箱体)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E3-1	09206Q130803	Pin 13×18	定位销13×18	2	
E3-2A	6401017002100	Crankcase set	箱体组合	1	双启动
E3-3	02104Q060555	Bolt M6×55	螺栓M6×55	4	
E3-4	02104Q060605	Bolt M6×60	螺栓M6×60	4	
E3-5	02104Q060752	Bolt M6×75	螺栓M6×75	4	
E3-6	11319QK01000	Plate	压板	1	
E3-7	09124Q060807	Bolt M6×10	螺栓M6×10	1	
E3-8	09404Q066801	Clip	卡夹	1	
E3-9	09364Q120803	Hose, breath	通气管接头	1	
E3-10	33860QK01000	Lead wire	接地线	1	



E04 CRANKCASE COVER (箱盖)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E4-1A	11340QK01010-009	Cover clutch	离合器盖组合	1	双启动
E4-2	11971QK01000	Lens, oil level	机油窥视镜	1	
E4-3A	11482QK01070	Gasket, clutch cover	离合器盖垫	1	双启动
E4-4	09206Q130803	Pin 13×18	定位销13×18	2	
E4-5	09168Q060807	Gasket	密封垫	1	
E4-6	02104Q060305	Bolt M6×30	螺栓M6×30	9	
E4-7	02104Q060455	BoltM6×45	螺栓M6×45	1	
E4-8	09259Q200801	Plug , oil filler	塞子	1	
E4-9	09280Q160802	O-Ring (3.1×16.8)	O型圈 (3.1×16.8)	1	
E4-10	09247Q140803	Plug oil check M14×12	螺塞M14×12	1	
E4-11	09168Q130801	Gasket	复合垫圈	1	
E4-12	11351QK01J60-009	Cover, magneto	磁电机盖	1	
E4-13	11483QK010200	Gasket magneto cover	磁电机盖垫片	1	
E4-14	09206Q090803	Pin 9×12	定位销9×12	1	

E4-15	02104Q060305	Bolt M6×30	螺栓M6×30	2
E4-16	02104Q060355	Bolt M6×35	螺栓M6×35	2
E4-17	02104Q060405	BoltM6×40	螺栓M6×40	2
E4-18	02104Q060505	Bolt M6×50	螺栓M6×50	1
E4-19	09247Q120802	Plug, T.D.C M12×10	螺塞M12×10	1
E4-20	09168Q110801	Gasket	复合垫圈	1
E4-21	11353QK01000-009	Plug	塞子	1
E4-22	09280Q220801	O-Ring (3.1×22.7)	O型圈(3.1×22.7)	1
E4-23	11361QK01000	Cover, engine sprocket	链轮罩	1
E4-24	02104Q050255	Bolt M5×25	螺栓M5×25	1
E4-25	02104Q050355	Bolt M5×35	螺栓M5×35	2
E4-26	92810QMN2000	Retainer	链条隔板	1




E05 CRANKSHAFT (曲柄连杆)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E5-1	12200QK01000	Crankshaft assy	曲柄连杆总成	1	
E5-2	12111QK01000	Piston	活塞	1	
E5-3	12140QK01000	Ring set piston	活塞环组合	1	
E5-4	12151QK01000	Pin	活塞销	1	
E5-5	09381Q140801	Circlip	弹性挡环	2	
E5-6	09262Q280804	Bearing,RH 28×68×17	右曲柄轴承	1	
E5-7	09262Q350802	Bearing,LH 35×72×17	左曲柄轴承	1	
E5-8	09282Q120801	Oil seal, RH 12×21×7	右侧油封	1	
E5-9	16321QK01000	Gear oil pump drive	机油泵驱动齿轮	1	NT:15
E5-10	21111QK01000	Gear primary drive	初级驱动齿轮	1	NT:17
E5-11	09140Q160804	Nut M16	螺母M16	1	
E5-12	09166Q160801	Lock washer	锁紧垫片	1	
E5-13	09421Q040801	Key	键	1	
E5-14	12262QK01000	Washer	调整垫片	1	




E06 STARTER CLUTCH (起动离合器)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E6-1	12611QK01000	Gear, starter idle	电起动惰轮	1	
E6-2	09206Q130804	Pin	销轴	1	
E6-3	09180Q130801	Spacer	衬套	1	
E6-4	12600QK01000	Clutch set starter	电启动离合器组合	1	
E6-5	03614Q006169	Bolt M6×16	螺钉M6×16	3	
E6-6	12620QK01000	Gear starter assy	电启动齿轮组合	1	




E07 CAM SHAFT VALVE (配气总成)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E7-1	12711QK01000	Camshaft	配气凸轮轴	1	
E7-2	12741QK01000	Sprocket	凸轮轴链轮	1	
E7-3	09202Q050802	Pin 5×8	销子5×8	1	
E7-4	12747QK01000	Washer	链轮压板	1	
E7-5	09100Q060808	BoltM6×10.5	螺栓M6×10.5	2	
E7-6	09390Q220801	C-Ring	C型环	1	
E7-7	12840QK01000	Arm, valve rocker intake	摇臂组合	2	
E7-8	09289Q050805	Oil seal 5.5×11×8.2	油封5.5×11×8.2	2	
E7-9	12931QK01000	Retainer, spring	气门弹簧座	2	
E7-10	12861QK01000	Shaft,rocker arm	摇臂轴	2	
E7-11	09280Q080803	O-Ring 1.9×8.7	O型圈1.9×8.7	2	
E7-12	09164Q120806	Wave washer	波形垫圈	2	
E7-13	09168Q060807	Gasket	密封垫	2	
E7-14	09135Q060803	Bolt M6×25	螺栓M6×25	2	
E7-15	12911QK01000	Valve, intake	进气门	1	
E7-16	12912QK01000	Valve, exhaust	排气门	1	
E7-17	12921QK17000	Spring set, valve	气门内弹簧	2	
E7-18	12922QK17000	Spring, valve outer	气门外弹簧	2	
E7-19	12932QK01000	Cotter valve	气门锁夹	4	
E7-20	12933QK01000	Seat spring	气门弹簧下托盘	2	



E08 CAM CHAIN (配气链条)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E8-1	12760QK01000	Chain,cam shaft drive	配气链条	1	
E8-2	12771QK01000	Guide cam chain	链条导板	1	
E8-3	12811QK01000	Tensioner cam chain	链条涨紧板	1	
E8-4	12812QK01000-016	Bolt M8×39.5	螺栓M8×39.5	1	镀铬
E8-5	09168Q080806	Washer	垫圈	1	
E8-6	12830QK01010-009	Adjuster tensioner	涨紧器组合	1	
E8-7	12837QK01020	Gasket, adjuster	涨紧器垫片	1	
E8-8	01604Q060202	Bolt M6×20	螺栓M6×20	2	
E8-9	05420Q022063	Spring washer	垫圈	2	



E09 OIL PUMP (机油泵)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E9-1	16400QK01000	Pump, engine oil	机油泵组合	1	
E9-2	16331QK01000	Gear, driven	机油泵齿轮	1	
E9-3	09261Q020802	Pin (2.5×11.8)	驱动销 (2.5×11.8)	1	
E9-4	09383Q060801	Circlip	E型环	1	
E9-5	03414Q060251	Screw M6×25	螺钉M6×25	3	
E9-6	16520QK01000	Strainer, engine oil	机油滤网组合	1	
E9-7	03414Q350121	Screw M5×12	螺钉M5×12	2	
E9-8	03014Q060851	Stud bolt M6×85	螺柱M6×85	1	
E9-9	05406Q011065	Nut M6	盖形螺母M6	3	
E9-10	16523QK01000	Cap	滤网盖	1	
E9-11	09280Q600801	O-Ring (2.4×60.5)	O型圈 (2.4×60.5)	1	
E9-12	02204Q060201	Bolt M6×20	螺栓M6×20	3	
E9-13	09247Q140804	Plug drain M14×12	螺栓M14×12	1	
E9-14	09168Q060810	Gasket	复合垫圈	1	


E9-15	16510QK01000	Filter engine oil	机油过滤器组合	1	
E9-16	09280Q130803	O-Ring (1.9×13)	O型圈 (1.9×13)	1	
E9-17	09440Q180804	Spring	弹簧	1	
E9-18	16514QK01000	Gasket	滤芯盖纸垫	1	
E9-19	09280Q520801	O-Ring (2.4×52.6)	O型圈 (2.4×52.6)	1	
E9-20	16512QK01M00-009	Cap	机油滤芯盖	1	H: 16
E9-21	03014Q060121	Stud bolt M6*12	双头螺柱M6*12	2	



E10 CLUTCH (离合器)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E10-1	21200QK01000	Gear assy primary driven	离合器大毂组合	1	双起动
E10-2	09181Q200811	Washer	垫片	2	
E10-3	21411QK01000	Hub, sleeve	离合器花键套	1	
E10-4	09140Q160805	Nut M16	六角螺母M16	1	
E10-5	09168Q160802	Lock washer	保险垫圈	1	
E10-6	23110QK01000	Rod, push	离合器顶杆组合	1	
E10-7	21441QK01000	Plate,drive	主动磨擦片	5	
E10-8	21451QK01000	Plate,driven	从动片	4	
E10-9	21462QK01000	Disk,pressure	离合器弹簧盘	1	
E10-10	09440Q150802	Spring	离合器弹簧	5	
E10-11	09116Q050801	Bolt M5×16	螺栓M5×16	5	
E10-12	09124Q060801	Bolt M6×10	螺栓M6×10	1	
E10-13	23121QK01000	Peace	离合器顶柱	1	
E10-14	23122QK01000	Camshaft	离合器分离凸轮轴	1	


E10-15	09181Q100806	Washer	平垫圈	1
E10-16	09160Q150801	Washer	平垫圈	1
E10-17	09263Q150807	Thrust, bearing	端面滚针轴承	1
E10-18	09283Q100804	Oil seal	油封	1
E10-19	21464QK01000	Screw M6×25	顶丝M6×25	1
E10-20	22117QK01000	Nut M6	螺母M6	1
E10-21	23271QK01000	Arm, release	离合器摇臂	1
E10-22	01604Q060165	Bolt M6×16	螺钉M6×16	1
E10-23	23123QK01000	Washer	油封压板	1
E10-24	21251QK01000	Spacer	离合器大毂内套	1



E11 TRANSMISSION (变速器)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E11-1	24121QK01000	Countershaft	中间轴 (不含齿轮)	1	
E11-2	24359QK01000	Washer	轴承挡圈	1	
E11-3A	09263Q150805	Bearing RH	驱动轴滚针轴承	1	双起动
E11-4	05510Q006204	Bearing LH	轴承6204基本组	1	
E11-5	24741QK01000	Holder, bearing	轴承挡板	1	
E11-6	03424Q060121	Screw M6×12	螺钉M6×12	2	白锌
E11-7	09262Q200806	Bearing , RH	中间轴右端轴承	1	6204C9
E11-8	05530Q006002	Bearing LH	中间轴左端轴承	1	6002-Z
E11-9	24741QK01000	Holder, bearing	轴承挡板	1	
E11-10	03424Q060121	Screw M6×12	螺钉M6×12	2	
E11-11	09283Q270803	Oil seal , LH	驱动轴油封	1	27*40*6
E11-12	24751QK01000	Holder oil seal	驱动轴油封挡板镀锌	1	
E11-13	01704Q060101	Bolt M6×10	螺栓M6×10	2	
E11-14	09181Q150807	Washer	垫圈	1	脚起动
E11-15	05430Q021156	Circlip 15	轴用弹性挡圈 15	1	脚起动


E11-16	27511QK01000	Sprocket (NT: 13)	链轮428 (NT: 13)	1	
E11-17	27531QK01000	Spacer	衬套	1	
E11-18	09280Q190804	O-Ring 19*2.4	O型环 19*2.4	1	
E11-19	09140Q160807	Nut M16×1.5	螺母M16×1.5	1	
E11-20	09167Q200808	Washer	止动垫圈	1	
E11-21	09181Q150807	Washer`	垫圈	1	脚起动
E11-22	26260QK01000	Idler pulley	起动惰轮组合	1	脚启动
E11-23A	24131QK01010	Driveshaft	驱动轴	1	双起动
E11-24	24120QK01000	Countershaft	中间轴组合(含齿轮)	1	
E11-25A	24130QK01010	Driveshaft	驱动轴组合 (含齿轮)	1	双起动



E12 GEAR SHIFTING (变档)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E12-1	25211QK01000	Fork,gear shifting (I)	变档拨叉 I	2	
E12-2	25231QK01000	Fork gear shifting (III)	变档拨叉 III	1	
E12-3	25411QK01000	Shaft, fork (I)	变档拨叉轴 I	1	
E12-4	25421QK01000	Shaft fork (II)	变档拨叉轴 II	1	
E12-5	25310QK01000	Cam, gear shifting	变档凸轮组合	1	
E12-6	25381QK01000	Plate, stopper	凸轮定位盘	1	
E12-7	25322QK01000	Gear cam driven	变档摇臂从动齿块	1	
E12-8	25323QK01000	Pawl, (I)	千斤 I	1	
E12-9	25324QK01000	Pawl, (II)	千斤 II	1	
E12-10	09202Q050803	Pin	千斤轴销	2	
E12-11	09440Q040806	Spring	千斤轴销弹簧	2	
E12-12	25331QK01000	Lifter, pawl	凸轮挡板	1	
E12-13	03424Q060121	Screw M6×12	螺钉 M6×12	2	
E12-14	25341QK01000	Guide, cam	凸轮保持架	1	

E12-15	03424Q060121	Screw M6×12	螺钉M6×12	2	
E12-16	25350QK01000	Stopper, cam	变档凸轮定位板组合	1	
E12-17	09103Q060813	Bolt M6×16	螺栓M6×16	1	
E12-18	09181Q060801	Washer I	垫圈I	1	
E12-19	09440Q110803	Spring	凸轮顶销弹簧	1	
E12-20	09443Q080801	Spring	变档限位拉簧	1	
E12-21	09201Q040802	Hook	柱销	1	
E12-22	25351QK01000	Stopper, neutral	凸轮顶销	1	
E12-23	03414Q050205	Screw M5×20	螺钉M5×20	2	
E12-24	04522Q040061	Pin4×6	销子4×6	1	
E12-25	09247Q140803	Plug, cam stopper	螺塞	1	M14×12
E12-26	09168Q130801	Washer	复合垫圈	1	
E12-27	25510QK01000	Shaft, gear shifting	变档轴组合	1	
E12-28	09180Q120803	Spacer	变档轴套	1	
E12-29	09444Q260802	Spring	变档轴扭簧	1	
E12-30	25671QK01000	Stopper, arm	变档回位销	1	
E12-31	09283Q120802	Oil seal	变档轴油封	1	
E12-32	01102Q060201	Bolt M6×20	螺栓M6×20	1	
E12-33	09160Q120002	Washer II	垫圈II	1	
E12-34	05430Q021126	Circlip	轴用弹性挡圈	1	
E12-35	37720QK01000	Terminal base assy	变档开关组合	1	
E12-36	09280Q260802	O-Ring 24×26.2	O型圈24×26.2	1	
E12-37	09440Q040804	Spring	轴销压簧	1	
E12-38	09202Q050804	Contact	轴销	1	
E12-39A	25600QMN2000	Lever assy	变档杆组合	1	直式
E12-40	09181Q250810	Washer	平垫圈	1	




E13 STARTING MOTOR (启动电机)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E13-1	31100QK01000	Motor assy starting	启动电机总成	1	
E13-2	09280Q250804	O-Ring (3*24.5)	O型圈 (3*24.5)	1	
E13-3	02104Q060305	Bolt M6×30	螺栓M6×30	2	




E14 ELECTRICAL (电器件)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E14-1	32101QK01000	Stator assy	定子组合	1	
E14-2	32102QK01000	Rotor, flywheel	磁电机转子	1	
E14-3	03434Q050255	Screw M5×25	螺钉M5×25	3	
E14-4	09125Q040801	Screw M 4 ×12	螺钉M 4 ×12	2	
E14-5	05404Q021104	Nut M10	螺母M10	1	
E14-6	05440Q030132	Key3×13	半圆键3×13	1	
E14-7	32100QK01000	Magneto	磁电机组合	1	
E14-8	32900QK01000	CDI unit	点火器组合	1	电感式
E14-9	09139Q060002	Screw M6×16	螺钉M6×16	2	
E14-10	33400QK01000	Coil assy, ignition	点火线圈	1	
E14-11	03451Q350124	Screw M5×12	螺钉M5×12	2	



E15 ENGINE ASS'Y\CARBURETOR ASS'Y (发动机\化油器)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E01-1	6102090401502	ENGINE ASS'Y	GS王柱塞黑机,非补双启,13T	1	
E01-2	13200QK01090	CARBURETOR ASS'Y	化油器	1	
E01-3	6250001004002	REER COVER	GS链轮罩(含螺栓)黑色	1	
E01-4		BOLT,HEX FLANGE (M5×35)	六角法兰面螺栓M5×35	3	
E01-5	6260050090000	ARM, CLUTCH RELEASE	离合器摇臂	1	
E01-7	6250047000523	KICK START LEVER	起动杆组合 (QM200GY)	1	
E01-10	6201999100000	PLUG	转速孔堵头	1	



E16 KICK STARTER (反冲起动)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
E16-1	6250047000523	Lever kick	起动杆组合	1	
E16-2	01604Q080251	Bolt M8×25	螺栓M8×25	1	
E16-3	09283Q160804	Oil seal	油封	1	
E16-4	09160Q160807	Washer	推力垫圈	1	
E16-5	26240Q01000	Gear, starter drive	起动驱动齿轮组合	1	
E16-6	09160Q200805	Washer	垫圈	1	
E16-7	26211QK01000	Shaft kick starter	反冲起动轴	1	
E16-8	26231QK01000	Ratchet Wheel	起动结合子	1	
E16-9	09440Q310802	Spring	反冲起动弹簧	1	
E16-10	09160Q170804	Washer	垫圈	1	
E16-11	26221QK01000	Guide shaft spring	弹簧导套	1	
E16-12	26212QK01000	spring	起动轴回位弹簧	1	
E16-13	09380Q160803	Spring	弹性挡环	1	
E16-14	01704Q080201	Bolt M8×20	螺栓M8×20	2	
E16-15	26232QK01000	Plate	反冲起动导板	1	
E16-16	26233QK01000	Plate	反冲起动挡板	1	

F1



F1-BODY COMP.,FRAME\FLOOR STEP (车架\脚踏)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F1-01	1031400073000	FRAME,PART 1	QM250-2X车架	1	
F1-03	7082803010002	RIVET (φ3.0×10)	抽芯铆钉 铝材	2	
F1-04	1030300030000	PLATE,ENGINE RIGHT UP HANGER	QM125-2发动机吊板	2	
F1-05	7013008050168	BOLT,HEX FLANGE(M8×50)	六角法兰螺栓 蓝白锌	3	
F1-06	7033608000148	NUT,FLANGE	六角法兰自锁螺母 蓝白锌	3	
F1-07	1030300020000	PLATE,ENGINE FR.HANGER	QM125-2发动机托架	1	
F1-08	7013008065167	BOLT,HEX FLANGE (M8×65)	六角法兰螺栓 军绿	2	
F1-09	7.01301E+12	BOLT,HEX FLANGE (M8×65)	六角法兰螺栓 军绿	2	
F1-10	7034310000247	NUT (M10×1.25)	六角法兰螺母 军绿	2	
F1-11	7013008090168	BOLT,HEX FLANGE (M8×90)	六角法兰螺栓 蓝白锌	2	
F1-12	7033608000148	NUT,FLANGE	六角法兰自锁螺母 蓝白锌	2	
F1-13	1041400190000	BAR COMP.,STEP L.	QM250-2X前左脚踏组合	1	
F1-14	1041400200000	BAR COMP.,STEP R.	QM250-2X前右脚踏组合	1	

F1



序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F1-15	7013012030268	BOLT,HEX FLANGE	六角法兰螺栓 蓝白锌	2	
F1-16	1260700040204	BAR COMP.,PILLION STEP ,L	QM125-2V后左搁脚组合	1	
F1-17	1260700050204	BAR COMP.,PILLION STEP ,R	QM125-2V后右搁脚组合	1	
F1-18	7012810025267	BOLT,HEX FLANGE (M10×55)	六角法兰螺栓 军绿	2	
F1-19	1041400120000	HANDLE COMP,PILLION RIDER	QM250-2X后扶手	2	
F1-20	1040400211000	CLAMPER,CLUTCH CABLE	QM125-10K离合线夹	1	
F1-21	7012810045267	HEXAGON FLANGE BOLT	六角法兰螺栓 军绿	1	


F2




F2- SWITCH\CABLE\HANDLE\HANDLE LEVER\BRAKE (开关\导线\方向把\手把拉杆\碟刹)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F2-1	1040400260000	HANDLE COMP.,STEERING (HIGH HANDLE BAR)	QM125-3B(E)方向把	1	black
F2-1	1130100070000	HANDLE COMP.,STEERING (LOW HANDLE BAR)	QM125-2V方向把	1	silver
F2-2	1260300231000	GRIP,R.HANDLE	QM125-2双火右旋把胶组合	1	
F2-3	1260300221000	GRIP,L.HANDLE	QM125-2双火左握把胶	1	
F2-4	1139900008000	WEIGHT BALANCE MASS	平衡块(小头电镀)	2	
F2-5	1180300190000	FRONT BRAKE SWTICH CABLE	QM125-2前刹车开关线	1	
F2-6	1161000012000	SPEEDOMETER ASSY	QM125GY-2D仪表	1	
F2-7	1180300123000	SWITCH COMP.,L.	QM125-10B(B)L左手把开关	1	
F2-8	1180200110000	SWITCH ASSY	QM125-7A左闸把	1	
F2-9	1141400010000	DISK BRAKE ASS;Y,FRONT (HIGH HANDLE BAR)	QM250-2X前碟刹组合	1	
F2-9	1141400011000	DISK BRAKE ASS;Y,FRONT (LOW HANDLE BAR)	QM250-2X前碟刹组合	1	
F2-10	1180300231000	SWITCH COMP.,R.	QM125-2右手把开关	1	

F2




序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F2-12	7013006012167	BOLT,HEX FLANGE (M6×12)	六角法兰螺栓 军绿	1	
F2-13	1280400049000	CABLE COMP.,THROTTLE (HIGH HANDLE BAR)	QM125-2X油门线	1	
F2-13	1280700010000	CABLE COMP.,THROTTLE (LOW HANDLE BAR)	QM125-2V油门线	1	
F2-14	1281000020000	CABLE COMP.,CLUTCH (HIGH HANDLE BAR)	QM125GY-2D离合线	1	
F2-14	1281200021000	CABLE COMP.,CLUTCH (LOW HANDLE BAR)	QM125-2T离合线	1	
F2-15	1281400030000	CABLE COMP.,SPEEDOMETER	QM250-2X里程线	1	
F2-16	1041000070000	BRACKET	QM125GY-2D仪表支架	1	
F2-17	1260300330000	CLAMPER,CLUTCH CABLE	QM125-2离合器下线夹	1	
F2-18	1260200010000	GRIP,L.HANDLE	QM125-7A手柄护套	1	
F2-19	7511806020167	CROSS SCREW,SPEEDOMETER	十字大扁头螺钉 军绿	2	
F2-20	7024908020167	HEXAGON SCREW,SPEEDOMETER BRACKET	内六角圆柱头螺钉 军绿	2	
F2-21	1260300300000	RUBBER CUSHION,TORQUE BAR	QM125-2扭力杆胶垫	4	




F3 - FUEL TANK\SEAT\REAR CARRIER (油箱\坐垫\后货架)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F3-01	1181400152000	KEY SET	QM250-2X套锁	1	
F3-02	7021805012158	SCREW,PAN (M5×12)	盘头螺钉	2	
F3-03	1241400116002	FULE TANK, BLACK	QM250-2X油箱(B款) (出口)	1	
	1241400021501	FULE TANK, BLACK	QM250-2X油箱(B款) (出口)	1	
F3-04	1260300010000	POSITION FIXING WASHER	QM125-2油箱前缓冲胶	2	
F3-05	1261700020000	CUSHION,UPPER REAR	QM125-10E油箱后缓冲上胶圈	2	
F3-06	1261700010000	CUSHION,LOWER REAR	QM125-10E油箱后缓冲T形胶圈	2	
F3-07	7012406040168	BOLT,HEX FLANGE (M6×40)	六角法兰螺栓	2	
F3-08	7052706222038	WASHER ,PLAIN φ×6	加大垫圈 蓝白锌	2	
F3-09	1211400012000	SEAT ASS'Y	QM250-2X坐垫	1	
F3-10	1040300130000	COCK ASS'Y,FUEL	QM125-2油箱开关	1	
F3-11	7012806016168	BOLT,HEX FLANGE (M6×16)	六角法兰螺栓 蓝白锌	2	
F3-12	1260300322000	TUBE ASS'Y,VACUUM (120mm)	QM125-2油管	1	
F3-13	1260300980000	CLIP ANNULUS φ7*1.1	卡环φ7*1.1	2	



序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F3-14	1260300040000	CLIP ANNULUS Φ7-Φ10×20	QM125-2油箱后胶圈衬套	2	
F3-15	1261400050000	LEFT FUEL TANK DECORATE RUBBER	QM250-2X油箱左装饰皮	1	
F3-16	1261400060000	RIGHT FUEL TANK DECORATE RUBBER	QM250-2X油箱右装饰皮	1	
F3-17	1221400034002	SEAT COVER (BLACK)	QM250-2X座垫装饰罩	1	
F3-17	1221400032301	SEAT COVER (ORANGE)	QM250-2X座垫装饰罩		
F3-18	7050108161638	GASKET,SEAT	垫圈 蓝白锌	2	
F3-19	7012406016164	HEXAGON BOLT,SEAT	六角螺栓 白铬	2	
F3-20	7070042012007	CROSS SCREW, SEAT COVER	十字槽自攻螺钉 军绿	2	
F3-21	7025006012164	PIN,SEAT	QM250-2X座垫销子	2	
F3-22	7630208025164	HEXAGON BOLT,TURNING LIGHT BRACKET	六角球头螺栓 白铬	2	

F4


F4-CHAIN CASE\CHAIN DRIVE \REAR SHOCK ABSORBER (链罩\链条\后减震器总成)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F4-01	1100400053903	REAR SHOCK ABSORTER	QM125-3B(E)后减震器组合	2	
F4-02	7050210302538	WASHER,PLAIN (M10)	垫圈 蓝白锌	4	
F4-03	7033710000244	NUT,CAP (M10×1.25)	盖形螺母 白铬	4	
F4-04	7050312242538	WASHER,PLAIN (φ12)	垫圈 蓝白锌	4	
F4-05	1260300100000	CHAIN,SLIDE PIECE	QM125-10B链条滑块(带铁)	1	
F4-06	7070042016007	Screw	十字槽白攻螺钉 军绿	1	
F4-07	1070200040000	CHAIN DRIVE	链条	1	
F4-08	7111106016167	CROSS BOLT ASSY. CHAIN COVER REAR	十字小盘头大平垫组合螺钉 军绿	2	
F4-09	1260300190000	CUSHION,INNER	QM125-2链罩橡胶圈	1	
F4-10	1221000012000	CASE,UPPER HALF DRIVE CHAIN	QM125GY-2D链盒(改进)	1	
F4-11	7111106012167	CROSS BOLT ASSY. CHAIN COVER FRONT	十字小盘头大平垫组合螺钉 军绿	1	


F5




F5-HEADLIGHT ASSY\METER\TURNING LINHT\TAILLIGHT ASSEMBLY (前大灯\仪表\转向灯\尾灯)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F05-1	1170400056000	HEAD LIGHT ASSY	QM125-2B大灯	1	
F05-2	1171000010000	WINKER ASSY L FRONT	QM125GY-2D前左转向灯	1	
F05-3	1171000020000	WINKER ASSY R FRONT	QM125GY-2D前右转向灯	1	
F05-4	1171000030000	WINKER ASSY L REAR	QM125GY-2D后左转向灯	1	
F05-5	1171000040000	WINKER ASSY R REAR	QM125GY-2D后右转向灯	1	
F05-6	1171000060000	TAIL LAMP ASSY	QM125GY-2D尾灯	1	
F05-7	1041000080000	TAIL LAMP BRACKET	QM125GY-2D尾灯支架	1	
F05-8	1260300180000	CUSHION, REAR FENDER REAR	QM125-2后挡泥板胶圈	2	
F05-9	7050206181637	WASHER,PLAIN (M10)	垫圈 军绿	2	
F05-10	7511806016167	BOLT M6×16	十字大扁头螺钉 军绿	2	
F05-11	1261000920000	REAR REFLECTOR	QM125GY-2D后反射器	1	
F05-12	1041400010000	BRACKET, HEADLAMP	QM250-2X大灯支架	2	
F05-13	1041000110000	BRACKET, REAR TURNING LIGHT, L	QM125GY-2D后左转向灯支架	1	

F5



序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F05-14	1041000120000	BRACKET, REAR TURNING LIGHT, R	QM125GY-2D后右转向灯支架	1	
F05-15	1260200152000	RUBBER,HEAD LIGHT BRACKET	QM125-7A大灯支架胶	2	
F05-16	1041300050205	LINK PLATE,HEAD LIGHT BRACKET	QM125-10M大灯支架连接板	2	
F05-17	7013006020167	HEXAGON FLANGE BOLT	六角法兰螺栓 军绿	3	
F05-18	7032606000147	HEXAGON FLANGE BOLT	六角法兰螺母 军绿	13	
F05-19	7523706017147	ACORN NUT	长盖形螺母 军绿	2	
F05-20	7702208020164	HEXAGON BOLT ASSY.	球面六角弹平垫组合螺栓 镀铬	2	
F05-21	7511806012167	CROSS SCREW	十字大扁头螺钉 军绿	6	
F05-22	7032606000148	HEXAGON FLANGE BOLT	六角法兰螺母 蓝白锌	2	



F6-WIRE HARNESS (主电缆)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F6-01	1180400600000	WIRE HARNESS	QM125-3B(E)主线束	1	
F6-02	1180300030000	SWITCH ASS'Y,STARTER MAGNETIC	QM125-2起动继电器	1	
F6-03	1180300050000	FLASH UNIT	QM125-2闪光器	1	
F6-04	1180300040000	RECTIFIER COMP.,REGULATOR	QM125-2整流稳压器	1	
F6-05	7011006020168	SCREW,PAN (M6×16)	十字槽凹穴六角螺栓 蓝白锌	1	
F6-06	1180300010000	COIL COMP.,IGNITION	QM125-2高压包	1	
F6-07	7021805012158	SCREW,PAN (M5×12)	十字槽盘头螺钉 蓝白锌	2	
F6-08	1180300020000	C.D.I. UNIT	QM125-2点火器	1	
F6-09	1150000041000	BATTERY	QM125-2蓄电池	1	
F6-10	7012808016167	BOLT,HEX FLANGE (M8×16)	六角法兰螺栓 军绿	1	
F6-11	1181000060000	HORN	QM125GY-2D喇叭(E4 000422)	1	
F6-12	1180400100000	LEAD WIRE, STARTING MOTOR	起动马达线	1	


F7



F7 - SWING ARM ASS'Y,RR\ARM,RR\REAR FENDER (后平叉\扭力杆\后挡泥板)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F7-01	1041400140000	SWING ARM ASS'Y,RR.	QM250-2X后平叉(碟刹)	1	
F7-02	1220300041000	BODY,REAR FENDER, FRONT	QM250-2X后挡泥板前部	1	
F7-03	1221400110000	FENER,REAR	QM250-2X后挡泥板后段	1	
F7-04	7012808040167	BOLT M8×40	六角法兰螺栓 军绿 M8*40 GB5787-00 2	2	
F7-05	7013006016167	BOLT M6*16	六角法兰螺栓 军绿M6*16	7	
F7-06	1260300180000	CUSHION,REAR FENDER REAR	QM125-2后挡泥板胶圈	2	
F7-07	1040300350000	ADJUSTER	QM125-2调链器	2	
F7-08	1080300140000	BOLT,RR.FORK PIVOT	QM125-2后平叉轴(含螺母)	1	
F7-09	1260300290000	BUFFER, CHAIN TOUCH DEFFENSE	QM125-2链条滑块	1	
F7-10	7032608000147	HEXAGON FLANGE BOLT	六角法兰螺母 军绿	4	
F7-11	7630308050168	HEXAGON BALL HEAD BOLT	六角球头螺栓 蓝白锌	2	

F8



F8 - MAIN STAND\SIDE STAND (主支架\侧支架)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F8-01	1041400060000	SIDE STAND	QM250-2X侧支架	1	
F8-02	1290300020000	SPRING A,SIDE STAND	QM125-2侧支架簧	1	
F8-03	7640310035267	BOLT,HEX STEP (M10×35)	侧支腿阶梯螺栓 军绿	1	
F8-04	7640310035267	NUT,HEX (M10)	六角螺母 军绿	1	
F8-05	7013006025107	HEXAGON FLANGE BOLT	六角法兰螺栓 军绿	2	
F8-06	1041400090000	PEDAL, REAR BREAK	QM250-2X刹车踏板(碟刹)	1	
F8-07	1290300031000	SPRING.BACKWARD,BRAKE PEDAL	QM125-2刹车踏板簧	1	
F8-08	1040300061000	SPACER, BRAKE PEDAL BOSS	QM125-10B刹车踏板轴套	1	
F8-09	7012810055268	BOLT, BRAKE PEDAL	后刹车踏板螺栓M10*55*1.25	1	
F8-10	7040020016008	PIN, FR FOOTREST COTTER	开口销 蓝白锌	1	
F8-11	7012406020168	BOLT	六角螺栓 蓝白锌	1	
F8-12	1040400120000	PEDAL COMP.,GEAR CHANGE	QM125-2B变档杆(单向)	1	




F9-FRONT WHEEL (前轮)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F9-01	1090100510000	TIRE,FR.WHEEL	前轮外胎(90/90-17)	1	
F9-02	1090100500000	TUBE,FR.WHEEL	前轮内胎(90/90-17)	1	
F9-03	1081400012000	WHEEL SUB ASS'Y,FR.	QM250-2X前轮辋组合	1	
F9-04	1081400070908	COLLAR,FR.R WHEEL SIDE	QM250-2X前轮右轴套	1	
F9-05	1081400060908	AXLE,FR.WHEEL	QM250-2X前轮轴(含螺母)	1	
F9-06	1081400052000	GEAR BOX ASSY	QM250-2X计速器	1	
F9-07	1141400020000	DISC FRONT AXLE	QM250-2X前碟刹盘	1	
F9-10	1090100999000	FLAP	轮胎垫带		
F9-11	1040200510000	POSITION LIMITER,SPEEDOMETER GEAR	QM250-2X计速器限位支架	1	



F10 - REAR WHEEL(后轮)


序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F10-01	1090100530000	TIRE,RR.WHEEL	后轮外胎(110/80-17)	1	
F10-02	1081400022000	WHEEL SUB ASS'Y,RR.	QM250-2X后轮辋组合	1	
F10-03	1070100022000	CLUTCH,HALF	链轮42T	1	
F10-04	7112210030168	BOLT,SPROCKET,FINAL DRIVE	六角弹平垫组合螺栓 蓝白锌	4	
F10-05	1081400090908	COLLAR,RR.L	QM250-2X后轮左轴套	1	
F10-06	1081400080908	AXLE,RR.WHEEL	QM250-2X后轮轴(含螺母)	1	
F10-07	1141400031000	REAR DISK BRAKE,ASSY.	QM250-2X后碟刹组合	1	
F10-07	1141400030000	REAR DISK BRAKE,ASSY.	QM250-2X后碟刹组合	1	
F10-08	1081400100908	COLLAR,RR.R	QM250-2X后轮右轴套	1	
F10-09	1090100520000	Rear inner tube	后轮内胎(110/80-17)	1	
F10-10	7032608000148	NUT,HEX (M14×1.5)	六角法兰螺母 蓝白锌	1	
F10-11	1090100999000	FLAP	轮胎垫带	1	
F10-12	1141400040000	REAR BRAKE DISK	QM250-2X后碟刹盘	1	



F11- AIR CLEANER\EXHAUST MUFFLER\BATTERY COMP BRACKET\AIR CONDITIONING

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F11-01	1040300230000	BATTERY BRACKET	QM125-2电池支架	1	
F11-02	7012406020168	BOLT,FLANGE (M6×20)	六角螺栓 蓝白锌	3	
F11-03	1260300060000	BUSH BRACE,BATTERY	QM125-2电瓶支架衬套	3	
F11-04	1260300070000	RUBBER,BATTERY	QM125-2电瓶支架胶圈	3	
F11-05	1220300021000	TOOL SET BOX	QM125-9B工具盒(含盖)	1	
F11-06	7031906000148	NUT,HEX (M6)	六角螺母 蓝白锌	3	
F11-07	1040300320000	TRIPOD	QM125-2三角固定板	1	
F11-08	1121400011305	EXHAUST MUFFLER	250-2X消声器 (带短形防烫板安装)	1	
F11-09	1221400014000	AIR CLEANER ASS'Y	QM125-2X空滤器组合(欧I)	1	
F11-10	7111906016168	WASHER BOLT	六角平垫组合螺栓 蓝白锌	2	
F11-11	1260300891000	BAND BATTERY	电瓶皮带(带保险管夹)	1	
F11-12	1590300011000	GASKET,EXHAUST	消声器垫	1	
F11-13	7024908025167	HEXAGON BOLT	内六角圆柱头螺钉 军绿	2	
F11-14	1040400255000	HEAT PROOF PLATER,MUFFLER	QM250-2X防烫板	1	
F11-15	1593200030000	UPPER GASKET,MUFFLER	QM125T-9E消声器上衬套	1	DO NOT SUPPLY

F12



F12 - FRONT SHOCK ABSORBER\STEERING STEM\BRIDGE,FORK TOP

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F12-01	1051400010000	STEM COMP.,STEERING	QM250-2X方向柱组件	1	
F12-02	1051400060000	LOCKED NUT	锁紧螺母	1	
F12-03	1051400090000	DUST PROOF CAP	防尘盖	1	
F12-04	1051400130000	UPPER BEARING,STEM STEERING	QM250-2X滚针上轴承组件	1	
F12-05	1051400140000	LOWER BEARING,STEM STEERING	QM250-2X滚针下轴承组件	18	
F12-06	1261000910000	REFLECTOR	QM125GY-2D侧反射器	2	
F12-07	1101400020000	SHOCK ABSORBER,FRONT R.	QM250-2X倒置右前减震器	1	
F12-08	1101400010000	SHOCK ABSORBER,FRONT L.	QM250-2X倒置左前减震器	1	
F12-09	1051400060000	NUT	QM250-2X锁紧螺母	1	
F12-10	1050700100000	NUT COVER	QM125-2V压把块装饰片	4	
F12-11	1051400020000	BRIDGE,FORK TOP	QM250-2X上联板	1	
F12-12	7013006012167	BOLT,HEX FLANGE (M6×12)	六角法兰螺栓 军绿	2	
F12-13	7050122361034	GASKET	垫圈 白铬	1	

F 1 3



F13 - FRONT FENDER\L&R RR.COVER(前挡泥板\左右侧盖)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F13-01	1041400180000	FRONT FENDER	QM250-2X前挡泥板	1	
F13-02	7511806016167	Cross screw	十字大扁头螺钉 军绿 M6*16 非标	3	
F13-03	1260400090000	CABLE CLIP	QM125-2B软轴导环	1	
F13-04	1251400051002	COVER SUB ASS'Y,R.SIDE	QM250-2X右侧盖(B款)	1	BLACK
F13-04	1251400062002	COVER SUB ASS'Y,R.SIDE	QM250-2X右侧盖(B款)	1	ORANGE
F13-05	1251400041002	COVER SUB ASS'Y,L.SIDE	QM250-2X左侧盖(B款)	1	BLACK
F13-05	1251400061002	COVER SUB ASS'Y,L.SIDE	QM250-2X左侧盖(B款)	1	ORANGE
F13-06	1260300160000	WASHER RUBBER .UNDER	QM125-2侧盖胶圈A	2	
F13-07	1260300170000	WASHER RUBBER .UNDER	QM125-2侧盖胶圈D	2	
F13-08	1041400210000	Front fender bracket(front)	QM250-2X前挡泥板支架 (前)	1	
F13-09	1041400220000	Front fender bracket(rear)	QM250-2X前挡泥板支架 (后)	1	

F14



F14— LABEL\ANNEX (标牌贴花\附件)

序号 NO.	零件号码 Article NO.	英文名称 Description of English	中文名称 Description of Chinese	用量 Q'TY	备注 REMARK
F14-01	1201000021000	MIRROR BACK R	QM125GY-2D右后视镜(无标)	1	
F14-02	1201000011000	MIRROR BACK L	QM125GY-2D左后视镜(无标)	1	
F14-03	1040300370000	TOOL SET	随车工具	1	
F14-05	1260300901000	BAND WIRE (250mm)	尼龙扎带	6	
F14-06	1263200902000	BAND WIRE (300mm)	尼龙扎带	2	
F14-07	1260300903000	BAND WIRE (245mm)	尼龙扎带	4	