



F01 操纵 CONTROL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F01	40450U210001	LR VIEW MIRROR ASSY	1	
2	F01	40480U210001	RR VIEW MIRROR ASSY	1	
3	F01	40101L430000	HANDLE BAR ASSY	1	
4	F01	B0205060356H	SCREW M6×35	2	
5	F01	B0703000060H	WASHER 6	2	
6	F01	B0700000060H	SPRING WASHER 6	2	
7	F01	40031P250000	GRIP END	2	
8	F01	40032P250000	BALANCE PIECE INSTALLED A	2	
9	F01	40031S010000	BALANCER	2	
10	F01	40001K740000	LEFT HANDLEBAR GRIP	1	
11	F01	40500L210002	LEFT HANDLEBAR SWITCH	1	
12	F01	40600L210004	RIGHT HANDLEBAR SWITCH	1	
13	F01	40210K740000	RIGHT HANDLEBAR GRIP	1	
14	F01	40080J04006Z	CLUTCH LEVER ASSY	1	
15	F01	40300N290000	THROTTLE CABLE ASSY	1	
16	F01	40400L430000	CLUTCH CABLE ASSY	1	
17	F01	40017J010000	CLUTCH CABLE RUBBER COVER	1	
18	F01	40084J040006	CLUTCH LEVER	1	
19	F01	40083K010000	MOUNTING BOLT,HANDLE	1	
20	F01	B0205060306H	SCREW M6×30	2	
21	F01	45083K010000	SPIRALTUBE,ADJUSTING	1	
22	F01	55064K010000	NUT	1	
23	F01	70190L430000	SPEEDOMETER ADJUST SWITCH	1	
24	F01	B0417060004H	NUT M6	1	
25	F01	49371T620000	CLIP,RUBBER	5	
26	F01	91090K010000	SWITCH, CLUTCH	1	


F02 前叉I FORK ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F02	B0205080256K	SCREW M8×25	4	
2	F02	43013P010000	UPPER HANDLEBAR HOLDER	2	For vehicle vin before LBBU32016KBA63976
2	F02	43013P010001	UPPER HANDLEBAR HOLDER	2	Start vin LBBU32016KBA63976
3	F02	43014P010000	LOWER HANDLEBAR HOLDER	2	
4	F02	40086P010002	HANDLE POSITIONING STUD	2	
5	F02	47015P010000	SILENCING PLUG	4	
6	F02	40089P010100	HANDLEBAR DOWEL WASHER φ10.2×φ24.9×2.5	2	
7	F02	B0417101254H	SELF-LOCKING NUT M10×1.25	2	
8	F02	08002K670000	SCREW M6×30	8	
9	F02	43049J000000	BOLT STEM FIXING M10×1.25×23	1	
10	F02	43044K230000	WASHER	1	
11	F02	43011L430000	UPPER BRACKET	1	
12	F02	43008L430000	LOCK NUT	1	
13	F02	43005G130000	DUST COVER	1	
14	F02	43001G130000	RACE,UPPER BEARING,UPPER	1	
15	F02	B06010140000	STEEL BALL 3/16"	22	
16	F02	43002G130000	RACE,UPPER BEARING,LOWER	1	
17	F02	43003N040000	RACE,UPPER,BOTTOM BEARING	1	
18	F02	B06010200000	STEEL BALL 1/4"	18	
19	F02	43004J000000	RACE,LOWER,BOTTOM BEARING	1	
20	F02	43100J800020	CROWN	1	
21	F02	B0109060126H	BOLT M6×12	1	
22	F02	B02830600862	BOLT M8×8	2	
23	F02	43035J300000	CLIP	1	
24	F02	B0109100166H	BOLT M10×16	1	
25	F02	43035J800000	CLIP	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
26	F02	B0109060606K	BOLT M6×60	1	
27	F02	08524P250000	HEADLIGHT BUFFER SETS	2	
28	F02	08523P250010	HEADLIGHT INSTALL SPACER	1	
29	F02	08333L430000	HEADLIGHT FIXING PLATE	1	
30	F02	B0109060166H	BOLT M6×16	2	
31	F02	B0407060005H	NUT M6	1	
32	F02	43200L430000	FRONT LEFT SHOCK ABSORBER ASSY.	1	
33	F02	43300L430000	FRONT RIGHT SHOCK ABSORBER ASSY.	1	
34	F02	B0109060126H	BOLT M6×12	4	
35	F02	08330L430000	HEADLIGHT BRACKET	1	
36	F02	58780L430000	HEADLIGHT MOUNTING BRACKET	1	
37	F02	B0109080126H	BOLT M8×12	2	
38	F02	86200L420000	FRONT SIDE REFLECTOR	2	
39	F02	43290D010000	DUST SEAL	2	
40	F02	43260K990000	OIL SEAL	2	
41	F02	B0205060256H	SCREW M6×25	2	
42	F02	08021P250000	WASHER	2	
46	F02	08021K020010	WASHER	1	

F03 前挡泥板 FRONT FENDER




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F03	65101L29033Z	FRONT FENDER, GREEN U6, WITH STICKER	1	
1	F03	65101L29034Z	FRONT FENDER, RED RB, WITH STICKER	1	
1	F03	65101L29035Z	FRONT FENDER, BLACK N4, WITH STICKER	1	
2	F03	B0284060150A	SCREW M6×15.2	6	
3	F03	B01591004065	BOLT M10×1.25×40	2	
4	F03	65108L290000	LEFT DECORATIVE BOARD	1	
5	F03	65116L290000	RIGHT DECORATIVE BOARD	1	
6	F03	65625J560000	CLIP NUT M6	2	
7	F03	B0283060146H	SCREW M6×14	2	
8	F03	08012P160000	BOLT M5×16	2	
9	F03	65105S040000	T BUSH 5×7×6×10×0.8	2	
10	F03	B0400050005H	NUT M5	2	
11	F03	65175L430000	SPEEDOMETER GEAR WIRE FIXING PLATE	1	
12	F03	65102P250000	LITTLE FENDER BEFORE	1	
13	F03	B0507420130H	TAPPING SCREW ST4.2×13	1	
14	F03	65801T020201	INSERT ST4.2	1	
15	F03	65130L290000	FRONT FENDER LEFT BRACKET I	1	
16	F03	65140L290000	FRONT FENDER RIGHTT BRACKET I	1	
17	F03	08001K670000	SCREW M6×16	4	
18	F03	65150J800200	FRONT FENDER LEFT BRACKET II	1	
19	F03	65160J800200	FRONT FENDER RIGHTT BRACKET II	1	
20	F03	43057K670000	CLIP	1	
21	F03	B0283060146H	SCREW M6×14	2	
22	F03	B0159100306H	BOLT M10×1.25×30	2	
24	F03	65113J000000	RUBBER RING	1	

F04_1 前液刹总成 FRONT BRAKE




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F04_1	45900J800216	FRONT DISC BRAKE ASSY	1	
2	F04_1	45400J800001	OIL PUMP ASSY.	1	
3	F04_1	45180J000000	WASHER	4	
4	F04_1	45037J000000	BRAKE HOSE BANJO BOLT	1	
5	F04_1	45200J800004	FR. BRAKE HOSE	1	
6	F04_1	45500J800001	FRONT CALIPER ASSY.RED,WITHOUT MARK	1	
7	F04_1	45120J800000	BRAKE PAD ASSY.	2	
8	F04_1	B02810602562	SCREW M6×25	2	
9	F04_1	45023K010000	COVER,FIX	1	
10	F04_1	45020J800000	FRONT BRAKE LEVER	1	
11	F04_1	B04170600055	NUT M6	1	
12	F04_1	45076K010010	BRAKE LEVER PIVOT BOLT	1	
13	F04_1	B02010401225	SCREW M4×12	1	
14	F04_1	45037P300000	BRAKE HOSE BANJO BOLT	1	
15	F04_1	45300J000010	BRAKE SWITCH	1	

F04_2 后液刹总成REAR BRAKE




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F04_2	55300J800001	REAR BRAKING SWITCH	1	
2	F04_2	55180J410000	WASHER	4	
3	F04_2	55400P100000	REAR MASTER CYLINDER ASSY	1	
4	F04_2	55200L430000	REAR BRAKE HOSE	1	
5	F04_2	55600J800103	REAR BRAKE CALIPER,RED	1	
6	F04_2	55037J410000	BRAKE HOSE BANJO BOLT	2	
7	F04_2	45110T400000	BRAKE PADS	1set	Qty/Package: 2
8	F04_2	B0109060126H	BOLT M6×12	1	
9	F04_2	55900L430000	REAR DISC BRAKE ASSY	1	
10	F04_2	57041V030001	TAMPER BRACKET	1	

F05 前轮 FRONT WHEEL ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F05	44004J800200	FRONT WHEEL AXLE M14×1.5×207	1	
2	F05	44016K740000	BUSH FRONT WHEEL ASSY RIGHT	1	
3	F05	44200K690000	SPEEDOMETER DRIVE ASSY	1	
4	F05	44023J000000	DRIVING PLATE	1	
5	F05	44230J000000	SEAL ASSY	1	
6	F05	B12016020200	BALL BEARING 6202-2RS	2	
7	F05	44600N210000	BUSH	1	
9	F05	44101N210000	FRONT RIM,BLACK	1	
9	F05	44101N21U600	FRONT RIM,GREEN U6	1	
10	F05	44300B910000	FRONT OIL SEAL ASSY	1	
11	F05	44005J800200	FRONT WHEEL LEFT COLLAR	1	
12	F05	45033L290000	FRONT BRAKE DISC	1	
13	F05	45036D010200	BOLT M6×16	6	
14	F05	B1403Z201100	AIR VALVE/RIM VALVE	1	

F06 消声器 MUFFLER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F06	47100L430121	MUFFLER ASSY,MARK:E9 QJ EX-L43A	1	
2	F06	47800P250000	EXHAUST PIPE GASKET ASSY	1	
3	F06	08051N030100	NUT M8	2	
4	F06	B0283060146H	SCREW M6×14	3	
5	F06	08022N050000	HEAT INSULATION WASHER	6	
6	F06	47023V030000	GUARD BOARD,MUFFLER	1	
7	F06	B01591004065	BOLT M10×1.25×40	1	
8	F06	31902V020000	OXYGEN SENSOR	1	
9	F06	47028H390000	RUBBER BUSH	1	
10	F06	47040H390100	T BUSH	1	
11	F06	60005N050000	NUT M10×1.25	1	
12	F06	47762V030000	REAR PROTECT COVER	1	

F07 空滤器 AIR CLEANER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F07	49100L430000	AIR FILTER ASSY	1	
2	F07	49016N070000	STAINLESS CLAMP 50	1	
3	F07	B0109060126H	BOLT M6×12	2	
4	F07	65625J560000	CLIP NUT M6	2	
5	F07	49858L430000	PIPE	1	
6	F07	49805G120000	CLAMP Φ14.5×12×0.8	2	
7	F07	49200L430000	AIR FILTER ASSY	1	


F08 油箱总成 FUEL TANK



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F08	50100L430000	FUEL TANK ASSY	1	
2	F08	B0280050300A	SCREW M5×30	3	
3	F08	B0280050140A	SCREW 5X14	2	
4	F08	08012P160000	BOLT M5×16	2	
5	F08	65624P160000	CARD NUT M5	2	
6	F08	B0109060356H	BOLT M6×35	2	
7	F08	08023J000100	FUEL TANK MOUNTING WASHER	8	
8	F08	50243L430000	BUFFER SPACER	2	
9	F08	50242L430000	BUFFER RUBBER	2	
10	F08	57080L430000	FUEL TANK REAR PRESSURE PLATE	1	
11	F08	50005P250000	RUBBER BUSH	4	
12	F08	50014P250010	RUBBER BUSH	4	
13	F08	B0109060256H	BOLT M6×25	4	
14	F08	50231L430000	FUEL TANK FRONT FIXING PLATE	1	
15	F08	B0109060256H	BOLT M6×25	2	
16	F08	50800L430000	FUEL SENSOR ASSY	1	
17	F08	50002K020000	FUEL LEVEL SENSOR RUBBER WASHER	1	
18	F08	B0407060005H	NUT M6	4	
19	F08	50400P100040	FUEL PUMP ASSY	1	
20	F08	B0109050166H	BOLT M5×16	6	
21	F08	50340N100001	FUEL FILTER	1	
22	F08	50391N070010	FUEL FILTER JACKET	1	
23	F08	50307J690000	CLAMP 14.5	2	
24	F08	50080L430000	TUBE	1	
25	F08	58430J000000	CLIP	1	
26	F08	49923L430000	TUBE	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
27	F08	B17010110003	WIRE CLAMP Φ11	5	
28	F08	49710N070000	CANISTER SOLENOID VALVE	1	
29	F08	49922L430000	TUBE	1	
30	F08	B17010125003	WIRE CLAMP Φ12.5	1	
31	F08	B17010085003	WIRE CLAMP Φ8.5	4	
32	F08	49910V300001	CANISTER ASSY	1	
33	F08	50260T730003	ROLL OVER SENSOR	1	
34	F08	49902L430000	TUBE	1	
35	F08	49905L430000	TUBE	1	
36	F08	50090L430000	TUBE	1	
37	F08	B16010726201	HOSE Φ7×11×620	1	


F09 后摆臂 REAR SWINGING ARM ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F09	58303L430000	PIVOT SHAFT M12×1.25×318	1	
2	F09	05583L350000	CHAIN ADJUSTING STICKER	1	
3	F09	54640L430000	SEAL RING 17×27×6	12	
4	F09	53006L430000	T BUSH	2	
5	F09	B0417121254H	SELF-LOCKING NUT M12×1.25	1	
6	F09	08013V030000	BOLT M10×67	1	
7	F09	53243L430000	NEEDLE BEARING 17×24×15	8	
8	F09	53242L430000	REAR SHOCK ABSORBER BUSH	4	
9	F09	B0417101254H	SELF-LOCKING NUT M10×1.25	5	
10	F09	53241L430000	REAR SHOCK ABSORBER ROCKER	1	
11	F09	08011L430000	BOLT	1	
12	F09	53244L430001	ROCKER CONNECT PLATE	2	
13	F09	63800L430000	REAR SHOCK ABSORBER ASSY	1	
14	F09	B0255100558H	SCREW M10×1.25×55	1	
15	F09	53004L430000	CHAIN SHIELD BLOCK	1	
16	F09	B0201060122H	SCREW M6×12	6	
17	F09	53056D010200	BUSH	6	
18	F09	60101L430000	DRIVE CHAIN COVER	1	
19A	F09	08013J020100	BOLT	1	
19B	F09	08012H010100	BOLT M6×20	1	
20	F09	B0109060166H	BOLT M6×16	1	
21	F09	08021K670000	WASHER Φ16×Φ32×2	2	
22	F09	53230L430100	LEFT CHAIN REGULATOR ASSY	2	
24	F09	53100L430000	SWING ARM ASSY	1	
25	F09	53018L430000	CHAIN REAR SHIELD BLOCK	1	
26	F09	08012V030000	BOLT M10×77	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
27	F09	08013V030000	BOLT M10×67	1	
28	F09	08011H010200	BOLT M6×14	2	
29	F09	53021P250000	BUSH	2	
30	F09	B02810602562	SCREW M6×25-8.8-ZG	2	


F10 后轮 REAR WHEEL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F10	54004L430000	REAR WHEEL SHAFT M14×1.25×318	1	
2	F10	54016L430000	REAR WHEEL LEFT COLLAR	1	
3	F10	60200J000001	DUST SEAL ASSY	1	
4	F10	B12016020400	BALL BEARING 6204-2RS	1	
5	F10	60006L430000	REAR WHEEL AXLE SLEEVE	1	
6	F10	B0417101254H	NUT M10×1.25	6	
7	F10	60002M500001	SPROCKET WHEEL 46 TOOTH	1	
8	F10	B1502S1124B0	CHAIN 428HO-1×124	1	
9	F10	60001L430000	REAR WHEEL DRIVE HUB	1	
10	F10	60015L430000	BOLT M10×1.25×55	6	
11	F10	54024N210000	REAR WHEEL DRIVE HUB DAMPER	6	
12	F10	B12016020200	BALL BEARING 6202-2RS	1	
13	F10	54006J800000	REAR WHEEL SPACER	1	
14	F10	B12016030200	BALL BEARING 6302-2RS	1	
15	F10	B1403Z201100	AIR VALVE/RIM VALVE	1	
16	F10	B1404Z2011A0	CAP, VALVE	1	
17	F10	54101N210000	REAR RIM, BLACK	1	
17	F10	54101N21U600	REAR RIM, GREEN U6	1	
19	F10	44300J040000	FRONT WHEEL RIGHT OIL SEAL ASSY, CORDIAL	1	
20	F10	54005L290200	REAR WHEEL RIGHT COLLAR	1	
21	F10	55033L430000	REAR BRAKE DISC	1	
22	F10	45036D010200	BOLT M6×16	6	
23	F10	55410L430000	REAR BRAKE CALIPER MOUNTING BRACKET ASSY	1	
24	F10	B0700000100H	SPRING WASHER 10	2	
25	F10	B01090602065	BOLT M6×20	3	
26	F10	B0255100186H	SCREW M10×18	2	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
27	F10	B0417141504H	SELF-LOCKING NUT M14×1.25	1	
28	F10	65761L43BG01	REAR FENDER UNDER PART,MATT BLACK BG	1	
29	F10	51076J410100	BUSH	3	
30	F10	B0703000100H	WASHER 10	2	


F12 车架 FRAME BODY



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F12	57100L43BG03	FRAME ASSY	1	
2	F12	58306V030100	ENGINE MOUNTING SHAFT M10×124	1	
3	F12	B0417101254H	SELF-LOCKING NUT M10×1.25	1	
4	F12	65570L430000	LEFT COWLING	1	
5	F12	B0109080166H	BOLT M8×16	4	
6	F12	65580L430000	LEFT FIXING PLATE	1	
7	F12	58305L430000	ENGINE MOUNTING SHAFT M10×1.25×134	1	
8	F12	57020L430000	ENGINE LEFT MOUNTING PLATE	1	
9	F12	B0255100186H	SCREW M10×1.25×18	4	
10	F12	B01591007562	BOLT M10×1.25×75	1	
11	F12	B0417101254H	SELF-LOCKING NUT M10×1.25	2	
12	F12	57030L430000	ENGINE RIGHT MOUNTING PLATE	1	
13	F12	B0109060126H	BOLT M6×12	7	
14	F12	58750L430002	BATTERY FIXING BRACKET	1	
15	F12	58752P250000	BATTERY SPONGE CUSHION	5	
16	F12	58900L430000	SEAT LOCK CABLE ASSY	1	
18	F12	58741L430000	BATTERY PRESSURE PLATE	1	
19	F12	B0201060252H	SCREW M6×25	2	
20	F12	57410L430000	SEAT SUPPORT PLATE	1	
21	F12	58761L430000	TOOL KIT BOX BRACKET	1	
23	F12	57437L430000	FLASHER FIXING PLATE	1	
24	F12	51103L430000	BUFFER RUBBER	1	
25	F12	57015N140000	PLUG	2	
26	F12	57400L430000	STARTER RELAY FIXING BRACKET	1	
28	F12	B0702000060H	WASHER 6	1	
31	F12	B0703000100H	WASHER 10	4	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
32	F12	B10000300600	RIVET 3×6	2	
33	F12	40022L430000	WIRE CLIP	1	
34	F12	08011P160000	SCREW M5×12	2	
35	F12	B0283060146H	SCREW M6×14	1	


F13 中撑/单撑 MAIN & SIDE STAND ASSY & 脚蹬 PEDAL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F13	58700L430000	SIDE STAND ASSY	1	
2	F13	57005B410101	SIDE STAND BOLT M8×35.5	1	
3	F13	57010J830000	SIDE STAND SPRING	1	
4	F13	B0402080001H	NUT M8	1	
5	F13	B0226080206H	SCREW M8×20	2	
6	F13	58451L430000	LEFT FOOTREST BRACKET PLATE	1	
7	F13	52018J800000	SCREW M8×25	4	
8	F13	58211L430000	LEFT FOOTREST DECORATIVE PLATE	1	
9	F13	B02810602062	BOLT M6×1×20	4	
10	F13	58220L430000	LEFT FRONT FOOTREST ASSY.	1	
11	F13	08370L430000	SHIFT PEDAL	1	
12	F13	40706S040000	M6 LEFT SECTION HEAD	1	
13	F13	B0109060166H	BOLT M6×16	1	
14	F13	08371L430000	SHIFT ROD	1	
15	F13	08375S010000	SECTION HEAD	1	
16	F13	B0417060004H	SELF-LOCKING NUT M6	2	
17	F13	47033T430100	MUFFLER GUARD PLATE INSTALLATION SPACER	1	
18	F13	08386P100001	SHIFT PEDAL MOUNTING BRAK CET	1	
19	F13	B0109060356H	BOLT M6×35	2	
20	F13	58213L430000	PEDAL MOUNTING SHAFT	2	
21	F13	08352S020000	LEFT PEDAL RUBBER	1	
22	F13	58266S010000	LEFT REAR FOOTREST	1	
23	F13	58222B930000	PEDAL SPRING	2	
24	F13	B06000002000	PEDAL BALL	2	
25	F13	58203L430000	PEDAL LIMIT PLATE	2	
26	F13	B0882000050A	CIRCLIP φ5	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
27	F13	B0280040100A	SCREW M4×10	2	
28	F13	58205S020000	LEFT PEDAL RUBBER PAD IS	1	
29	F13	08372S020000	RUBBER PEDAR RIGHT	1	
30	F13	58286S010000	RIGHT REAR PEDAL	1	
31	F13	58405S020000	RUBBER PEDAR RIGHT	1	
32	F13	58471L430000	RIGHT FOOTREST BRACKET PLATE	1	
33	F13	58311L430000	RIGHT FOOTREST DECORATIVE PLATE	1	
34	F13	55061L290000	BRAKE PUSH ROD	1	
35	F13	40283S010000	SECTION HEAD M6	1	
36	F13	40710L430000	BRAKE PEDAL ASSY	1	
37	F13	40702L290000	BRAKE SPRING	1	
38	F13	58240L430000	RIGHT FRONT PEDAL ASSY	1	
39	F13	B0109060256H	BOLT M6×25	1	
40	F13	08051S040010	LEFT NUT M6	2	
41	F13	B02810602062	BOLT M6×1×20	1	
42	F13	08023P250000	WASHER Φ10.5×Φ19×0.8	2	

F14 导流罩总成 FRONT COVER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F14	65203L43B200	METER VISOR,BLACK B2	1	
2	F14	08011P160000	SCREW M5×12	2	
3	F14	65202L430000	INSTRUMENT COVER	1	
4	F14	70000L430000	METER ASSY	1	
5	F14	B0507420130H	TAPPING SCREW ST4.2×13	8	
6	F14	65801T020201	INSERT ST4.2	8	
7	F14	65501L430000	COWLING	1	
8	F14	81100L430000	FRONT LEFT TURN SIGNAL LIGHT	1	
9	F14	81065L430000	SCREW	2	
10	F14	65521L430000	LEFT COWLING DECORATIVE PLATE	1	
11	F14	65506L43B200	LEFT COWLING,GRAPHITE BLACK B2,WITHOUT STICKER	1	
12	F14	80000L430010	HEAD LIGHT	1	
13	F14	65531L430000	RIGHT COWLING DECORATIVE PLATE	1	
14	F14	65507L43B200	RIGHT COWLING,GRAPHITE BLACK B2,WITHOUT STICKER	1	
15	F14	81300L430000	FRONT RIGHT TURN SIGNAL LIGHT	1	
16	F14	B01070601263	BOLT M6×12	2	
17	F14	B0507420101H	TAPPING SCREW ST4.2×10	2	


F15 油箱护板 FUEL TANK PROTECTOR COVER



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F15	50015L43009Z	FUEL TANK LEFT SIDE COVER, GREEN U6, WITH STICKER	1	
1	F15	50015L43010Z	FUEL TANK LEFT SIDE COVER, RED RB, WITH STICKER	1	
1	F15	50015L43011Z	FUEL TANK LEFT SIDE COVER, BLACK N4, WITH STICKER	1	
2	F15	50016L43009Z	FUEL TANK RIGHT SIDE COVER, GREEN U6, WITH STICKER	1	
2	F15	50016L43010Z	FUEL TANK RIGHT SIDE COVER, RED RB, WITH STICKER	1	
2	F15	50016L43011Z	FUEL TANK RIGHT SIDE COVER, BLACK N4, WITH STICKER	1	
3	F15	B0284060200A	SCREW M6×20	2	
4	F15	65616L430000	RUBBER CUSHION	12	
5	F15	65517J900001	HEADLIGHT BRACKET BUSH	10	
6	F15	50018G530000	RUBBER SLEEVE	2	
7	F15	65672L43N400	FUEL TANK MID COVER, BLACK N4	1	
8	F15	08012P160000	BOLT M5×16	16	
9	F15	65624P160000	CARD NUT M5	16	
10	F15	B0507420130H	TAPPING SCREW ST4.2×13	38	
11	F15	65801T020201	INSERT ST4.2	12	
12	F15	65671L430000	FUEL TANK FRONT DECORATIVE PLATE	1	
13	F15	65675L43009Z	FUEL TANK LEFT FRONT SIDE COVER, GREEN U6, WITH STICKER	1	
13	F15	65675L43010Z	FUEL TANK LEFT FRONT SIDE COVER, RED RB, WITH STICKER	1	
13	F15	65675L43011Z	FUEL TANK LEFT FRONT SIDE COVER, BLACK N4, WITH STICKER	1	
14	F15	65676L43009Z	FUEL TANK RIGHT FRONT SIDE COVER, GREEN U6, WITH STICKER	1	
14	F15	65676L43010Z	FUEL TANK RIGHT FRONT SIDE COVER, RED RB, WITH STICKER	1	
14	F15	65676L43011Z	FUEL TANK RIGHT FRONT SIDE COVER, BLACK N4, WITH STICKER	1	
15	F15	81900L430001	FRONT LEFT CITY LIGHT	1	
16	F15	83900L430001	FRONT RIGHT CITY LIGHT	1	
17	F15	08012P160000	SCREW M5×16	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
18	F15	65681L430000	FUEL TANK LEFT LOWER SIDE COVER	1	
19	F15	65682L430000	FUEL TANK RIGHT LOWER SIDE COVER	1	
20	F15	B0284060200A	SCREW M6×20	4	
21	F15	65677L430000	LEFT FRONT DECORATIVE PLATE	1	
22	F15	65678L430000	RIGHT FRONT DECORATIVE PLATE	1	
23	F15	65683L430000	LEFT GUIDE TUYERE	1	
24	F15	65684L430000	RIGHT GUIDE TUYERE	1	
25	F15	65673L430000	LEFT INNER DECORATIVE PLATE	1	
26	F15	65674L430000	RIGHT INNER DECORATIVE PLATE	1	
27	F15	B0284060250A	SCREW M6×25	2	
28	F15	65406L43007Z	LEFT BOTTOM COVER,BLACK B2,U6,WITH STICKER	1	
28	F15	65406L43008Z	LEFT BOTTOM COVER,BLACK B2,RB,WITH STICKER	1	
28	F15	65406L43009Z	LEFT BOTTOM COVER,BLACK B2,N4,WITH STICKER	1	
29	F15	65407L43007Z	RIGHT BOTTOM COVER,BLACK B2,U6,WITH STICKER	1	
29	F15	65407L43008Z	RIGHT BOTTOM COVER,BLACK B2,RB,WITH STICKER	1	
29	F15	65407L43009Z	RIGHT BOTTOM COVER,BLACK B2,N4,WITH STICKER	1	
30	F15	65436L430000	BOTTOM COVER CONNECT PLATE	1	
31	F15	B0284060250A	SCREW M6×25	2	
32	F15	65306L430000	STEEL NET	2	
33	F15	65305L430000	STEEL NET	2	
34	F15	82038J800000	CLIP	10	
35	F15	50026L430000	T RUBBER	2	
36	F15	65627J410100	SPACER,SIDE COVER	2	
37	F15	B0284060200A	SCREW M6×20	2	
38	F15	65517J900001	HEADLIGHT BRACKET BUSH	2	

F16 护板 SIDE COVER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F16	65601L43001Z	LEFT SIDE COVER,BLACK B2,WITH STICKER	1	
2	F16	65602L43001Z	RIGHT SIDE COVER,BLACK B2,WITH STICKER	1	
3	F16	B0284060250A	SCREW M6×25	2	
4	F16	65517J900001	HEADLIGHT BRACKET BUSH	4	
5	F16	65616L430000	RUBBER CUSHION	4	
6	F16	65621L430000	LEFT SIDE COVER DECORATIVE PLATE	1	
7	F16	65623L430000	RIGHT SIDE COVER DECORATIVE PLATE	1	
8	F16	08012P160000	SCREW M5×16	4	
9	F16	65801T020201	INSERT ST4.2	6	
10	F16	65901L43018Z	LEFT TAIL COVER,BLACK B2,U6,WITH STICKER	1	
10	F16	65901L43019Z	LEFT TAIL COVER,BLACK B2,WF-RB-N4,WITH STICKER	1	
11	F16	65902L43018Z	RIGHT TAIL COVER,BLACK B2,U6,WITH STICKER	1	
11	F16	65902L43019Z	RIGHT TAIL COVER,BLACK B2,WF-RB-N4,WITH STICKER	1	
12	F16	50018G530000	RUBBER SLEEVE	2	
13	F16	65606L43B200	TAIL COVER CONNECT PLATE,BLACK B2,U6-WF-N4-RB	1	
14	F16	51100L430000	FRONT SEAT	1	
15	F16	51200L430100	REAR SEAT	1	
16	F16	82038J800000	CLIP	4	
17	F15	65307L430000	STEEL NET	2	
18	F16	B0284060200A	SCREW M6×20	4	
19	F16	B0507420101H	TAPPING SCREW ST4.2×10	2	
20	F16	B02810602562	SCREW M6×25	2	

F17 后挡泥板 REAR FENDER ASSY



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F17	65731L430000	REAR FENDER FORESIDE	1	
2	F17	B0109060126H	BOLT M6×12	2	
3	F17	65625J560000	CLIP NUT M6	2	
4	F17	08012P160000	SCREW M5×16	4	
5	F17	65624P160000	CARD NUT M5	4	
6	F17	82000L430000	TAIL LIGHT	1	
7	F17	65713H160000	RUBBER SLEEVE I	1	
8	F17	65770L43CJ00	REAR FENDER BRAKCET,SILVER CJ	1	
9	F17	B01090602065	BOLT M6×20	2	
10	F17	65711L430000	REAR FENDER UPPER SPACER	4	
11	F17	65701V020000	REAR FENDER	1	
12	F17	82900B470002	REAR LICENSE PLATE LIGHT	1	
13	F17	B0500420160H	TAPPING SCREW ST4.2×16	1	
14	F17	B0284060250A	SCREW M6×25	4	
15	F17	08252V020000	REAR LICENSE FIXING PLATE	1	
16	F17	58507K670000	BUFFER BLOCK MAIN STAND	1	
17	F17	86500V020000	REAR REFLECTOR	1	
18	F17	81500L430000	REAR LEFT TURN SIGNAL LIGHT	1	
19	F17	81700L430000	REAR RIGHT TURN SIGNAL LIGHT	1	
20	F17	B0507420130H	TAPPING SCREW ST4.2×13	2	
21	F17	65801T020201	INSERT ST4.2	2	


F18 RADIATOR SYSTEM ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1A	F18	279124460040	RADIATOR ASSY	1	Start vin LBBU32012KBA14659 For water temperature switch 98°C
2	F18	B0109060256H	BOLT M6×25	4	
3	F18	06106P250000	CLAMP 27.1-706R	2	
4	F18	06211L430000	INLET HOSE	1	
5	F18	06251L430000	OUTLET HOSE	1	
6	F18	59510L430000	RADIATOR LOWER FIXING PLATE	1	
7	F18	280756030001	THROTTLE POSITION SENSOR	1	
8A	F18	279115050000	WATER TEMPERATURE SWITCH 98°C	1	Start vin LBBU32012KBA14659, 98°C
9	F18	B0109060126H	BOLT M6×12	1	
10	F18	58430J000000	CLIP	2	
11	F18	50306J690000	WIRE CLAMP Φ12.5	1	
12	F18	06223L430000	OVER FLOW PIPE	1	
13	F18	B17010110003	WIRE CLAMP Φ11	1	
14	F18	14039S040000	GUIDE TUBE	1	
15	F18	14030S040000	VICE WATER TANK COVER	1	
16	F18	43038P250000	RUBBER BUSH	1	
17	F18	06107L430000	COOLANT RESERVE TANK OVER FLOW PIPE	1	
18	F18	06111L430000	INFLATION KETTLE	1	
19	F18	06113L430000	INFLATION KETTLE PROTECT JACKET	1	
20	F18	65616L430000	RUBBER CUSHION	2	
21	F18	65517J900001	HEADLIGHT BRACKET BUSH	2	
22	F18	65550L430000	LEFT COWLING FRONT FIXING PLATE	1	
23	F18	65560L430000	RIGHT COWLING FRONT FIXING PLATE	1	
24	F18	06226P250000	OVER FLOW PIPE	1	
25	F18	16904441BY01	LEFT REAR COVER ASSY,MATT BLACK	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
26	F18	B0107060286H	BOLT M6×28	2	
27	F18	49016N250000	CLIP Φ15.5×10×1	2	
28	F18	289004320030	THROTTLE BODY ASSY	1	
29	F18	280024320000	STEPPER MOTOR	1	
30	F18	06203L430001	RUBBER	1	
31	F18	06104N220001	CLIP Φ24×12×1.5	2	
32	F18	279185050000	CAP,WATER TANK,SILVER	1	
33	F18	43070J670010	WIRE CLIP	1	
34	F18	C2446014HT00	COMPLETE ENGINE	1	


F19 电器 ELECTRICAL EQUIPMENT ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F19	95100T750000	HORN	1	
2	F19	B0109060126H	BOLT M6×12	1	
3	F19	96200U320000	IGNITION COIL	1	
4	F19	08012P160000	SCREW M5×16	4	
5	F19	94100T850000	STARTER RELAY	1	
6	F19	B0400060005H	NUT M6	2	
7	F19	96200V030000	IGNITION COIL	1	
8	F19	299064010000	RECTIFIER.	1	
9	F19	91170N070000	SIDE STAND SWITCH	1	
10	F19	B0205050166H	SCREW M5×16	2	
11	F19	94400N140000	HEADLIGHT RELAY CONTROLLER	1	
12	F19	96C00P100J01	ECU	1	
13	F19	65625J560000	CLIP NUT M6	2	
14	F19	B0284060190A	SCREW M6×19.2	2	
15	F19	96400H390001	FLASHER	1	
16	F19	96007B720001	JACKET,FLASHER	1	
17	F19	96700K060000	START DIODE	2	
18	F19	92000L430002	MAIN WIRE HARNESS	1	Before Vin LBBU32019LBB76998
18	F19	92000L430006	MAIN WIRE HARDNESS	1	Start Vin LBBU32019LBB76998
19	F19	289035210000	FUEL INJECTOR	1	
20	F19	88000L430000	LOCK ASSY	1	Parent Part
21	F19	B0207080168H	SCREW M8×16	2	
22	F19	96100V030000	BATTERY	1	
23	F19	02200J0000A0	BATTERY BELT ASSY	1	
24	F19	96004W020010	BAND	1	
25	F19	B0205050166H	SCREW M5×16	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
26	F19	289044460000	INJECTION HOUSING	1	
27	F19	88100L430000	POWER LOCK	1	Child Part of 88000L430000 (item F19-20)
28	F19	88400L430000	FUEL TANK LOCK	1	Child Part of 88000L430000 (item F19-20)
29	F19	88800P250000	SEAT LOCK	1	
30	F19	88900L43090X	KEY NUT	1	
31	F19	B0702000060H	WASHER 6	2	
32	F19	B0700000060H	SPRING WASHER 6	2	
33	F19	92940P100000	OBD WIRE	1	
34	F19	40098B450000	BAND 3×150	16	
35	F19	96C21L290000	ECU WATERPROOF COVER	1	
36	F19	96003P250000	RUBBER CLIP	1	
37	F19	58800P250000	BASE SEAT LOCK REAR	1	
38	F19	96003J000000	BAND 250MM	5	
39	F19	B01090602065	BOLT M6×20	2	
40	F19	94100J800000	RELAY	2	
43	F19	96001N350000	BAND	1	

F20 随车工具 TOOL KIT ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F20	02100B420000	TOOL KIT ASSY	1	

F26 STICKER, FOR GREEN U6 VEHICLE




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F26	05535M620001	STICKER,FUEL TANK SIDE COVER,RIGHT,REAR,U6	1	
2	F26	05534M620001	STICKER,FUEL TANK SIDE COVER,LEFT,REAR,U6	1	
3	F26	05582L43U601	RIM STICKER,U6	4	
4	F26	05511M620001	STICKER,LEFT&RIGHT SIDE COVER,U6	2	
5	F26	05501M62U601	STICKER,FRONT FENDER,U6	1	
6	F26	05533M62U601	BENELLI STICKER,U6	2	
7	F26	05572L43U601	150S STICKER,RIGHT TAIL COVER,U6	1	
8	F26	05571L43U601	150S STICKER,LEFT TAIL COVER,U6	1	
9	F26	05532M62U601	FUEL TANK RIGHT FRONT STICKER,U6	1	
10	F26	05531M62U601	FUEL TANK LEFT FRONT STICKER,U6	1	
11	F26	05542M62U601	STICKER,RIGHT BOTTOM COVER,U6	1	
12	F26	05541M62U601	STICKER,LEFT BOTTOM COVER,U6	1	
13	F26	05543L43U601	150 STICKER,ENGINE RIGHT UNDER COVER,U6	1	
14	F26	05542L43U601	150 STICKER,ENGINE LEFT UNDER COVER,U6	1	

F27 STICKER, FOR RED RB VEHICLE




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F27	05535M620001	STICKER,FUEL TANK SIDE COVER,RIGHT,REAR,RB	1	
2	F27	05534M620001	STICKER,FUEL TANK SIDE COVER,LEFT,REAR,RB	1	
3	F27	05582L43RB01	RIM STICKER,RB	4	
4	F27	05511M620001	STICKER,LEFT&RIGHT SIDE COVER,RB	2	
5	F27	05501M62RB01	STICKER,FRONT FENDER,RB	1	
6	F27	05533M62RB01	BENELLI STICKER,RB	2	
7	F27	05572L43RB01	150S STICKER,RIGHT TAIL COVER,RB	1	
8	F27	05571L43RB01	150S STICKER,LEFT TAIL COVER,RB	1	
9	F27	05532M62RB01	FUEL TANK RIGHT FRONT STICKER,RB	1	
10	F27	05531M62RB01	FUEL TANK LEFT FRONT STICKER,RB	1	
11	F27	05542M62RB01	STICKER,RIGHT BOTTOM COVER,RB	1	
12	F27	05541M62RB01	STICKER,LEFT BOTTOM COVER,RB	1	
13	F27	05543L43U601	150 STICKER,ENGINE RIGHT UNDER COVER,RB	1	
14	F27	05542L43U601	150 STICKER,ENGINE LEFT UNDER COVER,RB	1	

F28 STICKER, FOR BLACK N4 VEHICLE



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F28	05535M620001	STICKER,FUEL TANK SIDE COVER,RIGHT,REAR,N4	1	
2	F28	05534M620001	STICKER,FUEL TANK SIDE COVER,LEFT,REAR,N4	1	
3	F28	05582L43RB01	RIM STICKER,N4	4	
4	F28	05511M620001	STICKER,LEFT&RIGHT SIDE COVER,N4	2	
5	F28	05501M62WF01	STICKER,FRONT FENDER,N4	1	
6	F28	05533M62WF01	BENELLI STICKER,N4	2	
7	F28	05572L43RB01	150S STICKER,RIGHT TAIL COVER,N4	1	
8	F28	05571L43RB01	150S STICKER,LEFT TAIL COVER,N4	1	
9	F28	05532M62N401	FUEL TANK RIGHT FRONT STICKER,N4	1	
10	F28	05531M62N401	FUEL TANK LEFT FRONT STICKER,N4	1	
11	F28	05542M62N401	STICKER,RIGHT BOTTOM COVER,N4	1	
12	F28	05541M62N401	STICKER,LEFT BOTTOM COVER,N4	1	
13	F28	05543L43U601	150 STICKER,ENGINE RIGHT UNDER COVER,N4	1	
14	F28	05542L43U601	150 STICKER,ENGINE LEFT UNDER COVER,N4	1	


E01 CYLINDER HEAD (气缸盖、气缸盖罩分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E01	B0107060206H	BOLT M6×20	9	
2	E01	150013070000	WASHER 6	1	
3	E01	109014470010	CYLINDER HEAD COVER COMP,GREY	1	
4	E01	109024460000	RUBBER SEALS	1	
5	E01	280596090000	COOLANT TEMPERATURE SENSOR	1	
7	E01	AC-005-1201-0009	SPARK PLUG	1	
8	E01	120015090000	VALVE STEM SEAL	4	
9	E01	AC-005-1201-0009	SPARK PLUG	2	
10	E01	109054460010	CYLINDER HEAD ASSY,GREY	1	
11	E01	150013070000	WASHER 6	2	
12	E01	B01070601263	BOLT M6×12	1	
13	E01	B0300080206H	STUDS M8×20	2	
14	E01	109074460000	CYLINDER HEAD GASKET	1	Three layers For 125CC: Start vin LBBU32016KBA63976
15	E01	100084460000	CYLINDER HEAD BOLT	2	
16	E01	100014460000	CYLINDER HEAD BOLT	2	
17	E01	17001305011X	BOLT M6×100	2	
18	E01	100054460000	WASHER 8	4	
19	E01	279165050000	THERMOSTAT ASSY	1	
20	E01	100094460001	THERMOSTAT COVER,GREY	1	
21	E01	B0107060106H	BOLT M6×10	1	
22	E01	B0107060186H	BOLT M6×18	1	
23	E01	290016250000	TEMPERATURE SENSOR,INTAKE	1	
24	E01	109154460000	HEAT INSULATION BODY	1	
25	E01	B190103000A0	O-RING	2	
26	E01	119014470000	INLET AIR DUCT	1	
27	E01	110043090004	CLAMP ASSY	1	
28	E01	120073050020	STUD BOLT	2	
29	E01	B0407060005H	NUT M6	2	
30	E01	200086030000	DOWEL PIN Φ8×8	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
31	E01	B0107060256H	BOLT M6×25	2	
32	E01	150084230000	PIPE	1	
33	E01	100024460011	CHAIN WHEEL COVER,GREY	1	
34	E01	100034460000	SEAL RING,CHAIN WHEEL COVER	1	
35	E01	100064460000	BREATHING ROOM COVER	1	
36	E01	100434460000	GASKET	1	
37	E01	B1308040100H	SCREW W/WASHER M4×10	4	
38	E01	150283070000	O-RING	1	
39	E01	100044460000	SPARK PLUG COVER	1	
40	E01	120202140000	O-RING	1	
41	E01	B08000002800	CIRCLIP	1	
42	E01	B0201050106H	SCREW M5×10	2	
43	E01	100074460000	BACK PLATE,ROCKER ARM SHAFT	1	
44	E01	280756030001	THROTTLE POSITION SENSOR	1	
45	E01	289004320030	THROTTLE BODY ASSY	1	
46	E01	280024320000	STEPPER MOTOR	1	

E02 VALVE MECHANISM SUB-ASSEMBLY (配气机构分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit		Remark
1	E02	129314460000	INTAKE ROCKER ARM	1	New	
2	E02	129324460000	EXHAUST ROCKER ARM	1	New	
3	E02	129164410000	ROCKER ARM SHAFT	2		
4	E02	129202290000	RETAINER,VALVE SPRING	4		
5	E02	129225090000	VALVE COTTER	8		
6	E02	129254410000	VALVE SPRING	4		
7	E02	129212290000	VALVE LOWER SPRING SEAT	4		
8	E02	129194460000	EXHAUST VALVE	2		
9	E02	129184460000	INTAKE VALVE	2		
10	E02	129094460000	CAMSHAFT ASSY.	1		
11	E02	129034410000	SPROCKET	1		
11A	E02	120034410010	SPROCKET	1	start vin ZBNL43003KBB25016	
12	E02	100424460000	RUBBER PLUG	1		
13	E02	100414460000	BAFFLE	1		
13A	E02	129264460000	BAFFLE	1	start vin ZBNL43003KBB25016	
14	E02	120014410010	BOLT	1		
15	E02	120054460000	WASHER 21×8.2×2.4	1	start vin ZBNL43003KBB25016	
16	E02	120044410010	REDUCED PRESSURE PINE	1	start vin ZBNL43003KBB25016	

E03 STRAINER UNIT ASSEMBLY (正时传动机构分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E03	B0107060206H	BOLT M6X20	2	
2	E03	14005305001X	TENSIONER BOLT	1	
3	E03	210043050000	O-RING	1	
4	E03	149033140080	TENSIONER ASSY,GREY	1	
5	E03	140013050040	GASKET	1	
6	E03	149014410000	REAR CHAIN GUIDE ASSY.	1	
7	E03	140053630000	PIVOT, CAM CHAIN TENSIONER	1	
8	E03	149024410000	FRONT CHAIN GUIDE	1	
9	E03	140023140010	OIL PUMP DRIVE CHAIN	1	

E04 PISTON,CONNECTING ROD & CRANKSHAFT ASSY (活塞连杆曲轴平衡轴分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E04	17009309003Z	PISTON RING	1	
2	E04	179134410021	PISTON	1	
3	E04	149144100000	PISTON PIN	1	
4	E04	179153090000	PISTON PIN CLIP	2	
5	E04	B11120404028	STRAIGHT KEY	1	
6	E04	179274410010	BALANCER GEAR ASSY	1	
7	E04	170034410010	BUSH	1	
8	E04	170204410010	DAMPING BLOCK	6	
9	E04	170194410010	DAMPING SPRING	6	
10	E04	179284410010	BALANCE SHAFT DRIVE GEAR	1	
11	E04	170144410000	DISC SPRING	1	
13	E04	269063090000	OIL PUMP DRIVE GEAR	1	
14	E04	170023090000	LOCK WASHER	1	
15	E04	170013090100	NUT M16X1.5	1	
16	E04	170065150110	NUT M14X1	1	
17	E04	170024320000	CONICAL WASHER	1	
18	E04	179264410000	BALANCE SHAFT GEAR	1	
19	E04	B11130040008	KEY 4×8	1	
20	E04	179254410000	BALANCE SHAFT	1	
21	E04	179014410000	CRANKSHAFT ASSY	1	
22	E04	B11810305013	WOODRUFF KEY	1	
23	E04	260092140100	NUT M10×1.25	1	

E05 CYLINDER ASSY (气缸体分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E05	150083070000	DOWEL PIN	2	
2	E05	139054410000	RUBBER PLUG	1	
3	E05	279085150000	INLET HOSE	1	
4	E05	B01070601263	BOLT M6X12	1	
5	E05	150013070000	WASHER 6	1	
6	E05	139014540010	CYLINDER COMP,GREY	1	Three layers For 125CC: Start vin LBBU32016KBA63976
6	E05	13901446HT01	CYLINDER COMP,GREY	1	
7	E05	139024410010	CYLINDER GASKET	1	

E06 LEFT CRANKCASE ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E06	150024410010	LEFT CRANKCASE ASSY,GREY	1	
2	E06	B0107060756H	BOLT M6X75	7	
3	E06	210373090000	OIL SEA 12X22X9	1	
4	E06	B0107060606H	BOLT M6X60	3	
5	E06	B0107060806H	BOLT M6X80	1	
6	E06	B0205050166H	SCREW M5X16	2	
7	E06	159124410000	GEARSHIFT SENSOR	1	
8	E06	B190102030B0	O-RING 20.3X2.65	1	
11	E06	210073090000	OIL SEAL 27X40X6	1	
12	E06	210093090000	OIL SEAL COVER	1	
13	E06	B0103060106H	BOLT M6X10	2	
14	E06	B0107060146H	SCREW M6X14	2	
15	E06	159134410000	CLUTCH WIRE GUIDE BRACKET	1	
16	E06	B1212K121002	NEEDLE ROLLER BEARING 12X16X10	1	
17	E06	200001050000	OIL SEAL	1	
18	E06	B080000020AA	CIRCLIP 20	1	
19	E06	130023090000	PIN	2	
20	E06	B12016020410	BALL BEARING 6204	1	
21	E06	B12016000204	BEARING 6002-Z	1	
22	E06	B12016020314	BALL BEARING 6203	1	
23	E06	B0201060126H	SCREW M6X12	2	
24	E06	150113090000	BLOCK PLATE	1	

E07 RIGHT CRANKCASE ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E07	150034410010	RIGHT CRANKCASE ASSY,GREY	1	
2	E07	B12016190503	BEARING 61905	1	
3	E07	B12016030501	BALL BEARING	1	
4	E07	150083070000	DOWEL PIN	2	
5	E07	150113090000	BLOCK PLATE	1	
6	E07	B0201060126H	SCREW M6X12	2	
7	E07	B12016020211	BALL BEARING	1	
8	E07	B12016020314	BALL BEARING 6203	1	
9	E07	B12016020410	BALL BEARING 6204	1	
10	E07	150166090010	CONE PLUG M10×1	2	For Vin behind LBBU32009JB895167
11	E07	B0107060706H	BOLT M6X70	1	
12	E07	159336190000	PLUG	1	
13	E07	B0107060656H	BOLT M6X65	1	
16	E07	21010405002X	LIMIT BLOCK NAIL	1	
18	E07	150126030100	RIVET 3X13	1	
19	E07	150045050000	HOSE	1	
20	E07	150105050000	SIEVE ASSY	1	
21	E07	150195050000	SPRING	1	
22	E07	150205040000	O RING II	1	
23	E07	150215040000	DRAIN PLUG	1	

E08 RIGHT COVER ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E08	16910446HT01	RIGHT COVER,GREY	1	
2	E08	169114410010	RIGHT COVER GASKET	1	
3	E08	160056030000	DOWEL PIN	2	
4	E08	B0107050086H	BOLT M5X8	2	
5	E08	160034410000	SEAL PLATE	1	
6	E08	160023090000	OIL SEAL	1	
7	E08	B190101700C0	O-RING 17X3.55	1	
8	E08	160024460010	OIL FILLER PLUG,GREY	1	
9	E08	06106P250000	CLAMP 27.1-706R	2	
10	E08	279094460000	OUTLET HOSE	1	
12	E08	B190101250A0	O-RING	1	
13	E08	B0107060356H	BOLT M6X35	10	
14	E08	B190105260B0	O-RING	1	
15	E08	160014410010	OIL FILTER COVER,GREY	1	
16	E08	B0300060126H	STUB BOLT M6X12	2	
17	E08	B0422060003H	NUT M6	2	
18	E08	B0107060906H	BOLT M6×90	1	
19	E08	160123420030	ENGINE SIDE COVER PLATE,MARK:Benelli	1	
20	E08	160033090000	SPRING	1	
21	E08	160043090000	FILTER	1	
22	E08	160083090000	OIL LEVEL INDICATOR	1	
23	E08	160373210010	GASKER,FILTER	1	

E09 LEFT COVER ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E09	160056030000	DOWEL PIN	2	
2	E09	16020309011X	BOLT PLUG M12×1.25×10	1	
3	E09	160253090000	WASHER	1	
4	E09	160383090020	PLUG,COVER MAGNETO,GREY	1	
5	E09	169024410010	LEFT COVER,GREY	1	
6	E09	169044410020	LEFT REAR LID ASSEMBLY,GREY	1	
7	E09	169074410010	LEFT COVER GASKET	1	
8	E09	B0107060286H	BOLT M6X28	2	
9	E09	B0107060406H	BOLT M6X40	9	
10	E09	B190102240C0	O-RING	1	

E10 OIL PUMP ASSY



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E10	B0107060256H	BOLT M6X25	3	
2	E10	269014460020	OIL PUMP ASSY	1	
3	E10	B08030000600	CIRCLIP 6×6	1	
4	E10	260053300000	WASHER	1	
5	E10	269084460020	OIL PUMP GEAR ASSY	1	
6	E10	260043090000	OIL PUMP BODY	1	
7	E10	269043090000	OIL PUMP INNER&OUTER ROTOR	1	
9	E10	B09012501220	PIN B2.5×12	2	
10	E10	260064460020	OIL PUMP SHAFT	1	
11	E10	260013090000	OIL PUMP SEAT	1	
12	E10	B02000300522	SCREW M3X5	1	

E11 CLUTCH ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E11	209014410000	CLUTCH ASSY	1	
2	E11	200053090000	SPACER	1	
3	E11	200573090000	CLUTCH HOUSING	1	
4	E11	200073090000	CLUTCH HUB	1	
5	E11	200083090000	FRICTION PLATE	5	
6	E11	200093090000	CLUTCH PLATE	4	
7	E11	209144410000	CLUTCH SPRING	5	
8	E11	200103090000	PRESSURE PLATE	1	
9	E11	B13010501605	SCREW W/WASHER M5×16	5	
10	E11	B0402060000H	NUT M6	1	
11	E11	20013309001X	SLOTTED ADJUSTING SCREW	1	
12	E11	200143090000	BEARING SEAT	1	
14	E11	200123090000	NEEDLE BEARING	1	
15	E11	200013210020	PUSH ROD	1	
16	E11	209044410000	RELEASE LEVER ASSEMBLY	1	
17	E11	200024410000	RETURN SPRING	1	
18	E11	200153090000	NUT	1	
19	E11	200163090000	LOCKING WASHER	1	
20	E11	200043090000	THRUST WASHER	1	
21	E11	170014410000	CLUTCH DRIVE GEAR	1	

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or actuator. The parts are numbered 1 through 26. The assembly sequence generally starts from the bottom left, where a long shaft (1) is inserted into a bracket (2). A spring (4) is attached to the shaft. The shaft then passes through a series of bushings (3, 5, 6, 7, 8) and a lever arm (9). The lever arm is connected to a piston rod (10) which is part of a cylinder assembly (11). The cylinder is sealed with a cap (12) and a pin (13). The piston rod is connected to a series of bushings (14, 15, 16) and a lever arm (17). The lever arm is connected to a series of bushings (18, 19, 20, 21) and a gear (21A). The gear is connected to a shaft (22) which is part of a larger assembly (23). The shaft is connected to a series of bushings (24, 25, 26) and a lever arm (27).


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E12	219014410010	SHIFT LEVER ASSEMBLY	1	
2	E12	B0107060206H	FLANGE BOLT M6×20	1	
3	E12	219344410000	WASHER	1	
4	E12	210026030000	STOPPER LEVER SPRING	1	
5	E12	210416030010	STOPPER LEVER	1	
6	E12	219334410000	WASHER	1	
7	E12	210343090000	WASHER 6.2×14×2.2	1	
8	E12	210014410000	BOLT	1	
9	E12	210366030000	PLATE COMP,GEARSHIFT DRUM STOPPER	1	
10	E12	210356030000	DOWEL PIN	1	
11	E12	219054410000	SHIFT DRUM	1	
12	E12	210313090000	PROD SPRING	1	
13	E12	210323090000	SHIFT PROD	1	
14	E12	B080100015A0	CIRCLIPS FOR SHAFT	1	
15	E12	210133090000	THRUST WASHER	3	
16	E12	210034410000	COLLAR	1	
17	E12	210013210000	AXLE SLEEVE,MAIN SHAFT ASSY	1	
18	E12	B190101900B1	O RING	1	
19	E12	210053090000	COLLAR	1	
20	E12	219313090000	WASHER	1	
21A	E12	219304410010	SPROCKET,ENGINE 14TEETH	1	
22	E12	210063090100	NUT M16×1.5	1	
23	E12	219093090000	SHIFT FORK SHAFT	1	
24	E12	219124410000	RIGHT SHIFT FORK	1	
25	E12	219114410000	MIDDLE SHIFT FORK	1	
26	E12	219104410000	LEFT SHIFT FORK	1	

E13 PRIMARY SHAFT ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E13	219144410000	MAIN SHAFT	1	NO.9 must be replaced together
2	E13	219193390000	PRIMARY SHAFT GEAR 5	1	
3	E13	210243090000	WASHER	2	
4	E13	210023070000	CIRCLIP	2	
5	E13	210023390000	PRIMARY SHAFT GEAR 3&4	1	
6	E13	219203390000	PRIMARY SHAFT GEAR 6	1	
7	E13	219163390000	PRIMARY SHAFT GEAR 2	1	
8	E13	219134410000	PRIMARY SHAFT ASSY	1	
9	E13	210043090000	PLUG	1	NO.1 must be replaced together

E14 COUNTERSHAFT ASSY




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E14	210013390000.00	WASHER 20	1	
2	E14	219243090000.00	COUNTERSHAFT GEAR 2	1	
3	E14	210033390000.00	WASHER 30	1	
4	E14	219224410000.00	COUNTERSHAFT	1	
5	E14	219283390000.00	COUNTERSHAFT GEAR 6	1	
6	E14	219253390000.00	COUNTERSHAFT GEAR 3	1	
7	E14	210043390000.00	WASHER 22	2	
8	E14	219263390000.00	COUNTERSHAFT GEAR 4	1	
9	E14	210053390000.00	CIRCLIP 22	1	
10	E14	219273390000.00	COUNTERSHAFT GEAR 5	1	
11	E14	210133090000.00	THRUSH WASHER 15	2	
12	E14	210463090000.00	NEEDLE BEARING	1	
13	E14	219233090000.00	COUNTERSHAFT GEAR 1	1	
14	E14	219214410000.00	COUNTERSHAFT ASSY	1	

E15 ELECTRIC STARTER ASSY



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E15	B0107060286H	BOLT M6×28	2	
2	E15	249013210150	STARTER MOTOR ASSY,wire length:550mm	1	
3	E15	240023090000	DOWEL PIN	1	
4	E15	249043090000	GEAR,STARTER IDLER	1	
5	E15	240013090000	SLEEVE	1	
6	E15	240043090020	GEAR,STARTER DRIVEN	1	
7	E15	240025140000	SCREW M8	3	
8	E15	249093230050	SPROCKET UNIT	1	
9	E15	299024180060	FLY WHEEL ASSY	1	
10	E15	B0205050256H	SCREW M5×25	3	
11	E15	B0205040106H	SCREW M4×10	2	
12	E15	299033090000	COIL ASSY	1	

E16 WATER PUMP ASSY



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E16	279224460010	IMPELLER SHAFT	1	
2	E16	B12016000100	BEARING 6001	1	
3	E16	270153160000	OIL SEAL 12x24x5	1	
4	E16	270216030000	EKK SEAL ASSY	1	
5	E16	279214460000	IMPELLER	1	
6	E16	279344460000	GASKET	1	
7	E16	279334460010	WATER PUMP COVER,GREY	1	
8	E16	B0107061056H	BOLT M6×105	1	
9	E16	B0107060286H	BOLT M6×28	3	
10	E16	B0107060106H	BOLT M6×105	2	
11	E16	150013070000	WASHER 6	2	