



S.P.Catalog_Leoncino


COLOR	GEM RED	BLACK	GRAY	BROWN
CODE	F2	BW	CX	Z7
PICTURE				

JCK(Q60-00) -BJ500(公路款 欧IV ABS)-1A
JCK(Q19-12)-BJ500(公路款 欧IV ABS)-1A散件
JCK(Q17-91) -BJ500(公路款 欧IV ABS)-1A散件
JCK(Q19-01) -BJ500(公路款 欧IV ABS)-1A半散件

C26280040000
C2628001BY00
C2628001BY00
C2628010BY00


BJ269MR-A
BJ269MR-A
BJ269MR-A
BJ269MR-A

E01 CYLINDER HEAD(气缸盖分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E01	150136030100	SCREW STOPPER	1	
2	E01	299073160000	SPARK PLUG	2	
3	E01	100126030000	WATER JACKET LOCATING SCREW GASKET	1	
4	E01	B091406014A0	DOWEL PIN	2	
5	E01	120126030000	OIL SEAL ASSY	8	
6	E01	109056280020	CYLINDER HEAD ASSY,BLACK	1	
7	E01	10004609001X	SHORT STUD M8	4	
8	E01	270156030010	BOLT M6X20	2	
9	E01	120026280000	PLUG	1	
10	E01	270776280050	THERMOSTAT COVER,BLACK	1	
11	E01	279165050000	WATER THERMOSTAT	1	
12	E01	120166220000	BOLT	1	
13	E01	109076280000	CYLINDER HEAD GASKET	1	
14	E01	270013160002	COOLANT TEMPERATURE SENSOR	1	
15	E01	100106030000	WATER PIPE	1	
16	E01	120133090002	WASHER	1	
17	E01	160106030100	BOLT M6X12	1	
18	E01	160056090000	O-RING 41X1.78	2	
19	E01	280146030000	AIR DUCT	2	
20	E01	280426030000	CLAMP ASSY	2	
21	E01	280306060000	WASHER 6.4X12.5X1.6	4	
22	E01	B0205060206H	SCREW M6X20	4	
23	E01	B0205060508H	SCREW M6X50	2	
24	E01	100306220000	PLUG	2	
25	E01	100236030000	COMBINATION BOLT	6	

E02 CYLINDER HEAD COVER ASSY(气缸盖罩分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E02	96200P250000	IGNITION COIL	2	
2	E02	100286030000	HIGH-PRESSURE BUNDLE SLEEVE	2	
3	E02	B190102650B0	O-RING	2	
4	E02	110026030010	DOWEL SCREW	4	
5	E02	100066030000	SEAL WASHER ASSY.	4	
6	E02	B0107060166H	BOLT	1	
7	E02	B0700000060H	SPRING WASHER 6	1	
8	E02	100276220000	COIL POSITIONING CLIP	1	
9	E02	109016220020	CYLINDER HEAD COVER,BLACK	1	
10	E02	100146220000	CYLINDER HEAD COVER GASKET	1	


E03 VALVE MECHANISM SUB-ASSEMBLY(配气机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E03	129106280030	CAMSHAFT ESSY.,IN	1	
2	E03	B090103006A4	DOWEL,PIN 3X6	2	
3	E03	129036220001	SPROCKET,INTAKE	1	
4	E03	120156030000	BOLT	4	
5	E03	129036220000	SPROCKET,EXHAUST	1	
6	E03	129096280030	EXHAUST CAMSHAFT ASSY	1	
7	E03	120106030000	TAPPET	8	
8	E03	120096030000	VALVE ADJUSTING WASHE,Δ1.600MM	8	
8	E03	120096030020	VALVE ADJUSTING WASHE,Δ1.625MM	8	
8	E03	120096030021	VALVE ADJUSTING WASHE,Δ1.650MM	8	
8	E03	120096030022	VALVE ADJUSTING WASHE,Δ1.675MM	8	
8	E03	120096030023	VALVE ADJUSTING WASHE,Δ1.700MM	8	
8	E03	120096030024	VALVE ADJUSTING WASHE,Δ1.725MM	8	
8	E03	120096030025	VALVE ADJUSTING WASHE,Δ1.750MM	8	
8	E03	120096030026	VALVE ADJUSTING WASHE,Δ1.775MM	8	
8	E03	120096030027	VALVE ADJUSTING WASHE,Δ1.800MM	8	
8	E03	120096030028	VALVE ADJUSTING WASHE,Δ1.825MM	8	
8	E03	120096030029	VALVE ADJUSTING WASHE,Δ1.850MM	8	
8	E03	120096030030	VALVE ADJUSTING WASHE,Δ1.875MM	8	
8	E03	120096030031	VALVE ADJUSTING WASHE,Δ1.900MM	8	
8	E03	120096030032	VALVE ADJUSTING WASHE,Δ1.925MM	8	
8	E03	120096030033	VALVE ADJUSTING WASHE,Δ1.950MM	8	
8	E03	120096030034	VALVE ADJUSTING WASHE,Δ1.975MM	8	
8	E03	120096030035	VALVE ADJUSTING WASHE,Δ2.000MM	8	
8	E03	120096030036	VALVE ADJUSTING WASHE,Δ2.025MM	8	
8	E03	120096030037	VALVE ADJUSTING WASHE,Δ2.050MM	8	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
8	E03	120096030038	VALVE ADJUSTING WASHE,Δ2.075MM	8	
8	E03	120096030039	VALVE ADJUSTING WASHE,Δ2.100MM	8	
8	E03	120096030040	VALVE ADJUSTING WASHE,Δ2.125MM	8	
8	E03	120096030041	VALVE ADJUSTING WASHE,Δ2.150MM	8	
8	E03	120096030042	VALVE ADJUSTING WASHE,Δ2.175MM	8	
8	E03	120096030043	VALVE ADJUSTING WASHE,Δ2.200MM	8	
8	E03	120096030044	VALVE ADJUSTING WASHE,Δ2.225MM	8	
8	E03	120096030045	VALVE ADJUSTING WASHE,Δ2.250MM	8	
8	E03	120096030046	VALVE ADJUSTING WASHE,Δ2.275MM	8	
9	E03	120086030000	COTTER,VALVE	16	
10	E03	129336220000	RETAINER,VALVE SPRING	8	
12	E03	129216220000	SEAT,VALVE SPRING	8	
13	E03	129196030000	VALVE,EXHAUST	4	
11	E03	120186220000	SPRING,UPPER VALVE	4	
14	E03	129186030000	VALVE,INTAKE	4	
15	E03	120176220000	SPRING,VALVE INLET	4	

E04 STRAINER UNIT ASSEMBLY(正时传动机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E04	140036030010	CAMSHAFT CHAIN TENSIONER	1	
2	E04	160106030050	BOLT M6X25	2	
3	E04	140176030000	WASHER	1	
4	E04	140026280010	REAR CHAIN GUIDE ASSY.	1	
5	E04	149026280000	FRONT CHAIN GUIDE	1	
6	E04	140186030000	CHAIN PLATE COMPONENTS	1	
7	E04	129026280000	CAMSHAFT CHAIN	1	


E05 CRANKCASE SUB-ASSY(曲轴箱分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E05	150056280020	CRANKCASE ASSY,BLACK	1	
2	E05	150346030000	SEAL PLATE	1	
3	E05	B0107060126H	BOLT M6X12	2	
4	E05	B01070601464	BOLT M6X14	2	
5	E05	150136220000	PRESS PLATE	1	
6	E05	150156220000	CHAIN PLATE GUIDE PIN	1	
7	E05	150146220000	PIPE	1	
8	E05	170236090000	DOWEL PIN 10.5×13×13	2	
9	E05	150103070000	PLUG	1	
10	E05	150166280020	INLET PIPE,BLACK	1	
11	E05	270156030010	BOLT M6X20	2	
12	E05	150066030000	RING 46X2.4	1	
13	E05	150116220000	RUBBER PLUG	1	
14	E05	120166030100	BOLT	2	
15	E05	150126280000	OIL COOLER TIE-IN	1	
16	E05	150316030180	BOLT	2	
17	E05	150196030020	GEAR SENSOR	1	
18	E05	150025040000	OIL SEAL	1	
19	E05	150076280000	PLUG	2	
20	E05	150086030100	SCREW STOPPER M16	3	
21	E05	150086220000	WASHER M16	3	
22	E05	150316030110	BOLT M8X75	2	
23	E05	150156030000	WASHER M8	11	
24	E05	150316030120	BOLT M10X100	1	
25	E05	240056090000	GASKET 11×18×3	3	
26	E05	150316030140	BOLT M8X45	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
27	E05	150316030130	BOLT M8X115	1	
28	E05	150056030000	DOWEL PIN	2	
29	E05	150026280030	BEARING,RED	6	
30	E05	160106110000	CONNECT BOLT	1	
31	E05	260146090010	OIL FILTER	1	
32	E05	240026090000	MINIMUM OIL PRESSURE SWITCH	1	
33	E05	270056030000	O RING	1	
34	E05	150036220000	BREATHING VALVE GASKET	1	
35	E05	150046220000	BREATHING VALVE SPACER	1	
36	E05	B0201060162H	SCREW M6X16	7	
37	E05	150316030150	BOLT M6X40	8	
38	E05	B01070808591	BOLT M8X85	6	
39	E05	260126030010	REDUCING VALVE	1	
40	E05	150316030160	BOLT M10X60	1	
41	E05	B190102580B0	O RING	1	
42	E05	150226280000	CLIP	6	
43	E05	150186280000	FLEXIBLE PIPE I	1	
44	E05	150216280000	PIPE ASSEMBLY	1	
45	E05	150176280000	PIPE	1	
46	E05	150206280000	FLEXIBLE PIPE III	1	
47	E05	150196280000	FLEXIBLE PIPE II	1	
48	E05	150156280030	OIL COOLER COVER,BLACK	1	
49	E05	120055050000	O RING	1	
50	E05	150146280000	OIL COOLER BOLT	1	
51	E05	150136280000	OIL COOLER ASSY	1	
52	E05	150116030100	VARIABLE GEAR ARM POSITIONING SHAFT	1	

E06 LEFT COVER ASSY (左盖分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E06	169046280030	LEFT BACK COVER,BLACK	1	
2	E06	B190101330B0	O RING 13.3X2.65	1	
3	E06	160053070010	PLUG SEE,BLACK	1	
4	E06	169166030030	TIMING MARK ACCESSING SCREW	1	
5	E06	160076030000	O RING 32X2.5	1	
6	E06	160106030100	BOLT M6X12	1	
7	E06	290016220000	PHASE SENSOR	1	
8	E06	160106030050	SCREW M6x25	9	
9	E06	169026220020	LEFT COVER,BLACK	1	ALT: 16902622BY01
10	E06	160046030000	CLAMP PRESSURE	1	
11	E06	B0205060106H	SCREW M6X10	1	
12	E06	169076220000	LEFT COVER GASKET	1	
13	E06	B0205060326H	SCREW M6X32	3	
14	E06	160056030000	DOWEL PIN	2	

E07 RIGHT COVER ASSY (右盖分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E07	270016220020	BOLT M6X28	2	
2	E07	160083090000	OIL LEVEL INDICATOR	1	
3	E07	169106280030	RIGHT COVER,BLACK	1	
4	E07	160073070000	DOWEL PIN	2	
5	E07	200001050000	OIL SEAL	1	
6	E07	169116220010	RIGHT COVER GASKET	1	
7	E07	160063070000	O-RING	1	
8	E07	160063090050	OIL FILLER PLUG	1	
9	E07	200066280000	HANDSPIKE	1	
10	E07	160106030050	BOLT M6X25	14	
11	E07	200056030000	WASHER 12X22X0.8	1	
12	E07	200046030000	CLUTCH RELEASE SPRING	1	
13	E07	200096280010	OPERATING LEVER ASSY	1	
14	E07	B1212K121002	NEEDLE ROLLER BEARING 12X16X10	2	
15	E07	160016280010	CLUTCH STEEL CABLE SUPPORT	1	


E08 PISTON,CONNECTING ROD & CRANKSHAFT ASSY(活塞连杆曲轴平衡轴分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E08	170046280000	PISTON RING ASSY	2	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
2	E08	179155050000	PISTON PIN CLIP	4	
3	E08	179146280010	PISTON PIN	2	
4	E08	179136280010	PISTON	2	
5	E08	179036280010	CONNECTING ROD ASSY.	2	
6	E08	B11130044014	FLAT KEY	1	
7	E08	170036280000	SCREW	4	
8	E08	B091403006A1	PIN	4	
9	E08	179076280000	BEARING,BLUE	4	
9	E08	179076280010	BEARING,GREEN	4	
9	E08	179076280020	BEARING,YELLOW	4	
10	E08	179256280010	BALANCE SHAFT	1	
11	E08	27002305011X	NUT M12X1.25	1	
12	E08	170075040000	WASHER	1	
13	E08	179016280010	CRANKSHAFT ASSY	1	
14	E08	170065050000	KEY,WOODRUFF	1	
15	E08	170096220000	FLAT KEY	1	
16	E08	170016280010	DRIVING GEAR	1	
17	E08	179236220000	BALANCER DRIVE GEAR	1	
18	E08	170016110000	WASHER	1	
19	E08	170126220000	NUT M18X1.5	1	
20	E08	B12016030503	BALL BEARING	1	
21	E08	170186220100	NUT M14X1.5	1	
22	E08	179366220000	BALANCER DRIVEN GEAR ASSY	1	
23	E08	170026280000	COLLAR	1	
24	E08	210136030010	ROLLER BEARING	1	
25	E08	210186030000	STEEL WIRE DUMPING RING	1	


E09 GEAR SHIFT MECHANISM ASSEMBLY (变速换挡机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E09	219016220000	STOPPER LEVER SPRING	1	
2	E09	210343090000	WASHER 6.2×14×1.5	1	
3	E09	219046220000	STOPPER LEVER ASSY	1	
4	E09	210303420000	SHIFT POSITIOMING ROLLER ARM AXLE	1	
5	E09	210323090000	SHIFT PROD	1	
6	E09	210313090000	PROD SPRING	1	
7	E09	219056030000	SHIFT DRUM	1	
8	E09	B12016600501	BEARING 16005	1	
9	E09	210356030000	DOWEL PIN	1	
10	E09	210366030000	SEGMENT	1	
11	E09	210376030000	WASHER	1	
12	E09	B0107060156H	BOLT,FLANGE,M6×15	1	
13	E09	B0109060146H	BOLT,FLANGE,M6×14	2	
14	E09	210036030000	PLATE,BEARING SETTING	1	
15	E09	210406030000	WASHER	1	
16	E09	B08010001701	CIRCLIP 17	1	
17	E09	210396030000	SLEEVE,STOP ARM	1	
18	E09	210056030000	SHIFT SHAFT SPRING	1	
19	E09	210046030000	SHIFT SHAFT SLEEVE	1	
20	E09	219066280000	SHIFT SHAFT ASSY	1	
21	E09	219106030000	LEFT SHIFT FORKS	1	
22	E09	210016030000	SPRING,SHAFT,SHIFT FORK	2	
23	E09	219086030000	SHIFT FORK SHAFT	1	
24	E09	219116030000	MIDDLE SHIFT FORK	1	
25	E09	219126030000	RIGHT SHIFT FORK	1	
26	E09	B12016020406	BEARING 6204-Z	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
27	E09	210566030010	WASHER	1	
28	E09	219136280000	PRIMARY SHAFT ASSY	1	
29	E09	210186030000	BEARING CIRCLIP	2	
30	E09	210136030010	BEARING	2	
31	E09	210156030001	WASHER	1	
32	E09	210166030101	SPANER NUT	1	
33	E09	210196030000	NUT M18×1	1	
34	E09	210306030000	WASHER	1	
35	E09	219296030000	DRIVE SPROCKET	1	
36	E09	210206030000	SHAFT SLEEVE 25	1	
37	E09	210316030000	O RING 25×2.5	1	
38	E09	210216030010	OIL SEAL	1	
39	E09	219216030000	SECONDARY SHAFT ASSY	1	
40	E09	210236030000	WASHER	3	
41	E09	210246030000	CIRCLIP 28	3	
42	E09	210276030000	WASHER	1	
43	E09	210266030000	WASHER	1	
44	E09	210326030000	WASHER 22×30×1	1	
45	E09	210096030000	WASHER	2	
46	E09	210106060000	CIRCLIP 24	2	
47	E09	210076030000	WASHER	1	
48	E09	210066030000	WASHER	1	

E10 CLUTCH SYSTEM(离合器分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E10	209016280020	CLUTCH HOUSING	1	
2	E10	200206030001	CLUTCH HUB	1	
3	E10	200376030000	PLATE,FRICTION(Ⅱ)	7	
4	E10	200216030000	CLUTCH PLATE	7	
5	E10	200226030001	DISC SPRING	1	
6	E10	200366030000	PLATE,FRICTION(I)	1	
7	E10	200236030001	WASHER	1	
8	E10	200306030001	DRIVEN DISK ASSY,CLUTCH	1	
9	E10	200246030001	CLUTCH SPRING	4	
10	E10	200256030001	PRESS PLATE	1	
11	E10	B1331060250N	BOLTS ASSEMBLY	4	
12	E10	209106280010	CLUTCH ASSY	1	
13	E10	200476030000	NEEDLE BEARING	1	
14	E10	200446030000	WASHER	1	
15	E10	B12016600401	BEARING	1	
16	E10	210146280000	SPROCKET SHAFT SLEEVE	1	
17	E10	269116030000	OIL PUMP DRIVE SPROCKET	1	
18	E10	200176030001	COLLAR	1	

E11 ELECTRIC STARTER ASSY(电启动分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E11	150316030150	BOLT M6×40	2	
2	E11	249066280000	STARTER MOTOR	1	
3	E11	249046280000	STARTER IDLE GEAR	1	
4	E11	249056030000	STARTER IDLE GEAR SHAFT,size:φ10×φ4.7×44	1	size:φ10×φ4.7×44,for vehicle Vin before ZBNP18003HB906695
4	E11	16020307001X	SHAFT,STARTER IDLER GEAR,size:φ10×45	1	size:φ10×45,start Vin ZBNP18003HB906695 on 13th March 2018
5	E11	249016280000	STARTER CLUTCH DRIVE GEAR	1	
6	E11	249106280000	COMPLETE STARTER CLUTCH,outer diameter:Φ91mm	1	
7	E11	299026280020	FLY WHEEL	1	
8	E11	B0207080168H	SCREW M8×18	6	
9	E11	299036280000	COIL ASSY	1	
10	E11	240013060000	O RING Φ24×Φ3.1	1	

E12 OIL PAN ASSY (油底壳分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E12	160106030040	BOLT M6X30	12	
2	E12	260346030000	MAGNETISM BOLT	1	
3	E12	160073070000	DOWEL PIN 6.7 X 8 X 14	2	
4	E12	260036220000	GASKET	1	
5	E12	260016220020	SUMP COVER,BLACK	1	

E13 LUBRICATE SYSTEM (润滑系统分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E13	160073070000	DOWEL PIN	2	
2	E13	269136280000	DOWEL PIN	2	
3	E13	160085040000	O-RING	2	
4	E13	B0107060326H	BOLT M6×32	3	
5	E13	B0107060406H	BOLT M6×40	1	
6	E13	260036030000	OIL COLLECTER SHELL	1	
7	E13	269086220000	OIL COLLECTER	1	
8	E13	100066090000	CONE PLUG M14×1.5×10	1	
9	E13	269026280000	OIL PUMP BODY	1	
10	E13	260086030000	WASHER	1	
11	E13	269036280000	OIL PUMP SHAFT	1	
12	E13	B090103016B0	PIN	1	
13	E13	269046220000	INNER ROTOR	1	
14	E13	269056220000	OUTER ROTOR	1	
15	E13	269016220000	OIL PUMP COVER	1	
16	E13	269066220000	OIL PUMP DIRVING GEAR	1	
17	E13	260106030000	WASHER 5×20×1.5	1	
18	E13	B01070501063	BOLT M5×10	1	
19	E13	B01070603064	BOLT M6×30	3	
20	E13	269016280000	OIL PUMP ASSY	1	
21	E13	269056030000	OIL PUMP CHAIN	1	

E14 COOLING SYSTEM (冷却系统分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E14	279216030000	IMPELLER	1	
2	E14	160253160000	WATER SEAL ASSY	1	
3	E14	270153160000	OIL SEAL	1	
4	E14	279316030020	WATER PUMP BODY,BLACK	1	
5	E14	B190100335B0	O-RING 33.5x2.65	1	
6	E14	B12016000100	BEARING	2	
7	E14	B08010001201	CIRCLIP	1	
8	E14	27922603001X	IMPELLER SHAFT	1	
9	E14	150316030150	SCREW	2	
10	E14	279206030030	WATER PUMP,BLACK	1	
11	E14	270076030000	PIPE	1	
12	E14	270156030000	BOLT	2	
13	E14	270345050000	WASHER	1	
14	E14	279336030020	WATER PUMP COVER,BLACK	1	
15	E14	270066030000	SMALL SEAL RING	1	
16	E14	270166030000	BUSH	1	
17	E14	B080100028A1	CIRCLIP 28	1	
18	E14	279106280000	INTAKE PIPE	1	
19	E14	330265050000	STEEL BAND	2	
20	E14	279116280000	EXHAUST PIPE	1	
21	E14	B17010105003	CLIP Φ10	2	


E15 THROTTLE BODY SYSTEM (节流阀体分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
1	E15	280476090001	NUT M7,THROTTLE SHAFT	1	
2	E15	B07000000801	SPRING WASHER	1	
3	E15	280676030000	MANIPULATION OF THE WHEEL COMPONENT	1	
4	E15	280346090000	WASHER	1	
5	E15	280336090000	WASHER	2	
6	E15	280386030000	OIL SEAL 8X12X2.5	1	
7	E15	280016220020	THROTTLE SHAFT	1	
8	E15	280076030000	THROTTLE SLICE	2	
9	E15	280116080000	SCREW	4	
10	E15	280196030000	BUSH	1	
11	E15	280306030000	TORSIONAL SPRING,LEFT THROTTLE SHAFT	1	
12	E15	B02000501029	SCREW(M5X10)	2	
13	E15	280066220010	BRACKET	1	
14	E15	B04000500059	NUT	5	
15	E15	B02000502529	SCREW M5X25	3	
16	E15	280506030010	PIPE	1	
17	E15	3314302E0000	OIL INLET CAP	1	
18	E15	289026280000	FUEL INJECTOR	2	
19	E15	289086280010	FUEL	1	
20	E15	289066280000	SENSOR,INLET PRESSURE	1	
21	E15	B02040501629	SCREW	2	
22	E15	289076280000	RUBBER HOSE	1	
23	E15	49016T030000	CLAMP Ø8	2	
24	E15	3313701K0000	BRASS TUBE	1	
25	E15	280686030000	SEALING RING	1	
26	E15	280576030000	SEALING COVER PLATE	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	NOTES
27	E15	B02000300829	SCREW M3X8	1	
28	E15	280116090000	NEEDLE ROLLER BEARING	1	
29	E15	280249010000	SHAFT CIRCLIP,THROTTLE SHAFT	1	
30	E15	280116130000	TPS PLATE	1	
31	E15	B02010401225	SCREW M4X12	2	
32	E15	280756030010	SENSOR,THE LOCTION OF THROTTLE	1	
33	E15	B0703000400A	WASHER	2	
34	E15	B13080401029	SCREW M4X10	2	ALT: B1308040102H
35	E15	B02040501429	SCREW M5X14	2	
36	E15	289066220000	THROTTLE BODY	1	
37	E15	280716030000	NEGATIVE PRESSURE COPPER PIPE	2	
38	E15	06103N140000	CLAMP Φ13	4	
39	E15	280946030000	HOSE II	1	
40	E15	280956030000.00	INTAKE OF BRASS	2	
41	E15	280396030000.00	PLATE I	1	
42	E15	140106090000.00	O-RING	1	
43	E15	280476030020.00	REPEATING MOTOR	1	
44	E15	B07000000509	ELASTIC WASHER	2	
45	E15	280976030000.00	BUSH	2	
46	E15	280936030000	RUBBER HOSE I	1	
47	E15	280966030000	TIMING SYSTEM	1	
48	E15	57039S010000	RUBBER CUSHION	2	
49	E15	280406090000	ADJUSTING SCREW	2	
50	E15	280416090000	SEALING RING,ADJUSTING SCREW	2	
51	E15	B0200060162L	SCREW M6X12	1	
52	E15	289006280010	THROTTLE ASSY	1	


F01 操纵 CONTROL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F01	40450P180000	LEFT VIEW MIRROR ASSY	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
2	F01	40480P180000	REAR VIEW MIRROR ASSY	1	
3	F01	40101P180000	HANDLEBAR ASSY	1	
4	F01	B0281060356H	SCREW M6×35	2	
5	F01	B0700000060H	SPRING WASHER 6	2	
6	F01	B0703000060H	WASHER Φ6	2	
7	F01	40031P250000	GRIP END	2	
8	F01	40032P250000	GRIP END MOUNTING SEAT	2	
9	F01	40031S010000	GRIP END	2	
10	F01	40001P180010	LEFT HANDLEBAR GRIP	1	
11	F01	40500P160003	LEFT HANDLEBAR SWITCH	1	
12	F01	40600P160003	RIGHT HANDLEBAR SWITCH	1	
13	F01	40320P250000	THROTTLE CABLE HOUSING ASSY	1	
14	F01	40210P180010	RIGHT HANDLEBAR GRIP	1	
15	F01	40300P180000	THROTTLE CABLE ASSY I	1	
16	F01	40330P180000	THROTTLE CABLE ASSY II	1	
17	F01	40400P180000	CLUTCH CABLE ASSY	1	
18	F01	40080S01003Z	CLUTCH LEVER ASSY	1	
19	F01	40023P250000	RUBBER CLIP	2	
20	F01	40022P250000	WIRE CLIP	1	
21	F01	40084S010001	CLUTCH LEVER	1	
22	F01	B02810602562	SCREW M6×25	2	
23	F01	40087K010000	SPECIAL NUT	1	
24	F01	40086K010000	SPECIAL SCREW	1	
25	F01	40088S010000	CLUTCH SWITCH	1	
26	F01	91190P260000	ABS SWITCH ASSY.	1	

F02 前叉 FRONT FORK ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F02	B0205080206A	SCREW M8×20	4	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
2	F02	43014P180001	UPPER HANDLEBAR HOLDER	2	
3	F02	43013P180001	LOWER HANDLEBAR HOLDER	2	
4	F02	70078P180000	SPEEDOMETER BRACKET	1	
5	F02	47015P010000	DAMPER	4	
6	F02	40086P180000	HANDLEBAR STUD	2	
7	F02	B0281080256H	BOLT M8×1.25×25	2	
8	F02	43012P260000	UPPER BRACKET	1	
9	F02	08511P180000	HEAD LIGHT FIXING BOARD	1	
10	F02	B0417101254H	SELF-LOCKING NUT M10×1.25	2	
11	F02	43049P250000	STEERING STEM NUT	1	
12	F02	43008S010010	STEERING STEM HEAD NUT	1	
13	F02	43009P260000	STEERING STEM NUT	1	
14	F02	43005S010000	DUST SEAL	2	
15	F02	43130S010000	STEER BEARING	2	
16	F02	43290P250000	DUST SEAL,MARK:NOK	2	
17	F02	43103S010000	LOCKING RING	1	
18	F02	43100P160001	LOWER BRACKET ASSY	1	
19	F02	B02810602062	BOLT M6×1×20	6	
20	F02	B02830600862	BOLT M6×8	4	
21	F02	43260P250000	OIL SEAL	2	
22	F02	45353S050000	PIPE	1	
23A	F02	43151P250001	CLAP, DISC BRAKE, REAR,L	1	start Vin ZBNP1800XJB841723
24	F02	08521P250000	HEADLAMPS INSTALL A	1	
25	F02	08523P250020	SPACER BUSH	1	
26	F02	08524P250000	BUFFER	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
27	F02	08011P160000	SCREW M5×12	2	
28	F02	B0283060146H	SCREW M6×14	1	
29	F02	43200P180000	FRONT LEFT SHOCK ABSORBER ASSY.	1	
30	F02	43300P180000	FRONT RIGHT SHOCK ABSORBER ASSY.	1	
31	F02	86200P250000	FRONT REFLECTOR	2	
32	F02	08029S020010	BOLT M10×1.25×55	4	
33	F02	B02810603062	BOLT M6×30	2	
34	F02	45710P250000	FRONT WHEEL ROTATION SENSOR	1	
35	F02	B02810601262	SCREW M6×12-8.8-ZG	1	
36	F02	43609P180000	SPRING GUIDE	2	
37	F02	43201P160000	DAMPER OUTER TUBE	2	
38	F02	43231P180000	DAMPER INNER TUBE	2	
39	F02	43202P250000	DAMPING SPRING	2	
40	F02	43321P160010	RIGHT MOUNTING BRACKET	1	
41	F02	43221P160010	LEFT MOUNTING BRACKET	1	
42	F02	43204P180000	BOLT	2	
43	F02	B190104870B0	O RING 48.7×2.65	2	
44	F02	43212P300000	DAMPER OUTER TUBE GUIDE BUSH	2	
45	F02	43239P010000	DAMPER INNER TUBE GUIDE BUSH	2	
46	F02	43681P160000	BOTTOM VALVE	2	
47	F02	43521P010000	OIL SEAL WASHER	2	
48	F02	43523P010000	OIL SEAL CLIP	2	
49	F02	B02051002553	BOLT M10×25	2	
50	F02	B190104100B0	O RING Φ41×Φ2.65	2	
51	F02	43503P300001	SPRING SEAT	2	

F03 前轮 FRONT WHEEL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F03	44004P160100	FRONT WHEEL AXLE	1	
2	F03	B02810802062	BOLT M8×1.25×20	12	
3	F03	45030P160000	FRONT BRAKE DISC	2	
4	F03	44016P100000	FRONT WHEEL RIGHT COLLAR	1	
5	F03	B140507D1700	TIRE 120/70 ZR17	1	
6	F03	44101P100000	FRONT RIM ASSY	1	
7	F03	60200J000001	DUST SEAL ASSY	2	
8	F03	B12016020400	BALL BEARING 6204-2RS	2	
9	F03	44006P100000	FRONT WHEEL MIDDLE SHAFT SLEEVE	1	
10	F03	B1403Z201100	AIR VALVE/RIM VALVE	1	
11	F03	45702P160000	ABS GEAR RING,FRONT WHEEL	1	
12	F03	44005P160000	FRONT WHEEL LEFT COLLAR	1	


F04 液刹总成 FRONT DISK BRAKE ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F04	55140P260000	OIL CUP ASSY.	1	
2	F04	08012P160000	SCREW M5×16	1	
3	F04	55240P180001	REAR BRAKE HOSE ASSY,I	1	start Vin ZBNP1800XJB841723
4	F04	55270P180001	REAR BRAKE HOSE ASSY,II	1	start Vin ZBNP1800XJB841723
5	F04	55400P180000	BRAKE FLUID RESERVOIR	1	
6	F04	55500P160000	REAR BRAKE CALIPER	1	
7	F04	55120P100000	REAR BRAKE PADS	1	
8	F04	55300P180000	REAR BRAKING SWITCH	1	
9	F04	45078P300000	WASHER	19	
10	F04	45240P180002	FRONT BRAKE HOSE ASSY,I	1	start Vin ZBNP1800XJB841723
11	F04	45250P180002	FRONT BRAKE HOSE ASSY,III	1	start Vin ZBNP1800XJB841723
12	F04	45270P180002	FRONT BRAKE HOSE ASSY,II	1	start Vin ZBNP1800XJB841723
13	F04	45400P250012	FRONT MASTER CYLINDER	1	
14	F04	45500P160000	FRONT LEFT BRAKE CALIPER	1	start Vin ZBNP1800XJB841723
15	F04	45600P160000	FRONT RIGHT BRAKE CALIPER	1	start Vin ZBNP1800XJB841723
16	F04	45700P100001	ABS	1	
18	F04	45120S010011	FRONT BRAKE PADS	1	
19	F04	45037P300000	BRAKE HOSE BANJO BOLT	1	
20	F04	55037P300000	BRAKE HOSE BANJO BOLT	5	
21	F04	B0281080256H	BOLT M8×1.25×25	2	
22	F04	45037J000000	SCREW	1	
23	F04	45024P300000	BRAKE LEVER PIVOT SCREW	1	
24	F04	45037P150000	BRAKE HOSE BANJO BOLT	1	
25	F04	45020P300000	FRONT BRAKE LEVER	1	
26	F04	B04170600055	NUT M6	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
27	F04	B02040401225	SCREW M4×12	1	
28	F04	45300J000010	FRONT BRAKE SWITCH	1	
29	F04	45023P250010	FRONT BRAKE MASTER CYLINDER HOLDER	1	
30	F04	45021B510000	COVER,ANTI-DUST, DEFLATING VALVE	2	
31	F04	45019N3CT000	DEFLATING VALVE	2	
32	F04	B0700000080H	SPRING WASHER 8	2	
33	F04	B02810602062	SCREW M6×1×20	2	
34	F04	65831P180000	CLIP	4	start Vin ZBNP1800XJB841723

F05 消声器 MUFFLER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F05	47800P250000	EXHAUST PIPE GASKET ASSY	2	
2	F05	319026280000	OXYGEN SENSOR	2	
3	F05	B0407080005H	NUT M8	4	
4	F05	47500P180010	EXHAUST PIPE ASSY,MARK: e13 BENELLI P18-S1	1	
5	F05	47035P250000	GRAPHITE LINING	1	
6	F05	48830P290000	CLAMP ASSY.	1	
7	F05	47300P180010	MUFFLER ASSY,MARK:e13 BENELLI P18-M1	1	
8	F05	47026P160000	RUBBER SLEEVE	1	
9	F05	B02810803062	BOLT M8×1.25×30	2	
10	F05	65613P260000	COVER BUSH	3	
11	F05	65617H010010	RUBBER SLEEVE II	3	
12	F05	48830P180000	CLAMP ASSY.	1	
13	F05	47200P180010	MUFFLER JOINTING COMP,MARK:e13 BENELLI P18-M2	1	
14	F05	B02810803062	BOLT M8×1.25×30	1	
15	F05	B0703000080H	WASHER 8	1	
16	F05	B04820800062	NUT M8	1	
17	F05	47620P180000	MUFFLER MOUNTING PLATE	1	
18	F05	47761P160001	FRONT DECORATIVE COVER	1	
19	F05	47023P180000	DECORATIVE COVER	1	
20	F05	B0218060106A	SCREW M6X10	4	
21	F05	B0700000060A	SPRING WASHER φ6	4	

F06 空滤器 AIR CLEANER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F06	49100P180000	AIR FILTER ASSY	1	
2	F06	B02810601262	SCREW M6×12-8.8-ZG	4	
3	F06	310015040000	INTAKE AIRTEMPERATURE SENSOR	1	
4	F06	49016N070001	STAINLESS STEEL CLIP 40 - 60	2	
5	F06	49025P180000	EXHAUST GAS RECIRCULATION TUBE	1	
6	F06	49805J000000	PLATE CLAMP Ø18.5×10×1	2	
7	F06	49912K670000	CARBON CANISTER	1	
8	F06	50307J140002	PLATE CLAMP Ø10	4	
9	F06	B16010721701	PIPE 11×7×170	1	
10	F06	49016B350010	CLIP	4	
11	F06	B16010521801	PIPE 5×9×180	1	
12	F06	50260T730000	VEHICLE-DOWN SENSOR	1	
13	F06	B16010521801	PIPE 5×9×180	1	
14	F06	49923P180000	VALVE EGR&THROTTLE BODY	1	
15	F06	49710N070000	VALVE EGR/SOLENOID VALVE	1	
16	F06	57054P180000	FIXING BOARD	1	
17	F06	49200P180000	AIR CLEANER FILTER	1	

F07 燃油箱 FUEL TANK ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F07	B0281060356H	SCREW M6×35	2	
2	F07	08023J000020	WASHER	2	
3	F07	50221J000001	FUEL TANK MOUNTING COLLAR	2	
4	F07	50222J000001	RUBBER SLEEVE	2	
5	F07	50006K980000	RUBBER MAT	1	
6	F07	50100P18F200	FUEL TANK ASSY,GEM RED F2	1	F2
6	F07	50100P18BW00	FUEL TANK ASSY,GEM BLACK BW	1	BW
7	F07	B0280050140A	SCREW M5×14	3	
8	F07	B0280050300A	SCREW M5×30	3	
9	F07	50005J000000	MOUNTING PAD,FUEL TANK	2	
10	F07	50800P180003	NEW FUEL LEVEL SENSOR ASSY	1	
11	F07	50808P250010	FUEL LEVEL SENSOR SEAL RING	2	same as 50808P250000
12	F07	B0109050166H	BOLT M5×16	14	
13	F07	50800P180004	NEW FUEL LEVEL SENSOR ASSY,REAR	1	
14	F07	50400P180000	FUEL PUMP ASSY.	1	
15	F07	50380P180000	FUEL PIPE ASSY I	1	
16	F07	50340N070000	FUEL FILTER	1	
17	F07	50390P180000	FUEL PIPE ASSY II	1	
18	F07	65618J000000	RUBBER CUSHION	2	
19	F07	50391N070000	FUEL FILTER JACKET	1	


F08 后摆臂 REAR SWING ARM ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F08	53006P180000	LEFT BUSH	2	
2	F08	53220S010000	SEAL	4	
3	F08	53213P300000	ROLLING BEARING RNA4905	3	
4	F08	53007P180000	RIGHT BUSH I	1	
5	F08	B12016190500	ROLLING BEARING 61905-2RS	1	
6	F08	B08000004201	CIRCLIP Ø42	1	
7	F08	53008P180000	RIGHT BUSH II	1	
8	F08	53100P180000	REAR SWING ARM ASSY	1	
9	F08	53004P180000	CHAIN SHIELD BLOCK	1	
10	F08	B0284060150A	SCREW M6×15.2	7	
11	F08	53053P180000	CHAIN PROTECTOR COVER	1	
12	F08	B02810804062	BOLT M8×1.25×40	3	
13	F08	B02810603062	BOLT M6×30	2	
14	F08	53021P250000	BUSH	2	
15	F08	08029S020010	BOLT M10×1.25×55	2	
16	F08	63800P180000	REAR ABSORBER ASSY	1	
17	F08	B0417101254H	SELF-LOCKING NUT M10×1.25	2	
18	F08	B0407080005H	NUT M8	2	
19	F08	08002P300010	SCREW M8	2	
20	F08	53231P100000	DRIVE CHAIN PULLER	2	
21	F08	49371T620000	RUBBER BAND	3	
22	F08	65770P180000	REAR FENDER BRACKET	1	
23	F08	96003P250000	RUBBER CLIP	3	
24	F08	53310P180000	FIXING PLATE	1	
25	F08	65731P180000	REAR FENDER FORESIDE	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
26	F08	65741P180000	REAR FENDER REAR SIDE	1	
27	F08	B0284060200A	SCREW M6×20	3	
28	F08	82015S010000	BUSH H6	3	
29	F08	08252P180001	REAR LICENSE PLATE BRACKET	1	
30	F08	B0201050162H	SCREW M5×16	3	
31	F08	08207N120000	T BUSHING	3	
32	F08	B0417050004H	NUT M5	3	
33	F08	82900P180000	LICENSE PLATE LAMP	1	
34	F08	B0500420160H	SELF-TAPPING SCREW ST4.2×16	1	
36	F08	86500B720001	REAR REFLECTOR	1	
37	F08	B0700000080H	SPRING WASHER 8	3	
38	F08	B0703000080H	WASHER 8	3	
39	F08	B0283060146H	BOLT M6×1×14	2	
40	F08	B04810600052	NUT M6×1	2	


F09 后轮 REAR WHEEL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F09	54004P100100	REAR WHEEL AXLE	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
2	F09	54016P100000	REAR WHEEL LEFT COLLAR	1	
3	F09	B04821012552	SELF-LOCKING NUT M10×1.25	5	
4	F09	60002P100000	REAR WHEEL SPROCKET 43TH	1	
5	F09	60310P180001	CHAIN 525SX-1×110	1	
6	F09	60001P100000	REAR WHEEL DRIVE HUB	1	
7	F09	60015P250010	SPROCKET MOUNTING BOLT M10×1.25×41	5	
8	F09	54622S010000	REAR WHEEL DRIVE HUB DAMPER	5	
9	F09	60200P100000	SEAL RING ASSY 38×62×7	1	
10	F09	B08810006200	CIRCLIP Φ62	1	
11	F09	54553S010000	BEARING 30×62×23.8	1	
12	F09	B190105300C0	O SEAL RING Φ53×Φ3.55	1	
13	F09	60006P100000	REAR WHEEL AXLE SLEEVE	1	
14	F09	B12016020400	BALL BEARING 6204-2RS	2	
15	F09	54006P100000	REAR WHEEL SPACER	1	
16	F09	60200J000001	DUST SEAL ASSY	1	
17	F09	B1403Z201100	AIR VALVE/RIM VALVE	1	
18	F09	54101P100000	REAR RIM ASSY	1	
19	F09	B140111C1780	TIRE 160/60-ZR17	1	
20	F09	54005P100100	REAR WHELL RIGHT COLLAR Φ20×Φ27×13	1	
21	F09	55030P250005	REAR DISC BRAKE	1	
22	F09	B0282060208H	SCREW M6×20	6	
23	F09	55401P180000	REAR BRAKE CALIPER MOUNTING BRACKET ASSY	1	
24	F09	08051P100100	NUT M20×1.5	1	
26	F09	B02810601262	SCREW M6×12-8.8-ZG	3	
27	F09	55710P250000	REAR WHEEL ROTATION SENSOR	1	


F10 车架 FRAME ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F10	B01591007562	BOLT M10×1.25×75	1	
2	F10	57110P18BH00	FRONT FRAME ASSY,EXTRA BLACK BH	1	
3	F10	B0417101254H	SELF-LOCKING NUT M10×1.25	13	
4	F10	58301P180000	ENGINE MOUNTING AXLE	1	
5	F10	B04821012552	SELF-LOCKING NUT M10×1.25	1	
6	F10	B0159101006H	BOLT M10×1.25×100	1	
7	F10	57060P180000	DAMPER	2	
8	F10	B0159100706H	BOLT M10×1.25×70	2	
9	F10	B0159101156H	BOLT M10×1.25×115	1	
10	F10	B0159100456H	SCREW M10×1.25×45	2	
11	F10	08029S020010	BOLT M10×1.25×55	2	
12	F10	57060p130000	DAMPER	2	
13	F10	57090P180000	BUSH FIXING BRACKET	2	
14	F10	B0283060146H	SCREW M6×14	8	
15	F10	57013P180000	LEFT CLIP	1	
16	F10	57043P180000	FIXING BORAD I	1	
17	F10	B100432007P0	RIVETS 3×2.7	2	
19	F10	57045P180000	FIXING BOARD III	1	
20	F10	57044P180000	FIXING BOARD II	1	
21	F10	57014P180000	RIGHT CLIP	1	
22	F10	B0159100356H	BOLT M10×1.25×35	2	
23	F10	B0159100686H	BOLT M10×1.25×68,GREEN	1	
24	F10	57120P18BH00	REAR FRAME ASSY,EXTRA BLACK BH	1	
25	F10	B0281080256H	BOLT M8×1.25×25	4	
26	F10	52010P180000	LEFT GRAB RAIL	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
27	F10	52020P180000	RIGHT GRAB RAIL	1	
28	F10	57046P180000	FIXING BOARD IV	1	
29	F10	B02830602562	SCREW M6×25-8.8-ZG	2	
30	F10	58900K980000	SEAT LOCK CABLE	1	
31	F10	B0703000100H	WASHER 10	2	
32	F10	57015P180000	RUBBER PLUG	2	

F11 单撑 SIDE STAND ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F11	57005P280000	SIDE STAND MOUNTING SCREW	1	
2	F11	08021P250000	SIDE STAND MOUNTING WASHER	1	
3	F11	58700P180000	SIDE STAND ASSY	1	
4	F11	B0702000060H	WASHER Φ6	1	
5	F11	B02830600862	BOLT M6×8	1	
6	F11	57405P280000	SIDE STAND MOUNTING BRACKET	1	
7	F11	B02810501262	SCREW M5X12	2	
8	F11	91170N070000	SIDE STAND SWITCH	1	
9	F11	B04031212514	NUT M12×1.25	1	
10	F11	B07000001204	SPRING WASHER 12	1	
11	F11	57003P250000	SIDE STAND OUTER SPRING	1	
12	F11	57004S010000	SIDE STAND INNER SPRING	1	


F12 脚蹬 PEDAL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F12	58226P180000	LEFT FRONT PEDAL BRACKET	1	
2	F12	08013S010010	SCREW	2	
3	F12	53001P300100	REARSWING ARM SHAFT	1	
4	F12	B091404008B4	PIN 4×8	2	
5	F12	B02051005562	SCREW M10×55	1	
6	F12	08011L290001	BOLT	2	
7	F12	08370P180000	SHIFT PEDAL ASSY	1	
8	F12	B02810603062	BOLT M6×30	1	
9	F12	08355S040000	SPACER	1	
10	F12	08375S010000	SECTION HEAD	1	
11	F12	08051S040010	NUT M6×1	1	
12	F12	B04810600052	NUT M6×1	3	
13	F12	08371V020000	CONNECTING ROD	1	
14	F12	B02810602562	SCREW M6×25-8.8-ZG	2	
15	F12	40706S040000	M6 LEFT SECTION HEAD	1	
16	F12	08381P910010	SHIFT PEDAL FIXING BRACKET	1	
17	F12	B04800600052	NUT M6-8-ZG	1	
18	F12	B02810601662	SCREW M6×1×16	1	
19	F12	58220P29000Z	LEFT FRONT FOOTREST ASSY	1	
20	F12	58217P260000	FOOTREST MOUNTING PIN	2	for vehicle Vin before ZBNP18002JB872139
20	F12	58217P160000	FOOTREST MOUNTING PIN	2	start Vin,ZBNP18002JB872139 Dec 15th 2017
21	F12	58260P26000Z	LEFT REAR FOOTREST ASSY	1	
22	F12	B0882000050A	CIRCLIP Φ5	2	for vehicle Vin before ZBNP18002JB872139
22A	F12	B0703000060H	WASHER Φ6	2	start Vin,ZBNP18002JB872139 Dec 15th 2017
23	F12	58280P26000Z	RIGHT REAR FOOTREST ASSY	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
24	F12	58246P180000	RIGHT FRONT FOOTREST BRACKET	1	
25	F12	58240P29000Z	RIGHT FRONT FOOTREST ASSY	1	
26	F12	40710P180000	REAR BRAKE PEDAL ASSY	1	
27	F12	40705P250000	ECCENTRIC PUSH ROD	1	
28	F12	B02051002262	SCREW M10×22	1	
29	F12	40717P250000	LOWER SPRING DOWEL	1	
30	F12	40273P250000	UPPER SPRING DOWEL	1	
31	F12	40702P260000	REAR BRAKE PEDAL RETURN SPRING	1	
32	F12	40283S010000	BRAKE PEDAL JOINT M6	1	
33	F12	55061P180000	BRAKE PUSH ROD	1	
34	F12	58430P180000	PROTECT BRACKET	1	
35	F12	B0702000060H	WASHER 6	2	
36	F12	B090002018AH	COTTER PIN 2×18	2	start Vin,ZBNP18002JB872139 Dec 15th 2017

F13 前挡泥板 FRONT FENDER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F13	65101P18F200	FRONT FEDER,GEM RED F2	1	F2
1	F13	65101P18BW00	FRONT FEDER,BLACK BW	1	BW
2	F13	B0284060150A	SCREW M6×15.2	6	
3	F13	47936S010000	NYLON WASHER	6	
4	F13	B02810501262	SCREW M5×0.8×12	4	
5	F13	65141P180000	FRONT FENDER FIXING BRACKET	2	
6	F13	65150P180000	FRONT FENDER LEFT FIXING BRACKET	1	
7	F13	65160P180000	FRONT FENDER RIGHT FIXING BRACKET	1	
8	F13	65106P18BG00	FRONT FEDER II,MATTE BLACK BG	1	
9	F13	05501P180000	LEONCINO LABEL	1	
10	F13	B0702000040H	WASHER 4	2	
11	F13	B0201030062H	SCREW M3×6	2	
12	F13	65836P160000	CLIP	1	


F14 护板 SIDE COVER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F14	65601P180010	LEFT SIDE COVER,GEM RED/MATTE BLACK F2/BG	1	F2
1	F14	65601P180020	LEFT SIDE COVERGEM BLACK/MATTE BLACK BW/BG	1	BW
2	F14	65602P180010	RIGHT SIDE COVER,GEM RED/MATTE BLACK F2/BG	1	F2
2	F14	65602P180020	RIGHT SIDE COVERGEM BLACK/MATTE BLACK BW/BG	1	BW
3	F14	B02830602562	SCREW M6×25	8	
4	F14	08513P250000	SPACER BUSH	8	
5	F14	65821S010000	RUBBER BLOCK	8	
6	F14	08012P160000	SCREW M5×16	10	
7	F14	65624P160000	CARD NUT M5	10	
8	F14	58381P180000	LEFT LABEL BRACKET	2	
9	F14	05511P180000	LEFT LABEL	2	
10	F14	65406P180000	UNDER COVER	1	
11	F14	08001B470000	SCREW	7	
12	F14	65709P18BG00	REAR FENDER UPPER II,MATTE BLACK BG	1	
13	F14	65701P18BG00	REAR FENDER UPPER I,MATTE BLACK BG	1	
14	F14	50015P18BG00	FUEL TANK LEFT COVER,MATTE BLACK BG	1	
15	F14	50016P18BG00	FUEL TANK RIGHT COVER,MATTE BLACK BG	1	
16	F14	08005J690000	SELF-TAPPING SCREW	2	
17	F14	65801S010000	CARD	2	
18	F14	58752P250000	BATTERY SPONGE CUSHION	2	
19	F14	05531P180000	FUEL TANK LABEL	2	
20	F14	58382P180000	DOUBLE-SIDED ADHESIVE	2	
21	F14	B0283060146H	SCREW M6×14	2	
22	F14	65723P180000	RUBBER	1	
23	F14	65436P180000	WIND DEFLECTOR	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
24	F14	B0284060150A	SCREW M6×15.2	3	
25	F14	51100P180000	SEAT ASSY	1	
26	F14	B0702000060H	WASHER Φ6	2	

F15 灯具 LIGHT ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F15	B01090606062	BOLT M6×60	1	same as B01090606062
2	F15	08305B400000	BUSH	2	
3	F15	80000P180000	HEAD LIGHT	1	
3	F15	80000P180010	HEAD LIGHT,with anti-fog coating	1	new
4	F15	B04810600052	NUT M6×1	5	
5	F15	81100P180000	FRONT LEFT TURN SIGNAL LIGHT	1	
6	F15	81300P180000	FRONT RIGHT TURN SIGNAL LIGHT	1	
7	F15	B0284060250A	STAINLESS SCREW M6×25	5	
8	F15	08513P250000	SPACER BUSH	2	
9	F15	65821S010000	RUBBER BLOCK	2	
10	F15	82015S010000	BUSH	6	
11	F15	81708S010000	RUBER BUSH 8×18×4×12×4×4	3	
12	F15	70000P180009	METER ASSY	1	
13	F15	81500P180000	REAR LEFT TURN SIGNAL LIGHT	1	
14	F15	81700P180000	REAR RIGHT TURN SIGNAL LIGHT	1	
15	F15	08001B470000	SELF-TAPPING SCREW	2	
16	F15	B0400100005H	NUT M10	2	
17	F15	82000P180000	TAIL LIGHT	1	
18	F15	47019K670000	SCREW W/WASHER	4	
19	F15	B02810602562	SCREW M6×25-8.8-ZG	4	
20	F15	59510P180000	WINDSHIELD LEFT BRACKET	1	
21	F15	59520P180000	WINDSHIELD RIGHT BRACKET	1	
22	F15	65503P180010	WINDSHIELD	1	BW
23	F15	80016P180000	HEAD LIGHT COVER	1	
24	F15	80026P180000	HEAD LIGHT BRACKET	1	


F16 COOLING SYSTEM ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F16	B0284060300A	SCREW M6×30	2	
2	F16	59452P250000	SPACER	2	
3	F16	65821S010000	RUBBER BLOCK	2	
4	F16	279126280030	RADIATOR ASSY	1	
5	F16	65117K670000	SCREW	4	
6	F16	06201P180000	RADIATOR DECORATIVE COVER	2	
7	F16	06102P180000	COOLANT RESERVE TANK INLET HOSE	1	
8	F16	65618J000000	RUBBER PAD	1	
9A	F16	06111P180001	COOLANT RESERVE TANK	1	start Vin ZBNP18002JB911568 March 27th 2018
10	F16	06113P180000	COOLANT RESERVE TANK CAP	1	
11	F16	06112P180000	COOLANT RESERVE TANK DECORATIVE BOARD	1	
12	F16	B0284060200A	SCREW M6×20	2	
13	F16	49650S010000	CLAMP 033.1-706R	2	
14	F16	06211P180000	INLET HOSE	1	
15	F16	270026110000	STAINLESS CLAMP	2	
16	F16	06251P180000	OUTLET HOSE	1	
17	F16	B02810801662	BOLT M8×16	1	
18	F16	B0700000080H	SPRING WASHER 8	1	
19	F16	58190P180000	RADIATOR FIXING BRACKET	1	
20	F16	169046280030	ENGINE LEFT REAR COVER	1	
21	F16	B02810603062	BOLT M6×30	4	
22	F16	45350P180000	ABS CLIP	1	
23	F16	B02810601262	SCREW M6×12-8.8-ZG	2	
24	F16	58393P180000	DOUBLE-SIDED ADHESIVE,CLUTH COVER LABEL I	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
25	F16	58391P180000	CLUTCH COVER LABEL I BRACKET	1	
26	F16	05597P180000	CLUTCH COVER LABEL I	1	
27	F16	05598P180000	CLUTCH COVER LABEL II	1	
28	F16	58392P180000	CLUTCH COVER LABEL II BRACKET	1	
29	F16	58394P180000	DOUBLE-SIDED ADHESIVE,CLUTH COVER LABEL II	1	
30	F16	65832P160000	CLIP	1	
31	F16	65518N100000	RUBBER BUSH	1	
32	F16	06224P250000	RESERVE TANK OVER FLOW PIPE	1	
33	F16	50306J690000	CLIP	1	
34	F16	50376S010000	CLIP Ø10	1	
35	F16	06140P180001	FIXING PLATE I	1	start Vin ZBNP18002JB911568 March 27th 2018
36	F16	06150P180001	FIXING PLATE II	1	start Vin ZBNP18002JB911568 March 27th 2018
37	F16	B0283060146H	SCREW M6×14	2	start Vin ZBNP18002JB911568 March 27th 2018


F17 电器 ELECTRICAL EQUIPMENT ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F17	95100P180000	HORN	1	
2	F17	B0283060146H	SCREW M6×14	8	
3	F17	59440P180000	HORN FIXING BRACKET	1	
4	F17	B02810801662	BOLT M8×16	1	
5	F17	91210P250000	SIDE TURN OFF	1	
6	F17	96007B720001	JACKET	1	
7	F17	B02830600862	BOLT M6×8	2	
8	F17	88900P180000	KEY NUT	1	
9	F17	58660P180000	ABS FIXING BRACKET	1	
10	F17	B02810601262	SCREW M6×12-8.8-ZG	5	
11	F17	57041P180000	BATTERY BOX BRACKET	1	
12	F17	65416P180000	BATTERY BOX	1	
13	F17	96100P160000	BATTERY	1	
14	F17	58752P250000	BATTERY SPONGE CUSHION	4	
15	F17	96700K060000	STARTER DIODE	2	
16	F17	92200P250001	POWER CABLE	1	
17	F17	B02810601662	SCREW M6×1×16	2	
18	F17	96C00P160001	ECU,AHO	1	
19	F17	08011P160000	SCREW M5×12	2	
20	F17	57360P180001	STARTER RELAY FIXING BRACKET	1	
21	F17	94000S010000	STARTER RELAY	1	
22	F17	57089J690000	FUSE BOX BRACKET	1	
23	F17	58820P250000	BATTERY BRACKET	1	
24	F17	96400H390001	FLASHER	1	
25	F17	57590P180000	RECTIFIER FIXING BRACKET	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
26	F17	299066060000	RECTIFIER	1	
27	F17	B02810603062	BOLT M6×30	2	
28	F17	92000P180002	WIRE HARNESS ASSY,AHO,EUROIV	1	
29	F17	92300P160000	MOTOR LINE	1	
30	F17	92500P160000	EARTH WIRE	1	
31	F17	40098B450000	BNAD	10	
32	F17	98901S010000	RUBBER	1	
33	F17	88000P180000	LOCK ASSY	1	
34	F17	B02260801662	SCREW M8×16	2	
35	F17	88101P180000	POWER LOCK COVER	1	
36	F17	88100P180000	MAIN LOCK	1	
37	F17	88400P180000	LOCK,FUEL TANK	1	
38	F17	58800P250000	BASE,SEAT LOCK,REAR	1	
39	F17	88800P250000	SEAT LOCK	1	
40	F17	57007P100000	SEAT CUSHION LOCK HOOK GUIDE PLATE	1	
41	F17	92940P100000	OBD WIRE	1	
42	F17	96004W020000	BAND	1	

F18 随车工具 TOOL KIT ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/U nit	NOTES
1	F18	02100N220001	TOOL KIT ASSY	1	