



F01 操纵 CONTROL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F01	40460P250100	LEFT VIEW MIRROR ASSY	1	
2	F01	40470P250100	REAR VIEW MIRROR ASSY	1	
3	F01	40101P260100	HANDLEBAR ASSY	1	
4	F01	B0284060400A	SCREW M6×40	2	
5	F01	40032P160000	GRIP END PRESSURE BLOCK	2	
6	F01	40031P160000	GRIP END	2	
7	F01	40032P250000	GRIP END MOUNTING SEAT	2	
8	F01	40001P250001	LEFT HANDLEBAR GRIP	1	
9	F01	40031S010000	GRIP END	2	
10	F01	40500P16000A	LEFT HANDLEBAR SWITCH	1	For vehicle vin before ZBNP16014KB986478
10	F01	40500P16000C	LEFT HANDLEBAR SWITCH	1	Only for Vin from ZBNP16014KB986478
11	F01	40600P160003	RIGHT HANDLEBAR SWITCH,AHO	1	
12	F01	40320P250001	THROTTLE CABLE HOUSING ASSY	1	
13	F01	40210P250002	RIGHT HANDLEBAR GRIP	1	
14	F01	40300P160000	THROTTLE CABLE ASSY I	1	
15	F01	40330P160000	THROTTLE CABLE ASSY II	1	
16	F01	40400P160000	CLUTCH CABLE ASSY	1	
17	F01	40080S01003Z	CLUTCH LEVER ASSY	1	For vehicle vin before ZBNP16014KB986478
17A	F01	40080P25000Z	CLUTCH LEVER ASSY	1	Only for Vin from ZBNP16014KB986478
18	F01	40023P250000	RUBBER CLIP	2	
19	F01	40706P250001	SCREW	1	
20	F01	58511S010000	SELF-LUBRICATING BUSHINGS	1	
21	F01	58216S010000	WASHER	1	
22	F01	40712P160001	BRAKE PEDAL ASSY	1	
23	F01	B0101060352H	BOLT M6×35	1	
24	F01	B0407060005H	NUT M6	1	
25	F01	B01820602562	BOLT M6×25-8.8-ZG	1	
26	F01	40720V300100	MOUNTING BRACKET	1	
27	F01	B04810600052	NUT M6×1	2	
28	F01	40283S010000	BRAKE PEDAL JOINT M6	1	
29	F01	B04800600052	NUT M6-8-ZG	1	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
30	F01	55061P120000	BRAKE PUSH ROD	1	
32	F01	40702P160000	REAR BRAKE RETURN SPRING	1	
33	F01	40273P250000	UPPER SPRING DOWEL	1	
34	F01	08370P160001	SHIFT PEDAL ASSY	1	
35	F01	B02810602562	SCREW M6×25-8.8-ZG	1	
36	F01	49371T620000	RUBBER BAND	3	
37	F01	91190P16000A	ABS SWITCH	1	
38	F01	58216S010000	WASHER	1	
39	F01	B0702000060H	WASHER 6	1	
40	F01	B02810602562	SCREW M6×25-8.8-ZG	2	
41	F01	B02810603062	BOLT M6×30	1	
42	F01	40088S010000	CLUTCH SWITCH	1	For vehicle vin before ZBNP16014KB986478
42A	F01	91090P250000	CLUTCH SWITCH	1	Only for Vin from ZBNP16014KB986478
43	F01	40084S010000	CLUTCH LEVER	1	For vehicle vin before ZBNP16014KB986478
43A	F01	40084P250001	CLUTCH LEVER	1	Only for Vin from ZBNP16014KB986478
44	F01	40081P250000	LEVER HOLDER	1	For vehicle vin before ZBNP16014KB986478
44A	F01	40081P250001	LEVER HOLDER	1	Only for Vin from ZBNP16014KB986478
45	F01	40087K010000	SLOTTED NUT	1	
46	F01	40086K010000	SPIRAL TUBE,ADJUSTING	1	


F02 前叉 FRONT FORK ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F02	B0205080256K	SCREW M8×25	4	
2	F02	43013P010000	UPPER HANDLEBAR HOLDER	2	For vehicle vin before ZBNP16015KBA56852
2	F02	43013P010001	UPPER HANDLEBAR HOLDER	2	Start vin ZBNP16015KBA56852
3	F02	43014P010000	LOWER HANDLEBAR HOLDER	2	
4	F02	47015P010000	DAMPER	4	
5	F02	40086P010000	HANDLEBAR STUD	2	Suggest order 40086P010002&08021P250000
5	F02	40086P010002	HANDLEBAR STUD	2	
6	F02	40089P010100	HANDLEBAR DOWEL WASHER $\phi 10.2 \times \phi 24.9 \times 2.5$	2	
7	F02	B04821012552	SELF-LOCKING NUT M10×1.25	2	
8	F02	B0281080256H	BOLT M8×1.25×25	2	
9	F02	43011P160000	UPPER BRACKET	1	
10	F02	43049P250000	STEERING STEM NUT	1	
11	F02	43008S010010	STEERING STEM HEAD NUT	1	
12	F02	43009P260000	STEERING STEM NUT	1	
13	F02	43005S010000	DUST SEAL	2	
14	F02	43130S010000	STEER BEARING	2	
15	F02	43100P160000	LOWER BRACKET ASSY	1	
16	F02	B02810601262	SCREW M6×12-8.8-ZG	1	
17	F02	43103S010000	LOCKING RING	1	
18	F02	B02830600862	BOLT M6×8	5	
19	F02	B02810602062	BOLT M6×1×20	6	
20	F02	43200P160101	FRONT LEFT SHOCK ABSORBER ASSY.	1	
21	F02	43300P160101	FRONT RIGHT SHOCK ABSORBER ASSY.	1	
22	F02	B02810603062	BOLT M6×30	2	
23	F02	B0205100306H	SCREW M10×30	4	
24	F02	B0284060200A	SCREW M6×20	2	
25	F02	43012P160000	UPPER BRACKET DECORATE COVER	1	
26	F02	45710P250000	FRONT WHEEL ROTATION SENSOR	1	
27	F02	43609P130000	SPRING GUIDE	2	
28	F02	43201P160000	DAMPER OUTER TUBE	2	
29	F02	43231P160001	DAMPER INNER TUBE	2	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
30	F02	43202P1800002	DAMPING SPRING	2	
31	F02	43321P160001	RIGHT MOUNTING BRACKET	1	
32	F02	43221P160001	LEFT MOUNTING BRACKET	1	
33	F02	43204P160000	BOLT	2	
34	F02	B190104870B0	O RING 48.7×2.65	2	
35	F02	43212P300000	DAMPER OUTER TUBE GUIDE BUSH	2	
36	F02	43239P010000	DAMPER INNER TUBE GUIDE BUSH	2	
37	F02	43681P160000	BOTTOM VALVE	2	
38	F02	43521P010000	OIL SEAL WASHER	2	
39	F02	43290P250000	DUST SEAL ASSY	2	
40	F02	43260P250000	OIL SEAL	2	
41	F02	43523P010000	OIL SEAL CLIP	2	
42	F02	43234P100010	SPRING SEAT	2	
43	F02	B02051002553	BOLT M10×25	2	
44	F02	B190104100B0	O RING Φ41×Φ2.65	2	
45	F02	08021P250000	WASHER	2	

F03 前轮 FRONT WHEEL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F03	44004P160100	FRONT WHEEL AXLE	1	
2	F03	B02810802062	BOLT M8×1.25×20	12	
3	F03	45030P180000	FRONT BRAKE DISC	2	
4	F03	44016P100100	FRONT WHEEL RIGHT COLLAR	1	
5	F03	44005P160100	FRONT WHEEL LEFT COLLAR	1	
7	F03	54013N020000	PROTECTOR TUBE	1	
8	F03	44100P160000	FRONT RIM ASSY	1	
9	F03	B140206E1900	TUBE 110/80 R19	1	
10	F03	45702P250000	ABS GEAR RING,FRONT WHEEL	1	
11	F03	B141106E1900	TIRE 110/80 R19	1	
12	F03	44011P160000	FRONT WHEEL OUTER SPOKE	18	
13	F03	44012P160000	FRONT WHEEL INNER SPOKE	18	
14	F03	44014P160000	NIPPLE	36	


F04 前液刹 FRONT DISK BRAKE ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F04	55140P260000	OIL CUP ASSY.	1	
2	F04	08012P160000	BOLT M5×16	1	
3	F04	55240P160001	REAR BRAKE HOSE ASSY.I,NEW	1	
4	F04	55270P160001	REAR BRAKE HOSE ASSY.II,NEW	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
5	F04	55400P16000A	BRAKE FLUID RESERVOIR	1	
6	F04	55500P100040	REAR BRAKE CALIPER	1	
7	F04	55110P100001	REAR BRAKE PADS	1	Qty/ Package: 2
8	F04	55300P180000	REAR BRAKE SWITCH	1	
9	F04	45078P300000	WASHER	19	
10	F04	45240P160002	FRONT BRAKE HOSE ASSY.I,NEW	1	
11	F04	45250P160001	FRONT BRAKE HOSE ASSY,III	1	
12	F04	45270P160001	FRONT BRAKE HOSE ASSY.II,NEW	1	
13	F04	45400P250012	FRONT MASTER CYLINDER	1	
14	F04	45500P180001	FRONT LEFT BRAKE CALIPER	1	
15	F04	45600P180001	FRONT RIGHT BRAKE CALIPER	1	
16	F04	45700P160000	ABS	1	
17	F04	B02810602062	SCREW M6×1×20	2	
18	F04	45110P180000	FRONT BRAKE PADS	1	Qty/ Package: 4
19	F04	45038P150000	BRAKE HOSE BANJO BOLT	1	
20	F04	55037P300000	BRAKE HOSE BANJO BOLT	4	
21	F04	B0281080256H	BOLT M8×1.25×25	4	
22	F04	45037J000000	SCREW	3	
23	F04	45024P300000	BRAKE LEVER PIVOT SCREW	1	
24	F04	B0700000080H	SPRING WASHER 8	2	
25	F04	45020P300000	FRONT BRAKE LEVER	1	
26	F04	B0417060004H	NUT M6	1	
27	F04	B0204040122H	SCREW M4×12	1	
28	F04	45300J000010	FRONT BRAKE SWITCH	1	
29	F04	45023P250000	FRONT BRAKE MASTER CYLINDER HOLDER	1	
30	F04	65836P160000	TUBE CLIP	1	
31	F04	55018P100000	PADS HOLDER	2	
32	F04	55099P100000	PADS WASHER	2	
33	F04	55098P100000	HEAT RESISTING PLATE	2	
34	F04	45011P180000	FRONT BRAKE PADS HOLDER	2	
35	F04	55078S070000	YOKE SPRING	2	

F05 消声器 MUFFLER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F05	47800P250000	EXHAUST PIPE GASKET ASSY	2	
2	F05	319026280000	OXYGEN SENSOR	2	
3	F05	B0407080005H	NUT M8	4	
4	F05	47500P160202	EXHAUST PIPE ASSY	1	
5	F05	47026P160000	SILENCER BUFFER RUBBER	1	
6	F05	B0205100306H	SCREW M10×30	1	
7	F05	48830P290000	CLAMP ASSY.	1	
8	F05	47200P160203	MUFFLER ASSY	1	
9	F05	47830P160002	CLAMP ASSY.	1	
10	F05	47027P160000	CYLINDER CUSHION RUBBER	1	
11	F05	47028P160000	CARTRIDGE CUSHION BUSHING	1	
12	F05	47029P160000	DECORATING COVER	1	
13	F05	47780P160002	REAR DECORATING COVER	1	
14	F05	B0218060126L	SCREW M6×12	6	
15	F05	B0700000060A	SPRING WASHER	6	
16	F05	47760P160002	FRONT DECORATING COVER	1	

F06 空滤器 AIR CLEANER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F06	49100P160000	AIR FILTER ASSY	1	
2	F06	B0109060166H	BOLT M6×16	2	
3	F06	310015040000	INTAKE AIR TEMPERATURE SENSOR	2	
4	F06	49016N070001	STAINLESS STEEL CLIP 40 - 60	2	
5	F06	49025P100000	EXHAUST GAS RECIRCULATION TUBEbe	1	
6	F06	49805J000000	PLATE CLAMP Φ18.5×10×1	2	
7	F06	49912K670000	CARBON CANISTER	1	
8	F06	50306T450010	PLATE CLAMP φ8	4	
9	F06	B16010425951	PIPE 4×8×595	1	
10	F06	50260T730003	VEHICLE DOWN SENSOR	1	
11	F06	B16010422901	PIPE 4×8×290	1	
12	F06	49710N070000	VALVE EGR/SOLENOID VALVE	1	
13	F06	50307J140002	PLATE CLAMP φ10	4	
14	F06	49922P160000	CANISTER&VALVE EGR PIPE	1	
15	F06	49923P160000	VALVE EGR&THROTTLE BODY	1	
16	F06	57050P160000	CANISTER FIXING BOARD	1	
17	F06	B0109060126H	BOLT M6×12	2	
18	F06	49202P160000	AIR CLEANER FILTER	1	
19	F06	82015S010010	BUSH H6	2	

F07 燃油箱 FUEL TANK ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F07	B0281060356H	SCREW M6×35	2	
2	F07	50138K980000	MOUNTING SEAT ASSY., SEAT	1	
3	F07	50222J000001	RUBBER SLEEVE	2	
4	F07	50221J000101	FUEL TANK MOUNTING COLLAR	2	
5	F07	50006K980000	RUBBER MAT	1	
6	F07	50100P160000	FUEL TANK ASSY.	1	
7	F07	50360P160000	FUEL PIPE ASSY I	1	
8	F07	65679V020000	FUEL TANK LOCK FIXING BOARD	1	
9	F07	B0283060146H	SCREW M6×14	2	
10	F07	B0109060166H	BOLT M6×16	2	
11	F07	50027P160000	FUEL TANK FRONT FIXING BOARD	1	
12	F07	50014P250010	FUEL TANK MOUNTING COLLAR	2	
13	F07	50005P250000	RUBBER CUSHION	2	
14	F07	B0702000060H	WASHER 6	2	
15	F07	B01820602562	BOLT M6×25-8.8-ZG	2	
16	F07	50800P160000	FUEL LEVEL SENSOR ASSY	1	
17	F07	50808P250010	FUEL LEVEL SENSOR SEAL RING	1	
18	F07	B0109050166H	BOLT M5×16	4	
19	F07	50400P160000	FUEL PUMP ASSY.	1	
20	F07	B0109050206H	BOLT M5×20	5	
21	F07	50340N070000	FUEL FILTER	1	
22	F07	50391N070000	FUEL FILTER JACKET	1	
23	F07	50090P160000	FUEL PIPE ASSY III	1	
24	F07	B160107C6001	PIPE 11×7×1260	1	
25	F07	B17010105003	CLIP Φ10.5	1	

F08 后摆臂 ARM AFTER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F08	53001P160100	REAR SWING ARM PIVOT SHAFT M20×1.5×314	1	
2	F08	53006P100100	REAR SWING ARM SPACER	2	
3	F08	53220P100000	SEAL RING ASSY 25×37×7	2	
4	F08	B08000003701	CIRCLIP φ37	2	
5	F08	B1210H490400	NEEDLE BEARING NA4904	2	
6	F08	B12016190400	BALL BEARING61904-2RS	2	
7	F08	53005P100100	REAR SWING ARM MIDDLE SHAFT SLEEVE	1	
8	F08	08051P100100	NUT M20×1.5	1	
9	F08	53100P160001	REAR SWING ARM ASSY	1	
10	F08	53004P100000	CHAIN SHIELD BLOCK	1	
11	F08	B0284060150A	SCREW M6×15.2	4	
12	F08	53022P100000	SPACER	2	
13	F08	53018P100000	UPPER CHAIN LIMITED BLOCK	1	
14	F08	B02810603062	BOLT M6×30	2	
15	F08	53021P250000	BUSH	2	
16	F08	B0283060146H	SCREW M6×14	3	
17	F08	08011M150002	BOLT M12×75	1	
18	F08	B0417121254H	NUT M12×1.25	2	
19	F08	63800P160004	REAR ABSORBER ASSY	1	
20	F08	08018P160001	REAR ABSORBER BOLT M12×1.25×65	1	
21	F08	B0407080005H	NUT M8	2	
22	F08	08002P300010	SCREW M8	2	
23	F08	53231P100001	DRIVE CHAIN PULLER	2	
24	F08	43025J010050	WASHER	2	
25	F08	55710P250000	REAR WHEEL ROTATION SENSOR	1	
26	F08	B0109060166H	BOLT M6×16	3	
27	F08	60101P160001	DRIVE CHAIN COVER	1	

F09 后轮 REAR WHEEL ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F09	54004P100100	REAR WHEEL AXLE	1	
2	F09	54016P160001	REAR WHEEL LEFT COLLAR	1	
3	F09	B04821012552	SELF-LOCKING NUT M10×1.25	6	
4	F09	60002P310000	REAR WHEEL SPROCKET 44TH	1	
5	F09	60310P160011	CHAIN 525SX-1×116	1	
6	F09	60001P16000Z	REAR WHEEL DRIVE HUB	1	
7	F09	B0159100306H	BOLT M10×1.25×30,SILVER	6	
8	F09	54100P16000Z	REAR RIM ASSY	1	
9	F09	54013P160000	PROTECTOR TUBE	1	
10	F09	B141110D170Z	TIRE&TUBE 150/70 R17	1	
11	F09	54005P160001	REAR WHEEL RIGHT COLLAR	1	
12	F09	55030P180001	REAR BRAKE DISC	1	
13	F09	B0282060208H	SCREW M6×20	6	
14	F09	55401P160000	REAR BRAKE CALIPER MOUNTING BRACKET ASSY	1	
15	F09	B0281080256H	BOLT M8×1.25×25	2	
16	F09	08051P100100	NUT M20×1.5	1	
17	F09	B140210D1700	TUBE 150/70 R17	1	
18	F09	B141110D1700	TIRE 150/70 R17	1	
19	F09	54024P160000	REAR WHEEL DRIVE HUB DAMPER	6	
20	F09	B12016020500	BEARING 6205-2RS	1	
21	F09	54300P160000	OIL SEAL ASSY	2	
22	F09	60006P160000	REAR WHEEL AXLE SLEEVE	1	
23	F09	54006P100100	REAR WHEEL SPACER	1	
24	F09	B12016030400	BEARING 6304-2RS	2	
25	F09	54011P160000	REAR WHEEL LEFT OUTER SPOKE	9	
26	F09	54012P160000	REAR WHEEL LEFT INNER SPOKE	9	
27	F09	54033P160000	REAR WHEEL RIGHT SPOKE	18	
28	F09	44014P160000	NIPPLE	36	


F10 前车架 FRAME ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F10	57110P16BH02	FRAME ASSY,EXTRA BLACK BH	1	
2	F10	B0159100506H	BOLT M10×1.25×50,SILVER	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
3	F10	B0417101254H	SELF-LOCKING NUT M10×1.25,SILVER	6	
4	F10	B01591007562	BOLT M10×1.25×75	1	
5	F10	59110P160100	FRONT LEFT GUARD BAR ASSY	1	
6	F10	B0205080206H	SCREW M8×20	2	
7	F10	B02050806024	SCREW M8×60	2	
8	F10	B0159101306H	BOLT M10×1.25×130,SILVER	1	
9	F10	57060P130000	DAMPER	2	
10	F10	57028P160100	LEFT BUSH	1	
11	F10	57029P160100	RIGHT BUSH	1	
12	F10	B0159101256H	BOLT M10×1.25×125	1	
13	F10	59120P160100	FRONT RIGHT GUARD BAR ASSY	1	
14	F10	B0159100686H	BOLT M10×1.25×68	2	
15	F10	B0109060166H	BOLT M6×16	5	
16	F10	08100P160000	HORN MOUNTING BRAKET	1	
17	F10	57041P160000	RADIATOR LEFT MOUNTING BOARD	1	
18	F10	57042P160000	RADIATOR RIGHT MOUNTING BOARD	1	
20	F10	B100432007P0	RIVET 3.2×7	2	
21	F10	43504E070001	DAMPER	2	
22	F10	59400P160100	BRAKCET ASSY	1	
23	F10	65803S010010	CARD NUT M6	7	
24	F10	B02810801662	BOLT M8×16	4	
25	F10	57480P160000	FIXING SEAT	1	
26	F10	B0159100206H	BOLT M10×1.25×20	2	
27	F10	59460P16000Z	WINDLESHIELD MOUNTING BRACKET	1	
28	F10	B0109080166H	BOLT M8×16,SILVER	2	
29	F10	B0700000080H	SPRING WASHER 8	2	
30	F10	B0109080206H	BOLT M8×20,SILVER	2	
31	F10	53018P160000	RUBBER	1	
32	F10	08014P160000	BOLT M10×17	1	
33	F10	B0417060004H	NUT M6	1	
34	F10	B0109060356H	BOLT M6×35	1	

F11 后车架 FRAME ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F11	57120P16BH02	REAR FRAME ASSY,EXTRA BLACK BH	1	
2	F11	B0109100256H	BOLT M10×25,SILVER	2	
3	F11	B0159100306H	BOLT M10×1.25×30,SILVER	2	
4	F11	B0417101254H	SELF-LOCKING NUT M10×1.25,SILVER	2	
5	F11	B0109060166H	BOLT M6×16	2	
6	F11	08430P250000	CLIP ASSY	1	
7	F11	52001J000000	PLUG	2	
8	F11	52018J800000	BOLT M8×25	2	
9	F11	08001J820000	GRAB RAIL SCREW M8×45	2	
10	F11	52100P160000	REAR CARRIER	1	
11	F11	65780P160000	REAR TURN SIGNAL MOUNTING BRACKET	1	
12	F11	08023P250000	WASHER Φ10.5×Φ19×0.8	2	
13	F11	81500P160001	REAR LEFT TURN SIGNAL LIGHT	1	
14	F11	81700P160001	REAR RIGHT TURN SIGNAL LIGHT	1	
15	F11	08301P160000	TAIL LIGHT MOUNTING BOARD	1	
16	F11	58306P160000	PROTECT RUBBER JACKET	2	
17	F11	57015P160000	FRAME PLUG I	2	
18	F11	57016P160000	FRAME PLUG II	2	
19	F11	02131P160000	TOOL KIT BOX	1	
20	F11	B0109060126H	BOLT M6×12	2	

F11_1 后车架 (带边箱支架) FRAME ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F11_1	57120P16BH02	REAR FRAME ASSY,EXTRA BLACK BH	1	
2	F11_1	B0109100256H	BOLT M10×25,SILVER	2	
3	F11_1	B0159100306H	BOLT M10×1.25×30,SILVER	2	
4	F11_1	B0417101254H	SELF-LOCKING NUT M10×1.25,SILVER	2	
5	F11_1	B0109060166H	BOLT M6×16	2	
6	F11_1	08430P250000	CLIP ASSY	1	
7	F11_1	52001J000000	PLUG	2	
8	F11_1	52018J800000	BOLT M8×25	2	
9	F11_1	08001J820000	GRAB RAIL SCREW M8×45	2	
10	F11_1	52100P160000	REAR CARRIER	1	
11	F11_1	65780P160000	REAR TURN SIGNAL MOUNTING BRACKET	1	
12	F11_1	08023P250000	WASHER Φ10.5×Φ19×0.8	2	
13	F11_1	81500P160001	REAR LEFT TURN SIGNAL LIGHT	1	
14	F11_1	81700P160001	REAR RIGHT TURN SIGNAL LIGHT	1	
15	F11_1	08301P160000	TAIL LIGHT MOUNTING BOARD	1	
16	F11_1	58306P160000	PROTECT RUBBER JACKET	2	
17	F11_1	57015P160000	FRAME PLUG I	2	
18	F11_1	57016P160000	FRAME PLUG II	2	
19	F11_1	52700P160004	LEFT SIDE BOX BRAK CET ASSY	1	
20	F11_1	52711P160005	CONNECTING ROD	1	
21	F11_1	52718P160001	BUSH	4	
22	F11_1	52800P160004	RIGHT SIDE BOX BRAK CET ASSY	1	
23	F11_1	B0109080406H	BOLT M8×40	4	
24	F11_1	B0109080166H	BOLT M8×16,SILVER	2	
25	F11_1	B02810803062	BOLT M8×1.25×30	2	
26	F11_1	B0417080004H	NUT M8	2	
27	F11_1	02131P160000	TOOL KIT BOX	1	
28	F11_1	B0109060126H	BOLT M6×12	2	

F12 脚蹬 PEDAL ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F12	58226P160000	LEFT FRONT FOOTREST BRACKET	1	
2	F12	58217P160000	FOOTREST MOUNTING PIN,with hole	2	
3	F12	58256P160000	FIXING BORAD	2	
4	F12	58220P160001	LEFT FRONT FOOTREST ASSY	1	
5	F12	B090002018AH	COTTER PIN 2×18	4	
6	F12	B02810802062	BOLT M8×1.25×20	4	
7	F12	58246P160000	RIGHT FRONT FOOTREST BRACKET	1	
8	F12	58240P160001	RIGHT FRONT FOOTREST ASSY	1	
9	F12	58452P16C800	LEFT REAR FOOTREST BRACKET,SILVER C8	1	
10	F12	B02810801662	BOLT M8×16	4	
11	F12	58217P100000	FOOTREST MOUNTING PIN	2	
12	F12	B0280040100A	SCREW M4×10	2	
13	F12	58205S020000	LEFT FOOTREST RUBBER PAD	1	
14	F12	08352S020000	LEFT FOOTREST RUBBER	1	
15	F12	58202D010000	SPRING	2	
16	F12	58222B930000	FRONT FOOTREST SPRING	2	
17	F12	B06000002000	REAR FOOTREST BALL	2	
18	F12	58451S010000	FOOTREST BRACKET PLATE	2	
19	F12	58266S010000	LEFT REAR FOOTREST	1	
20	F12	58405S020000	RIGHT FOOTREST RUBBER PAD	1	
21	F12	08372S020000	RIGHT PEDAL RUBBER	1	
22	F12	58472P16C800	RIGHT REAR FOOTREST BRACKET,SILVER C8	1	
23	F12	58286S010000	RIGHT REAR PEDAL	1	
24	F12	B0703000060A	WASHER Φ6	4	

F13 单撑 MAIN STAND ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F13	57005P280000	SIDE STAND MOUNTING SCREW	1	
2	F13	08021P250000	SIDE STAND MOUNTING WASHER	1	
3	F13	58700P250003	SIDE STAND ASSY	1	
4	F13	B02830600862	BOLT M6×8	1	
5	F13	B0703000060H	WASHER 6	1	
6	F13	57405P280000	SIDE STAND MOUNTING BRACKET	1	
7	F13	B02810501262	SCREW M5×0.8×12	2	
8	F13	91170P16000A	SWITCH ,FLAMEOUT,SIDE STAND	1	
9	F13	B07000001204	SPRING WASHER 12	1	
10	F13	B04031212514	NUT M12×1.25	1	
11	F13	57003P250000	SIDE STAND OUTER SPRING	1	
12	F13	57004S010000	SIDE STAND INNER SPRING	1	
13	F13	B0205100406H	HEXAGON SCREW M10×40	1	
14	F13	B0205100606H	HEXAGON SCREW M10×60	1	
15	F13	B0217100306H	SCREW M10×1.25×30	2	
16	F13	58520P160000	MID STAND ASSY	1	
17	F13	57010D010000	SPRING,SIDE STAND	2	
18	F13	58509P160000	SCREW SLEEVE	2	
19	F13	169143540000	BUFFER BLOCK,MAIN STAND	1	
20	F13	58730P290000	FIXING SEAT	1	
21	F13	91171P290000	DECORATIVE COVER	1	
22	F13	B0284060150A	SCREW M6×15.2	2	

F14 前挡泥板 FRONT FENDER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F14	65101P16BA00	FRONT FENDER I,SATIN BLACK BA,WITHOUT STICKER	1	
2	F14	B0284060150A	SCREW M6×15.2	6	
3	F14	47936S010000	NYLON WASHER	4	
4	F14	65131P160001	FRONT FENDER BRACKET I	2	
5	F14	B02810501262	SCREW M5×0.8×12	4	
6	F14	65141P160001	FRONT FENDER BRACKET II	2	
7	F14	86300J000002	SIDE RELECTOR	2	
8	F14	B02180501262	SCREW M5×12	1	
9	F14	B0700000050L	SPRING WASHER 5	1	
10	F14	B0703000050A	WASHER Φ5	1	
11	F14	08053G120100	NUT	1	
12	F14	65150P160000	FRONT FENDER II	1	
13	F14	B02810501462	SCREW M5×0.8×14	6	
14	F14	65105S040000	T BUSHING 5×7×6×10×0.8	2	
15	F14	B0400050005H	NUT M5	2	
16	F14	65108P160000	FRONT FENDER LEFT DECORATE BOARD	1	
17	F14	65116P160000	FRONT FENDER RIGHT DECORATE BOARD	1	
18	F14	65102P16000A	FRONT INNER FENDER	1	

F15 前护罩 FRONT SHIELD ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F15	65503P160002	WINDSHIELD	1	
2	F15	B0284060250A	BOLT M6×25	8	
3	F15	65517K320100	SPACER	10	
4	F15	81708S010000	RUBER BUSH 8×18×4×12×4×4	10	
5	F15	70000P160000	METER ASSY	1	
6	F15	B04810600052	NUT M6×1	4	
7	F15	65204P160000	LEFT WINDSHIELD	1	
8	F15	65205P160000	RIGHT WINDSHIELD	1	
9	F15	B0284060250A	BOLT M6×25	2	
10	F15	65216P160000	LEFT PROTECT COVER	1	
11	F15	65218P160001	LEFT CONNECTING BOARD	1	
12	F15	08012P160000	BOLT M5×16	2	
13	F15	65006D010000	SPACER	2	
14	F15	65624P160000	CARD NUT M5	12	
15	F15	65217P160000	RIGHT PROTECT COVER	1	
16	F15	65219P160001	RIGHT CONNECTING BOARD	1	
17	F15	65201P16BA00	HEAD LIGHT PROTECT COVER,SATIN BLACK BA	1	
18	F15	08011P160000	SCREW M5×12	17	
19	F15	65203P16BA00	METER VISOR,SATIN BLACK BA	1	
20	F15	80000P160001	HEAD LIGHT	1	
21	F15	B0109060256H	BOLT M6×25	3	
22	F15	14003S040010	BUSH	3	
23	F15	65821S010000	RUBBER BLOCK	3	
24	F15	65315P160000	METER MOUNTING BOARD	1	
25	F15	B240137200F0	BUBL 12V55W-H7	2	
26	F15	80110S010001	SPRING	2	

F16 前大罩 FRONT COVER ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F16	65301P16BA00	FRONT FACEPLATE,SATIN BLACK BA,WITH STICKER	1	
2	F16	B0284060250A	BOLT M6×25	4	
3	F16	14003S040010	BUSH	4	
4	F16	65821S010000	RUBBER BLOCK	4	
5	F16	08011P160000	SCREW M5×12	10	
6	F16	65624P160000	CARD NUT M5	18	
7	F16	65316P160000	LEFT CONECTING BOARD	1	
8	F16	65317P160000	RIGHT CONNECTING BOARD	1	
9	F16	B0507420130H	TAPPING SCREW ST4.2×13	4	
10	F16	65318P160000	LEFT BARBED WIRE	1	
11	F16	65319P160000	RIGHT BARBED WIRE	1	
12	F16	65303P16WF00	FRONT FACEPLATE LEFT DECORATE COVER,WHITE WF,WITHOUT STICKER	1	
12	F16	65303P16TL00	FRONT FACEPLATE LEFT DECORATE COVER,RED TL,WITHOUT STICKER	1	
12	F16	65303P16JH00	FRONT FACEPLATE LEFT DECORATE COVER,DARK GREY JH,WITHOUT STICKER	1	
13	F16	65309P16WF00	FRONT FACEPLATE RIGHT DECORATE COVER,WHITE WF,WITHOUT STICKER	1	
13	F16	65309P16TL00	FRONT FACEPLATE RIGHT DECORATE COVER,RED TL,WITHOUT STICKER	1	
13	F16	65309P16JH00	FRONT FACEPLATE RIGHT DECORATE COVER,DARK GREY JH,WITHOUT STICKER	1	
14	F16	08023P250000	WASHER Φ10.5×Φ19×0.8	2	
15	F16	81100V020000	FRONT LEFT TURN SIGNAL LIGHT	1	
16	F16	81300V020000	FRONT RIGHT TURN SIGNAL LIGHT	1	
17	F16	65305P16BA00	LEFT AIR VENTS,SATIN BLACK BA	1	
18	F16	65306P16BA00	RIGHT AIR VENTS,SATIN BLACK BA	1	
19	F16	08012P160000	BOLT M5×16	2	
20	F16	05521B450000	BENELLI LABEL	1	

F17 油箱护板 FUEL TANK COVER




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F17	65672P16BA00	FUEL TANK MIDDLE COVER,SATIN BLACK BA,WITHOUT STICKER	1	
2	F17	B0284060250A	BOLT M6×25	1	
3	F17	14003S040010	BUSH	1	
4	F17	65821S010000	RUBBER BLOCK	1	
5	F17	B0284060150A	SCREW M6×15.2	1	
6	F17	08011P160000	SCREW M5×12	20	
7	F17	65624P160000	CARD NUT M5	14	
8	F17	65673P16WF00	FUEL TANK LEFT SIDE COVER,WHITE WF,WITHOUT STICKER	1	
8	F17	65673P16TL00	FUEL TANK LEFT SIDE COVER,RED TL,WITHOUT STICKER	1	
8	F17	65673P16JH00	FUEL TANK LEFT SIDE COVER,DARK GREY JH,WITHOUT STICKER	1	
8	F17	65673P16001Z	FUEL TANK LEFT SIDE COVER,WHITE WF,WITH STICKER	1	
8	F17	65673P16002Z	FUEL TANK LEFT SIDE COVER,RED TL,WITH STICKER	1	
8	F17	65673P16003Z	FUEL TANK LEFT SIDE COVER,DARK GREY JH,WITH STICKER	1	
9	F17	65674P16WF00	FUEL TANK RIGHT SIDE COVER,WHITE WF,WITHOUT STICKER	1	
9	F17	65674P16TL00	FUEL TANK RIGHT SIDE COVER,RED TL,WITHOUT STICKER	1	
9	F17	65674P16JH00	FUEL TANK RIGHT SIDE COVER,DARK GREY JH,WITHOUT STICKER	1	
9	F17	65674P16001Z	FUEL TANK RIGHT SIDE COVER,WHITE WF,WITH STICKER	1	
9	F17	65674P16002Z	FUEL TANK RIGHT SIDE COVER,RED TL,WITH STICKER	1	
9	F17	65674P16003Z	FUEL TANK RIGHT SIDE COVER,DARK GREY JH,WITH STICKER	1	
10	F17	65675P160000	FUEL TANK LEFT UNDER COVER	1	
11	F17	65676P160000	FUEL TANK RIGHT UNDER COVER	1	
12	F17	08012P160000	BOLT M5×16	2	
13	F17	65691P160000	FRAME LEFT DECORATE BOARD	1	
14	F17	65692P160000	FRAME RIGHT DECORATE BOARD	1	
15	F17	B0283060146H	SCREW M6×14	2	
16	F17	47936S010000	NYLON WASHER	3	

F18 散热器导流板 RADIATOR GUIDE PLATE ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F18	65681P160000	RADIATOR FRONT COVER	1	
2	F18	08012P160000	BOLT M5×16	5	
3	F18	65624P160000	CARD NUT M5	21	
4	F18	65685P160000	RADIATOR PLATE	1	
5	F18	65682P160000	RADIATOR REAR PLATE	1	
6	F18	65683P160000	RADIATOR LEFT PROTECT PLATE	1	
7	F18	65684P160000	RADIATOR RIGHT PROTECT PLATE	1	
8	F18	08011P160000	SCREW M5×12	16	
9	F18	65307P16BA00	LEFT REAR AIR VENTS,SATIN BLACK BA	1	
10	F18	65308P16BA00	RIGHT REAR AIR VENTS,SATIN BLACK BA	1	
11	F18	B0284060250A	BOLT M6×25	4	
12	F18	14003S040010	BUSH	4	
13	F18	65821S010000	RUBBER BLOCK	4	
14	F18	65621P160000	LEFT FRONT PROTECT BOARD	1	
15	F18	65622P160000	RIGHT FRONT PROTECT BOARD	1	
16	F18	65632P16WF00	LEFT FRONT SIDE COVER,WHITE WF,WITHOUT STICKER	1	
16	F18	65632P16TL00	LEFT FRONT SIDE COVER,RED TL,WITHOUT STICKER	1	
16	F18	65632P16JH00	LEFT FRONT SIDE COVER,DARK GREY JH,WITHOUT STICKER	1	
17	F18	65633P16WF00	RIGHT FRONT SIDE COVER,WHITE WF,WITHOUT STICKER	1	
17	F18	65633P16TL00	RIGHT FRONT SIDE COVER,RED TL,WITHOUT STICKER	1	
17	F18	65633P16JH00	RIGHT FRONT SIDE COVER,DARK GREY JH,WITHOUT STICKER	1	
18	F18	B02810601462	BOLT M6×14	4	


F19 护板 FEAME COVER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F19	65601P160000	LEFT SIDE COVER	1	
2	F19	65602P160000	RIGHT SIDE COVER	1	
3	F19	08011P160000	SCREW M5×12	26	
4	F19	65624P160000	CARD NUT M5	18	
5	F19	43038P250000	RUBBER BUSH	8	
6	F19	65901P16WF00	LEFT TAIL COVER,WHITE WF,WITHOUT STICKER	1	
6	F19	65901P16TL00	LEFT TAIL COVER,RED TL,WITHOUT STICKER	1	
6	F19	65901P16JH00	LEFT TAIL COVER,DARK GREY JH,WITHOUT STICKER	1	
7	F19	65902P16WF00	RIGHTT TAIL COVER,WHITE WF,WITHOUT STICKER	1	
7	F19	65902P16TL00	RIGHTT TAIL COVER,RED TL,WITHOUT STICKER	1	
7	F19	65902P16JH00	RIGHTT TAIL COVER,DARK GREY JH,WITHOUT STICKER	1	
8	F19	B0284060250A	BOLT M6×25	4	
9	F19	14003S040010	BUSH	4	
10	F19	65821S010000	RUBBER BLOCK	6	
11	F19	65911P160000	LEFT LOWER REAR COVER	1	
12	F19	65912P160001	RIGHT LOWER REAR COVER	1	
13	F19	51100P160001	FRONT SEAT ASSY	1	For Q19-01 Thailand & Q19-12 Malaysia market
14	F19	51200P160001	REAR SEAT ASSY	1	
15	F19	B01820601462	BOLT M6×14	2	
16	F19	65605P16BA00	UPPER CONNECT BOARD,SATIN BLACK	1	
17	F19	65606P16BA00	UNDER CONNECT BOARD,SATIN BLACK	1	
18	F19	82000P160000	TAIL LIGHT	1	
19	F19	08013P160000	BOLT M6×22	1	
20	F19	B0407060005H	NUT M6	2	
21	F19	65697P160000	LEFT DECORATIVE BOARD II	1	
22	F19	65698P160000	RIGHT DECORATIVE BOARD II	1	
23	F19	B02810602062	BOLT M6×1×20	3	
24	F19	65693P160000	FRAME LEFT BOARD	1	
25	F19	65690P160000	FRAME RIGHT BOARD	1	
26	F19	65695P16000A	CONNECT BOARD	1	
27	F19	58211P160000	LEFT COVER	1	



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
28	F19	58311P160000	RIGHT COVER	1	
29	F19	B0282060208H	SCREW M6×20	4	
30	F19	58307B450000	SPACER	4	
31	F19	65406P160000	ENGINE COVER	1	
32	F19	57043P160000	MOUNTING BRACKET	1	
33	F19	65625J560000	CARD NUT M6	4	
34	F19	B02830601262	SCREW M6×12	4	
35	F19	05592T430000	WEIGHT LIMIT STICKER	1	

F20 后泥板 REAR FENDER ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F20	65731P16000A	REAR FENDER FORESIDE	1	
2	F20	65624P160000	CARD NUT M5	4	
3	F20	B02830600862	BOLT M6×8	2	
4	F20	65801T020201	INSERT ST4.2	4	
5	F20	08011P160000	SCREW M5×12	1	
6	F20	B0205060406A	SCREW M6×40	2	
7	F20	65770P160000	REAR FENDER BRACKET	1	
8	F20	65701P160001	REAR FENDER	1	
9	F20	51103V030000	RUBBER PLUG	1	
10	F20	86500B720001	REAR REFLECTOR	1	
11	F20	08202P160001	REAR LICENCE BRACKET	1	
13	F20	B0109060126H	BOLT M6×12	4	
14	F20	B04810600052	NUT M6×1	5	
15	F20	65761P16BG00	REAR FENDER UNDERPART,MATT BLACK	1	
16	F20	B0284060250A	BOLT M6×25	3	
17	F20	B0283060146H	SCREW M6×14	2	
18	F20	65703P160000	REAR FENDER RUBBER	1	

F21 COOLING SYSTEM ASSY.



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F21	B0109060256H	BOLT M6×25	1	
2	F21	59452P250000	SPACER	1	
3	F21	65821S010000	RUBBER BLOCK	2	
4	F21	279126280020	RADIATOR	1	
5	F21	270011170000	DAMPER	2	
6	F21	14039S040000	PIPE	1	
7	F21	14030S040000	RESERVE TANK CAP	1	
8	F21	06111P250000	RESERVE TANK	1	
9	F21	B0109060126H	BOLT M6×12	2	
10	F21	43038P250000	RUBBER BUSH	1	
11	F21	06224P250000	RESERVE TANK OVER FLOW PIPE	1	
12	F21	06226P250000	OVER FLOW PIPE	1	
13	F21	50376S010000	CLIP 10	2	
14	F21	06223P160000	RADIATOR OVER FLOW PIPE	1	
15	F21	06103P160000	CLAMP 32	2	
16	F21	06211P100000	INLET HOSE	1	
17	F21	06251P160000	OUTLET HOSE	1	
18	F21	49650S010000	CLAMP 033.1-706R	2	
19	F21	169046280000	ENGINE LEFT REAR COVER	1	
20	F21	B0107060306H	BOLT M6×30	4	
21	F21	270786280000	RADIATOR FAN ASSY	1	
22	F21	B0101060102H	BOLT M6×10	4	
23	F21	B0700000060H	SPRING WASHER 6	4	
24	F21	B0703000060H	WASHER 6	4	
26	F21	279185050000	RADIATOR CAP,SILVER	1	


This exploded view diagram illustrates the assembly of a vehicle chassis. The central component is the chassis frame, which includes the front and rear crossmembers and longitudinal rails. Key components shown include:

- Engine and Drivetrain:** An engine (1) is mounted to the front crossmember via a bracket (2). A transmission (3) is mounted to the rear crossmember. A drive shaft (16) connects the transmission to the rear axle.
- Suspension and Steering:** The front suspension features a steering knuckle (4) with a ball joint (5) and a shock absorber (6). The rear suspension includes a trailing arm (7) and a shock absorber (8). A steering rack (9) is mounted to the front crossmember.
- Braking System:** A master cylinder (10) is mounted to the front crossmember. A brake booster (11) is mounted to the rear crossmember. A brake line (12) connects the master cylinder to the rear brake assembly (13).
- Electrical System:** A battery (14) is mounted to the chassis. A fuse block (15) is mounted to the front crossmember. A wiring harness (17) is connected to the battery and the fuse block. A fuel filter (18) is mounted to the chassis.
- Other Components:** A fuel tank (19) is mounted to the chassis. A fuel line (20) connects the fuel tank to the engine. A fuel pump (21) is mounted to the fuel line. A fuel filter (22) is mounted to the fuel line. A fuel nozzle (23) is mounted to the fuel line. A fuel hose (24) connects the fuel nozzle to the fuel filter. A fuel hose (25) connects the fuel filter to the fuel pump. A fuel hose (26) connects the fuel pump to the fuel tank. A fuel hose (27) connects the fuel tank to the fuel filter. A fuel hose (28) connects the fuel filter to the fuel pump. A fuel hose (29) connects the fuel pump to the fuel tank. A fuel hose (30) connects the fuel tank to the fuel filter. A fuel hose (31) connects the fuel filter to the fuel pump. A fuel hose (32) connects the fuel pump to the fuel tank. A fuel hose (33) connects the fuel tank to the fuel filter. A fuel hose (34) connects the fuel filter to the fuel pump. A fuel hose (35) connects the fuel pump to the fuel tank. A fuel hose (36) connects the fuel tank to the fuel filter. A fuel hose (37) connects the fuel filter to the fuel pump. A fuel hose (38) connects the fuel pump to the fuel tank. A fuel hose (39) connects the fuel tank to the fuel filter. A fuel hose (40) connects the fuel filter to the fuel pump. A fuel hose (41) connects the fuel pump to the fuel tank. A fuel hose (42) connects the fuel tank to the fuel filter. A fuel hose (43) connects the fuel filter to the fuel pump. A fuel hose (44) connects the fuel pump to the fuel tank.

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F22	95100P160001	HORN	1	
2	F22	B02810801662	BOLT M8×16	1	
3	F22	96350P160001	METER CONVERTER	1	
4	F22	299066060000	RECTIFIER	1	
5	F22	B0109060306H	BOLT M6×30	2	
6	F22	94000S010000	STARTER RELAY	1	
7	F22	91210N300000	ROLL OVER SENSOR	1	
8	F22	96C00P160001	ECU	1	
11	F22	96400H390001	FLASHER	1	
12	F22	96700K060000	STARTER DIODE	1	
13	F22	88000P160000	LOCK ASSY	1	
14	F22	B0201060252H	SCREW M6×25	2	
15	F22	B02260801662	SCREW M8×16	2	
15	F22	B0226080206H	SCREW M8×20	2	
16	F22	92950H380001	USB ASSY	1	
17	F22	58900P160000	SEAT LOCK CABLE ASSY	1	
18	F22	96007J040001	BUSH,IGNITOR	1	
19	F22	92000P160008	WIRE HARNESS ASSY	1	
20	F22	92200P160000	POWER CABLE	1	
21	F22	92300P160000	MOTOR LINE	1	
22	F22	92500P160000	EARTH WIRE	1	
23	F22	96100P160000	BATTERY	1	
24	F22	58752P250000	BATTERY SPONGE CUSHION	8	
25	F22	96002J000000	BAND 200MM	8	
26	F22	40098B450000	BNAD	10	
27	F22	96003P250000	RUBBER CLIP	2	
28	F22	58430J000000	CLIP ASSY	5	
29	F22	02200J0000A0	BATTERY BAND	1	
30	F22	98901S010000	RUBBER	1	
31	F22	88900P25092X	KEY NUT	1	
32	F22	88100P160000	POWER LOCK	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
33	F22	88400V020001	FUEL TANK LOCK	1	
34	F22	58800S010000	SEAT LOCK SEAT	1	
35	F22	88800T420000	SEAT LOCK	1	
36	F22	B02810501462	SCREW M5×0.8×14	2	
37	F22	96010P160000	BAND CARD	1	
38	F22	92940P100000	OBD WIRE	1	
39	F22	92039S010000	RELAY,HEADLIGHT	5	
40	F22	02120J690000	BAND ASSY,TOOL KIT	1	
41	F22	58670P160000	ABS BRACKET	1	
42	F22	B0109060166H	BOLT M6×16	3	
43	F22	B0700000080H	SPRING WASHER 8	2	
44	F22	08013P100000	BOLT M6×16	1	

F23 随车工具 TOOL KIT ASSY.




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F23	02100P250010	TOOL KIT ASSY	1	

F24 STICKER (FOR WHITE WF)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F24	05512P16WF02	TRK STICKER,RIGHT FRONT PROTECT BOARD,WF	1	
2	F24	05511P16WF02	TRK STICKER,LEFT FRONT PROTECT BOARD,WF	1	
3	F24	05513P16WF02	502X STICKER,WF	2	
4	F24	05575P16WF02	WHITE BENELLI STICKER,WF	1	
5	F24	05515P16WF02	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,WF	1	
6	F24	05514P16WF02	STICKER,FRONT FACEPLATE LEFT DECORATE COVER,WF	1	
7	F24	05516P16WF03	STICKER,FRONT FACEPLATE LEFT DECORATE COVER,WF	1	
8	F24	05517P16WF03	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,WF	1	
9	F24	05578P16WF02	STICKER,RIGHT TAIL COVER,WF	1	
10	F24	05577P16WF02	STICKER,LEFT TAIL COVER,WF	1	
11	F24	05535P10WF06	BENELLI STICKER,WF	1	
12	F24	05501P160000	ABS STICKER,WF	2	

F25 STICKER (FOR RED TL)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F25	05512P16TL02	TRK STICKER,RIGHT FRONT PROTECT BOARD,TL	1	
2	F25	05511P16TL02	TRK STICKER,LEFT FRONT PROTECT BOARD,TL	1	
3	F25	05513P16TL02	502X STICKER,TL	2	
4	F25	05575P16WF02	WHITE BENELLI STICKER,TL	1	
5	F25	05515P16WF02	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,TL	1	
6	F25	05514P16WF02	STICKER,FRONT FACEPLATE LEFT DECORATE COVER.TL	1	
7	F25	05516P16TL03	STICKER,FRONT FACEPLATE LEFT DECORATE COVER,TL	1	
8	F25	05517P16TL03	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,TL	1	
9	F25	05578P16TL02	STICKER,RIGHT TAIL COVER,TL	1	
10	F25	05577P16TL02	STICKER,LEFT TAIL COVER,TL	1	
11	F25	05535P10GT06	BENELLI STICKER,TL	2	
12	F25	05501P160000	ABS STICKER,TL	2	

F26 STICKER (FOR GREY DARK JH)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	F26	05512P16JH02	TRK STICKER,RIGHT FRONT PROTECT BOARD,JH	1	
2	F26	05511P16JH02	TRK STICKER,LEFT FRONT PROTECT BOARD,JH	1	
3	F26	05513P16JH02	502X STICKER,JH	2	
4	F26	05575P16WF02	WHITE BENELLI STICKER,JH	1	
5	F26	05515P16JH02	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,JH	1	
6	F26	05514P16JH02	STICKER,FRONT FACEPLATE LEFT DECORATE COVER,JH	1	
7	F26	05516P16JH03	STICKER,FRONT FACEPLATE LEFT DECORATE COVER,JH	1	
8	F26	05517P16JH03	STICKER,FRONT FACEPLATE RIGHT DECORATE COVER,JH	1	
9	F26	05578P16JH02	STICKER,RIGHT TAIL COVER,JH	1	
10	F26	05577P16JH02	STICKER,LEFT TAIL COVER,JH	1	
11	F26	05535P10GT06	BENELLI STICKER,JH	2	
12	F26	05501P160000	ABS STICKER,JH	2	

E01 CYLINDER HEAD (气缸盖分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E01	150136030100	SCREW STOPPER	1	
2	E01	299073160000	SPARK PLUG	2	
3	E01	100126030000	WATER JACKET LOCATING SCREW GASKET	1	
4	E01	B091406014A0	DOWEL PIN	2	
5	E01	120126030000	OIL SEAL ASSY	8	
6	E01	109056280010	CYLINDER HEAD ASSY	1	
7	E01	10004609001X	SHORT STUD M8	4	
8	E01	270156030010	BOLT M6X20	2	
9	E01	120026280000	PLUG	1	
10	E01	270776280020	THERMOSTAT COVER	1	
11	E01	279165050000	WATER THERMOSTAT	1	
12	E01	120166220000	BOLT	1	
13	E01	109076280000	CYLINDER HEAD GASKET	1	
14	E01	270013160002	COOLANT TEMPERATURE SENSOR	1	
15	E01	100106030000	WATER PIPE	1	
16	E01	120133090002	WASHER	1	
17	E01	160106030100	BOLT M6X12	1	
18	E01	160056090000	O-RING 41X1.78	2	
19	E01	280146030000	AIR DUCT	2	
20	E01	280426030000	CLAMP ASSY	2	
22	E01	B0205060206H	SCREW M6X20	4	
23	E01	B0205060508H	SCREW M6X50	2	
24	E01	100306220000	PLUG	2	For vehicle vin before ZBNP16011JB946969
24	E01	150166090010	CONE PLUG M10×1	2	Start vin ZBNP16011JB946969
25	E01	100236030000	COMBINATION BOLT	6	
26	E01	109066280010	CYLINDER HEAD COMP	1	

E02 CYLINDER HEAD COVER ASSY (气缸盖罩分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E02	96200P250000	IGNITION COIL	2	
2	E02	100286030000	HIGH-PRESSURE BUNDLE SLEEVE	2	
3	E02	B190102650B0	O-RING	2	
4	E02	110026030010	DOWEL SCREW	4	
5	E02	100066030000	SEAL WASHER ASSY.	4	
6	E02	B0107060166H	BOLT	1	
7	E02	B0700000060H	SPRING WASHER 6	1	
8	E02	100276220000	COIL POSITIONING CLIP	1	
9	E02	109016220010	CYLINDER HEAD COVER	1	
10	E02	100146220000	CYLINDER HEAD COVER GASKET	1	


E03 VALVE MECHANISM SUB-ASSEMBLY (配气机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E03	129106280030	CAMSHAFT ESSY.,IN	1	
2	E03	B090103006A4	DOWEL,PIN 3X6	2	
3	E03	129036220001	SPROCKET,INTAKE	1	
4	E03	120156030000	BOLT	4	
5	E03	129036220000	SPROCKET,EXHAUST	1	
6	E03	129096280030	EXHAUST CAMSHAFT ASSY	1	
7	E03	120106030000	TAPPET	8	For vehicle vin before ZBNP16015KBA43437
7	E03	120506030430	TAPPET,MARK:430	8	Start vin ZBNP16015KBA43437
7	E03	120506030432	TAPPET,MARK:432	8	Start vin ZBNP16015KBA43437
7	E03	120506030434	TAPPET,MARK:434	8	Start vin ZBNP16015KBA43437
7	E03	120506030436	TAPPET,MARK:436	8	Start vin ZBNP16015KBA43437
7	E03	120506030438	TAPPET,MARK:438	8	Start vin ZBNP16015KBA43437
7	E03	120506030440	TAPPET,MARK:440	8	Start vin ZBNP16015KBA43437
7	E03	120506030442	TAPPET,MARK:442	8	Start vin ZBNP16015KBA43437
7	E03	120506030444	TAPPET,MARK:444	8	Start vin ZBNP16015KBA43437
7	E03	120506030446	TAPPET,MARK:446	8	Start vin ZBNP16015KBA43437
7	E03	120506030448	TAPPET,MARK:448	8	Start vin ZBNP16015KBA43437
7	E03	120506030450	TAPPET,MARK:450	8	Start vin ZBNP16015KBA43437
7	E03	120506030452	TAPPET,MARK:452	8	Start vin ZBNP16015KBA43437
7	E03	120506030454	TAPPET,MARK:454	8	Start vin ZBNP16015KBA43437
7	E03	120506030456	TAPPET,MARK:456	8	Start vin ZBNP16015KBA43437
7	E03	120506030458	TAPPET,MARK:458	8	Start vin ZBNP16015KBA43437
7	E03	120506030460	TAPPET,MARK:460	8	Start vin ZBNP16015KBA43437
8	E03	120096030000	VALVE ADJUSTING WASHER,Δ1.600MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030020	VALVE ADJUSTING WASHER,Δ1.625MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030021	VALVE ADJUSTING WASHER,Δ1.650MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030022	VALVE ADJUSTING WASHER,Δ1.675MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030023	VALVE ADJUSTING WASHER,Δ1.700MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030024	VALVE ADJUSTING WASHER,Δ1.725MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030025	VALVE ADJUSTING WASHER,Δ1.750MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030026	VALVE ADJUSTING WASHER,Δ1.775MM	8	For vehicle vin before ZBNP16015KBA43437


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
8	E03	120096030027	VALVE ADJUSTING WASHER,Δ1.800MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030028	VALVE ADJUSTING WASHER,Δ1.825MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030029	VALVE ADJUSTING WASHER,Δ1.850MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030030	VALVE ADJUSTING WASHER,Δ1.875MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030031	VALVE ADJUSTING WASHER,Δ1.900MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030032	VALVE ADJUSTING WASHER,Δ1.925MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030033	VALVE ADJUSTING WASHER,Δ1.950MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030034	VALVE ADJUSTING WASHER,Δ1.975MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030035	VALVE ADJUSTING WASHER,Δ2.000MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030036	VALVE ADJUSTING WASHER,Δ2.025MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030037	VALVE ADJUSTING WASHER,Δ2.050MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030038	VALVE ADJUSTING WASHER,Δ2.075MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030039	VALVE ADJUSTING WASHER,Δ2.100MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030040	VALVE ADJUSTING WASHER,Δ2.125MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030041	VALVE ADJUSTING WASHER,Δ2.150MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030042	VALVE ADJUSTING WASHER,Δ2.175MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030043	VALVE ADJUSTING WASHER,Δ2.200MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030044	VALVE ADJUSTING WASHER,Δ2.225MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030045	VALVE ADJUSTING WASHER,Δ2.250MM	8	For vehicle vin before ZBNP16015KBA43437
8	E03	120096030046	VALVE ADJUSTING WASHER,Δ2.275MM	8	For vehicle vin before ZBNP16015KBA43437
9	E03	120086030000	COTTER,VALVE	16	
10	E03	129336220000	RETAINER,VALVE SPRING	8	
12	E03	129216220000	SEAT,VALVE SPRING	8	
13	E03	129196030000	VALVE,EXHAUST	4	
11	E03	120186220000	SPRING,UPPER VALVE	4	
14	E03	129186030000	VALVE,INTAKE	4	
15	E03	120176220000	SPRING,VALVE INLET	4	

E04 STRAINER UNIT ASSEMBLY (正时传动机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E04	140036030000	CAMSHAFT CHAIN TENSIONER	1	
2	E04	160106030120	BOLT M6X25	2	
3	E04	140176030000	WASHER	1	
4	E04	140026280010	REAR CHAIN GUIDE ASSY.	1	
5	E04	149026280000	FRONT CHAIN GUIDE	1	
6	E04	140186030000	CHAIN PLATE COMPONENTS	1	
7	E04	129026280000	CAMSHAFT CHAIN	1	


E05 CRANKCASE SUB-ASSY (曲轴箱分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E05	150056280010	CRANKCASE ASSY	1	
2	E05	150346030000	SEAL PLATE	1	
3	E05	B0107060126H	BOLT M6X12	2	
4	E05	B0107060146H	BOLT M6X14	2	
5	E05	150136220000	PRESS PLATE	1	
6	E05	150156220000	CHAIN PLATE GUIDE PIN	1	
7	E05	150146220000	PIPE	1	
8	E05	170236090000	DOWEL PIN 10.5×13×13	2	
9	E05	150103070000	PLUG	1	
10	E05	150166280010	INLET PIPE	1	
11	E05	270156030010	BOLT M6X20	2	
12	E05	150066030000	RING 46X2.4	1	
13	E05	150116220000	RUBBER PLUG	1	
14	E05	120166030100	BOLT	2	
15	E05	150126280000	OIL COOLER TIE-IN	1	
16	E05	150316030180	BOLT M5X16	2	
17	E05	150196030020	GEAR SENSOR	1	
18	E05	150025040000	OIL SEAL	1	
19	E05	150076280000	PLUG	2	
20	E05	150086030100	SCREW STOPPER M16	3	
21	E05	150086220000	WASHER M16	3	
22	E05	150316030110	BOLT M8X75	2	
23	E05	150156030000	WASHER M8	11	
24	E05	150316030120	BOLT M10X100	1	
25	E05	240056090000	GASKET 11×18×3	3	
26	E05	150316030140	BOLT M8X45	2	
27	E05	150316030130	BOLT M8X115	1	
28	E05	150056030000	DOWEL PIN	2	
29	E05	150026280030	BEARING,RED	6	
30	E05	160106110000	CONNECT BOLT	1	
31	E05	260146090010	OIL FILTER	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
32	E05	240026090000	MINIMUM OIL PRESSURE SWITCH	1	
33	E05	270056030000	O RING	1	
34	E05	150036220000	BREATHING VALVE GASKET	1	
35	E05	150046220000	BREATHING VALVE SPACER	1	
36	E05	B0201060162H	SCREW M6X16	7	
37	E05	150316030150	BOLT M6X40	8	
38	E05	B01070808591	BOLT M8X85	6	
39	E05	260126030010	REDUCING VALVE	1	
40	E05	150316030160	BOLT M10X60	1	
41	E05	B190102580B0	O RING	1	
42	E05	150226280000	CLIP	6	
43	E05	150186280000	FLEXIBLE PIPE I	1	
44	E05	150216280000	PIPE ASSEMBLY	1	
45	E05	150176280000	PIPE	1	
46	E05	150206280000	FLEXIBLE PIPE III	1	
47	E05	150196280000	FLEXIBLE PIPE II	1	
48	E05	150156280010	OIL COOLER COVER,GREY	1	
49	E05	120055050000	O RING	1	
50	E05	150146280000	OIL COOLER BOLT	1	
51	E05	150136280000	OIL COOLER ASSY	1	
52	E05	150116030100	VARIABLE GEAR ARM POSITIONING SHAFT	1	

E06 LEFT COVER ASSY (左盖分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E06	169046280000	LEFT BACK COVER	1	
2	E06	B190101330B0	O RING 13.3X2.65	1	
3	E06	160053070030	PLUG SEE,GREY	1	
4	E06	169166030030	TIMING MARK ACCESSING SCREW,GREY	1	
5	E06	160076030000	O RING 32X2.5	1	
6	E06	160106030100	BOLT M6X12	1	
7	E06	290016220000	PHASE SENSOR	1	
8	E06	160106030120	SCREW M6x25	9	
9	E06	169026220040	LEFT COVER,MARK:BENELLI	1	
10	E06	160046030000	CLAMP PRESSURE	1	
11	E06	B0205060128H	SCREW M6X12	1	
12	E06	169076220000	LEFT COVER GASKET	1	
13	E06	B0205060326H	SCREW M6X32	3	
14	E06	160056030000	DOWEL PIN	2	

E07 RIGHT COVER ASSY (右盖分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E07	270016220020	BOLT M6X28	2	
2	E07	160083090000	OIL LEVEL INDICATOR	1	
3	E07	169106280010	RIGHT COVER	1	
4	E07	160073070000	DOWEL PIN	2	
5	E07	200001050000	OIL SEAL	1	
6	E07	169116220010	RIGHT COVER GASKET	1	
7	E07	160063070000	O-RING	1	
8	E07	160063090050	OIL FILLER PLUG	1	
9	E07	05597K740000	THE ENGINE SIDE COVER PLATE	1	
10	E07	160106030120	BOLT M6X25	14	
11	E07	200056030000	WASHER 12X22X0.8	1	
12	E07	200046030000	CLUTCH RELEASE SPRING	1	
13	E07	200096280010	OPERATING LEVER ASSY	1	
14	E07	B1212K121002	NEEDLE ROLLER BEARING 12X16X10	2	
15	E07	160016280010	CLUTCH STEEL CABLE SUPPORT	1	
16	E07	200066280000	HANDSPIKE	1	

E08 PISTON,CONNECTING ROD & CRANKSHAFT ASSY (活塞连杆曲轴平衡轴分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E08	170046280000	PISTON RING ASSY	2	
2	E08	179155050000	PISTON PIN CLIP	4	
3	E08	179146280010	PISTON PIN	2	
4	E08	179136280010	PISTON	2	
5	E08	179036280010	CONNECTING ROD ASSY.	2	
6	E08	B11130044014	FLAT KEY	1	
7	E08	170036280000	SCREW	4	
8	E08	B091403006A1	PIN	4	
9	E08	179076280000	BEARING,BLUE	4	
9	E08	179076280010	BEARING,GREEN	4	
9	E08	179076280020	BEARING,YELLOW	4	
10	E08	179256280010	BALANCE SHAFT	1	
11	E08	27002305011X	NUT M12X1.25	1	For M12, vehicle vin before ZBNP16017KB992694
11A	E08	170044320000	NUT M14X1	1	For M14, start vin ZBNP16017KB992694
12	E08	170075040000	WASHER	1	For vehicle vin before ZBNP16017KB992694
12A	E08	170034320000	WASHER	1	For M14,start vin ZBNP16017KB992694
13	E08	179016280010	CRANKSHAFT ASSY	1	
14	E08	170065050000	KEY,WOODRUFF	1	
15	E08	170096220000	FLAT KEY	1	
16	E08	170016280010	DRIVING GEAR	1	
17	E08	179236220000	BALANCER DRIVE GEAR	1	
18	E08	170016110000	WASHER	1	
19	E08	170126220000	NUT M18X1.5	1	
20	E08	B12016030503	BALL BEARING	1	
21	E08	170186220100	NUT M14X1.5	1	
22	E08	179366220000	BALANCER DRIVEN GEAR ASSY	1	
23	E08	170026280000	COLLAR	1	
24	E08	210136030010	ROLLER BEARING	1	
25	E08	210186030000	STEEL WIRE DUMPING RING	1	
26	E08	170024320000	TAPER WASHER	1	For M14,start vin ZBNP16017KB992694


E09 GEAR SHIFT MECHANISM ASSEMBLY (变速换挡机构分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E09	219016220000	STOPPER LEVER SPRING	1	
2	E09	210343090000	WASHER 6.2×14×1.5	1	
3	E09	219046220000	STOPPER LEVER ASSY	1	
4	E09	210303420000	SHIFT POSITIOMING ROLLER ARM AXLE	1	
5	E09	210323090000	SHIFT PROD	1	
6	E09	210313090000	PROD SPRING	1	
7	E09	219056030000	SHIFT DRUM	1	
8	E09	B12016600501	BEARING 16005	1	
9	E09	210356030000	DOWEL PIN	1	
10	E09	210366030000	SEGMENT	1	
11	E09	210376030000	WASHER	1	
12	E09	B0107060156H	BOLT,FLANGE,M6×15	1	
13	E09	B0109060146H	BOLT,FLANGE,M6×14	2	
14	E09	210036030000	PLATE,BEARING SETTING	1	
15	E09	210406030000	WASHER	1	
16	E09	B08010001701	CIRCLIP 17	1	
17	E09	210396030000	SLEEVE,STOP ARM	1	
18	E09	210056030000	SHIFT SHAFT SPRING	1	
19	E09	210046030000	SHIFT SHAFT SLEEVE	1	
20	E09	219066280000	SHIFT SHAFT ASSY	1	
21	E09	219106030000	LEFT SHIFT FORKS	1	
22	E09	210016030000	SPRING,SHAFT,SHIFT FORK	2	
23	E09	219086030000	SHIFT FORK SHAFT	1	
24	E09	219116030000	MIDDLE SHIFT FORK	1	
25	E09	219126030000	RIGHT SHIFT FORK	1	
26	E09	B12016020406	BEARING 6204-Z	2	
27	E09	210566030010	WASHER	1	
28	E09	219136280000	PRIMARY SHAFT ASSY	1	
29	E09	210186030000	BEARING CIRCLIP	2	
30	E09	210136030010	BEARING	2	
31	E09	210156030001	WASHER	1	


NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
32	E09	210166030101	CLUTCH NUT	1	
33	E09	210196030000	NUT M18×1	1	
34	E09	210306030000	WASHER	1	
35	E09	219296030000	DRIVE SPROCKET	1	
36	E09	210206030000	SHAFT SLEEVE 25	1	
37	E09	210316030000	O RING 25×2.5	1	
38	E09	210216030010	OIL SEAL	1	
39	E09	219216030000	SECONDARY SHAFT ASSY	1	
40	E09	210236030000	WASHER	3	
41	E09	210246030000	CIRCLIP 28	3	
42	E09	210276030000	WASHER	1	
43	E09	210266030000	WASHER	1	
44	E09	210326030000	WASHER 22×30×1	1	
45	E09	210096030000	WASHER	2	
46	E09	210106060000	CIRCLIP 24	2	
47	E09	210076030000	WASHER	1	
48	E09	210066030000	WASHER	1	
49	E09	210296030000	WASHER	1	

E10 CLUTCH SYSTEM (离合器分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E10	209016280020	CLUTCH HOUSING	1	
2	E10	200206030001	CLUTCH HUB	1	
3	E10	200376030000	PLATE,FRICTION(Ⅱ)	7	
4	E10	200216030000	CLUTCH PLATE	7	
5	E10	200226030001	DISC SPRING	1	
6	E10	200366030000	PLATE,FRICTION(I)	1	
7	E10	200236030001	WASHER	1	
8	E10	200306030001	DRIVEN DISK ASSY,CLUTCH	1	
9	E10	200246030001	CLUTCH SPRING	4	
10	E10	200256030001	PRESS PLATE	1	
11	E10	B1331060250N	BOLTS ASSEMBLY	4	
12	E10	209106280010	CLUTCH ASSY	1	
13	E10	200476030000	ROLLER BEARING	1	
14	E10	200446030000	WASHER	1	
15	E10	B12016600401	BEARING	1	
16	E10	210146280000	SPROCKET SHAFT SLEEVE	1	
17	E10	269116030000	OIL PUMP DRIVE SPROCKET	1	
18	E10	200176030001	COLLAR	1	

E11 ELECTRIC STARTER ASSY (电起动分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E11	150316030150	BOLT M6×40	2	
2	E11	249066280000	STARTER MOTOR	1	
3	E11	249046280000	STARTER IDLE GEAR	1	
4	E11	16020307001X	SHAFT,STARTER IDLER GEAR,size:φ10×45	1	
5	E11	249016280000	STARTER CLUTCH DRIVE GEAR	1	
6	E11	249106280000	STARTER CLUTCH ASSY	1	
7	E11	299026280020	FLY WHEEL ASSY	1	
8	E11	B0207080168H	SCREW M8×18	6	
9	E11	299036280000	COIL ASSY	1	
10	E11	240013060000	O RING Φ24×Φ3.1	1	

E12 OIL PAN ASSY (油底壳分总成)




NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E12	160106030130	BOLT M6X30	12	
1A	E12	270016220110	BOLT M6X35	2	
2	E12	260346030010	MAGNETISM BOLT	1	
3	E12	160073070000	DOWEL PIN 6.7 X 8 X 14	2	
4	E12	260036220000	GASKET	1	
5	E12	260016220010	SUMP COVER	1	
6	E12	260036280000	BRACKET II	1	
7	E12	260016280000	BRACKET I	1	
8	E12	219494320000	WASHER	4	

E13 LUBRICATE SYSTEM (润滑系统分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E13	160073070000	DOWEL PIN	2	
2	E13	269136280000	DOWEL PIN	2	
3	E13	160085040000	O-RING	2	
4	E13	B0107060326H	BOLT M6×32	3	
5	E13	B0107060406H	BOLT M6×40	1	
6	E13	260036030000	OIL COLLECTER SHELL	1	
7	E13	269086220000	OIL COLLECTER	1	
8	E13	100066090000	CONE PLUG M14×1.5×10	1	
9	E13	269026280000	OIL PUMP BODY	1	
10	E13	260086030000	WASHER	1	
11	E13	269036280000	OIL PUMP SHAFT	1	
12	E13	B090103016B0	PIN	1	
13	E13	269046220000	INNER ROTOR	1	
14	E13	269056220000	OUTER ROTOR	1	
15	E13	269016220000	OIL PUMP COVER	1	
16	E13	269066220000	OIL PUMP DIRVING GEAR	1	
17	E13	260106030000	WASHER 5×20×1.5	1	
18	E13	B01070501063	BOLT M5×10	1	
19	E13	B0107060306H	BOLT M6×30	3	
20	E13	269016280000	OIL PUMP ASSY	1	
21	E13	269056030000	OIL PUMP CHAIN	1	

E14 COOLING SYSTEM (冷却系统分总成)



NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E14	279216030000	IMPELLER	1	
2	E14	160253160000	WATER SEAL ASSY	1	For vehicle vin before ZBNP16005KB984746
2	E14	270216030000	EKK SEAL COMPONENTS	1	Start vin ZBNP16005KB984746
3	E14	270153160000	OIL SEAL	1	
4	E14	279316030001	WATER PUMP BODY,GREY	1	
5	E14	B190100335B0	O-RING 33.5x2.65	1	
6	E14	B12016000100	BEARING	2	
7	E14	B08010001201	CIRCLIP	1	
8	E14	27922603001X	IMPELLER SHAFT	1	
9	E14	150316030150	SCREW M6x40	2	
10	E14	279206030050	WATER PUMP,GREY	1	
11	E14	270076030000	PIPE	1	
12	E14	270156030010	BOLT M6X20	2	
13	E14	270345050000	WASHER	1	
14	E14	279336030000	WATER PUMP COVER,GREY	1	
15	E14	270066030000	SMALL SEAL RING	1	
16	E14	270166030000	BUSH	1	
17	E14	B080100028A1	CIRCLIP 28	1	
18	E14	279106280000	INTAKE PIPE	1	
19	E14	06103P160000	CLAMP 32	2	
20	E14	279116280000	EXHAUST PIPE	1	
21	E14	B17010100003	CLIP Φ10	2	

This exploded view diagram illustrates the assembly of a carburetor. The central component is the carburetor body (1), which includes the throttle body (2) and the main body (3). The diagram shows the following parts and their assembly sequence:

- Throttle Body (2):** Includes the throttle cable (4), throttle lever (5), throttle spring (6), and throttle cable bracket (7).
- Main Body (3):** Includes the main body (3), main body gasket (4), main body (5), main body (6), main body (7), main body (8), main body (9), main body (10), main body (11), main body (12), main body (13), main body (14), main body (15), main body (16), main body (17), main body (18), main body (19), main body (20), main body (21), main body (22), main body (23), main body (24), main body (25), main body (26), main body (27), main body (28), main body (29), main body (30), main body (31), main body (32), main body (33), main body (34), main body (35), main body (36), main body (37), main body (38), main body (39), main body (40), main body (41), main body (42), main body (43), main body (44), main body (45), main body (46), main body (47), main body (48), main body (49), main body (50), main body (51), main body (52).
- Jet and Needle Assembly (4):** Includes the jet (4), needle (5), needle spring (6), and needle valve (7).
- Choke and Accelerator Pump (5):** Includes the choke (5), choke lever (6), choke spring (7), and accelerator pump (8).
- Float and Needle Valve (6):** Includes the float (6), float lever (7), float spring (8), and needle valve (9).
- Throttle Cable and Lever (7):** Includes the throttle cable (7), throttle lever (8), throttle spring (9), and throttle cable bracket (10).
- Other Components (8-52):** Includes various screws, washers, and brackets (8-52) used to assemble the carburetor.

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
1	E15	280476090001	NUT M7,THROTTLE SHAFT	1	
2	E15	B07000000801	SPRING WASHER	1	
3	E15	280676030000	MANIPULATION OF THE WHEEL COMPONENT	1	
4	E15	280346090000	WASHER	1	
5	E15	280336090000	WASHER	2	
6	E15	280386030000	OIL SEAL 8X12X2.5	1	
7	E15	280016220020	THROTTLE SHAFT	1	
8	E15	280076030000	THROTTLE SLICE	2	
9	E15	280116080000	SCREW	4	
10	E15	280196030000	BUSH	1	
11	E15	280306030000	TORSIONAL SPRING,LEFT THROTTLE SHAFT	1	
12	E15	B02000501029	SCREW(M5X10)	2	
13	E15	280066220010	BRACKET	1	
14	E15	B04000500059	NUT	5	
15	E15	B02000502529	SCREW M5X25	3	
16	E15	280506030010	PIPE	1	
17	E15	3314302E0000	OIL INLET CAP	1	
18	E15	289026280000	FUEL INJECTOR	2	
19	E15	289086280010	FUEL	1	
20	E15	289066280000	SENSOR,INLET PRESSURE	1	
21	E15	B02040501629	SCREW	2	
22	E15	289076280000	RUBBER HOSE	1	
23	E15	49016T030000	CLAMP Φ8	2	
24	E15	3313701K0000	BRASS TUBE	1	
25	E15	280686030000	SEALING RING	1	
26	E15	280576030000	SEALING COVER PLATE	1	
27	E15	B02000300829	SCREW M3X8	1	
28	E15	280116090000	NEEDLE ROLLER BEARING	1	
29	E15	280249010000	SHAFT CIRCLIP,THROTTLE SHAFT	1	
30	E15	280116130000	TPS PLATE	1	
31	E15	B02010401225	SCREW M4X12	2	

NO.	Position No.	CODE	EN DESCRIPTION	Qty/Unit	Remark
32	E15	280756030010	SENSOR,THE LOCTION OF THROTTLE	1	
33	E15	B0703000400A	WASHER	2	
34	E15	B13080401029	SCREW M4X10	2	
35	E15	B02040501429	SCREW M5X14	2	
36	E15	289066220000	THROTTLE BODY	1	
37	E15	280716030000	NEGATIVE PRESSURE COPPER PIPE	2	
38	E15	06103N140000	CLAMP Φ13	4	
39	E15	280946030000	HOSE II	1	
40	E15	280956030000	INTAKE OF BRASS	2	
41	E15	280396030000	PLATE I	1	
42	E15	140106090000	O-RING	1	
43	E15	280476030020	REPEATING MOTOR	1	
44	E15	B07000000509	ELASTIC WASHER	2	
45	E15	280976030000	BUSH	2	
46	E15	280936030000	RUBBER HOSE I	1	
47	E15	280966030000	TIMING SYSTEM	1	
48	E15	57039S010000	RUBBER CUSHION	2	
49	E15	280406090000	ADJUSTING SCREW	2	
50	E15	280416090000	SEALING RING,ADJUSTING SCREW	2	
51	E15	B02000601624	SCREW M6X12	1	
52	E15	289006280010	THROTTLE ASSY	1	